




# Non-Programmable Electronic Thermostat

Non-Programmable, Auto Changeover, Fan Speed Control, Hardwire  
Daikin P/N (668811001)

- Single Stage Heat Pump/Non-Heat Pump Systems
- Backlit Display
- Single Stage Heat/Cool Systems
- Two Speed Fan Control
- Field Calibration
- Auto Changeover
- Button Lockout Function
- Remote Temperature Sensor Capability
- Title 24 Compliant / No Batteries Required
- Relay Outputs (minimum voltage drop in thermostat)
- Ideally Suited for:
  - Residential (New Construction/Replacement)
  - Light Commercial



## Installation, Operation & Application Guide



Version C: 06-30-15

\*\* Note: PROG refers to the spot immediately to the right of "MODE", directly below the down arrow.

### Specifications

- Electrical Rating:**
- 24 VAC (18 to 30 VAC)
  - 3 amp maximum total load
  - 1 amp maximum per terminal
- Temperature control ranges:** 45°F to 90°F **Accuracy:** ± 1°F
- System configurations:** 1-stage heat, 1-stage cool
- Timing:** Anti-short Cycle: 5 minutes  
Backlight Operation: 10 seconds
- Terminations:** C, RH, RC, W, Y, B, O, G1, G2, S1, S2

### Important Safety Information



Always turn off power at the main power supply before installing, cleaning, or removing thermostat.

- This thermostat is for 24 VAC applications only; do not use on voltages over 30 VAC
- Do not short across terminals of system control to test operation; this will damage your thermostat and void your warranty
- All wiring must conform to local and national electrical and building codes
- Use this thermostat only as described in this manual

### Package Contents/Tools Required

**Package includes:** Daikin 668811001 non-programmable thermostat and Operation and Application Guide.

### To Remove Existing Thermostat



**ELECTRICAL SHOCK HAZARD** – Turn off power at the main service panel by removing the fuse or switching the appropriate circuit breaker to the OFF position before removing the existing thermostat.

1. Turn off power to the heating and cooling system by removing the fuse or switching the appropriate circuit breaker off.
2. Remove old thermostat. This should expose the wires.
3. Label the existing wires before removing wires.
4. After labeling wires, remove wires from wire terminals.
5. Refer to the following section for instructions on how to install this thermostat.

### To Install Thermostat



**ELECTRICAL SHOCK HAZARD** – Turn off power at the main service panel by removing the fuse or switching the appropriate circuit breaker to the OFF position before removing the existing thermostat.

**IMPORTANT:** Thermostat installation must conform to local and national building and electrical codes and ordinances.

1. Turn off power to the heating and cooling system by removing the fuse or switching the appropriate circuit breaker off.
2. Insert stripped, labeled wires in matching wire terminals. See "Wiring Diagrams" section of this manual.




Be sure exposed portion of wires does not touch other wires.

3. Tighten screws on terminal block. Gently tug wire to be sure of proper connection. Double check that each wire is connected to the proper terminal.
4. Remove unused Gas/Electric jumper. Keep **gas** for oil or gas systems. Keep **electric** for heat pumps or electric heat systems.
5. Replace thermostat by snapping it in place.
6. Turn on power to the system at the main service panel.
7. Test thermostat operation as described in "Testing the Thermostat".

### Remote Sensor Installation (Optional)


1. Remove cover from remote sensor housing.
2. Select an appropriate location for mounting the remote sensor.
3. Mount remote sensor unit using hardware provided.
4. Install two strand shielded wire between remote sensor and thermostat. Shielded wire must be used. Do not run remote sensor wire in conduit with other wires.
  - **Wire 1** should run between the S1 terminal on the thermostat and the S1 terminal on the remote sensor
  - **Wire 2** should run between the S2 terminal on the thermostat and the S2 terminal on the remote sensor
  - Connect the shielding of the wire to the S2 terminal on the thermostat
5. Disable the main sensor (R12) on the thermostat by cutting it from the circuit board.



## Wiring Diagrams

### Heating/Cooling

#### 6-Wire, Single Transformer



### Configuration Mode

\*\* Note: PROG refers to the spot immediately to the right of "MODE", directly below the down arrow.


The configuration mode is used to set the Daikin 668811001 thermostat to match your heating/cooling system. The Daikin 668811001 thermostat functions with heat pump, air conditioning, gas, oil or electric heat systems.

1. To enter the configuration mode, simultaneously hold down the  $\vee$  and  $\wedge$  buttons while the Daikin 668811001 thermostat is in OFF mode.
2. Press the  $\vee$  or  $\wedge$  button to change settings within each screen.
3. Press the **PROG** button to advance to the next screen.
- \*\* Note: The **MODE** button will return you to the previous screen.
4. To exit configuration mode, hold the **PROG** button for 6 seconds.



### Configuration Mode Settings

1. Temperature scale (F or C) – Choose Fahrenheit or Celsius.  
Press the  $\vee$  or  $\wedge$  button to select.  
Press the **PROG** button to advance to the next screen.
2. Differential (1°F - 5°F) (1°C - 3°C) – Set the number of degrees between your "turn on" temperature and your "setpoint" temperature.  
Press the  $\vee$  or  $\wedge$  button to set differential value.  
Press the **PROG** button to advance to the next screen.
3. Deadband (1°F - 9°F) (1°C - 5°C) – Set the minimum number of degrees between your heating system activation and your cooling system activation.  
Press the  $\vee$  or  $\wedge$  button to set deadband value.  
Press the **PROG** button to advance to the next screen.
4. Heat pump – Press the  $\vee$  or  $\wedge$  button to configure as heat pump, or non-heat pump system.
  - ON = Heat pump system – 4 minute time delay with heat and cool
  - OFF = Non-heat pump system – 4 minute time delay with cool only
 Press the **PROG** button to advance to the next screen.
5. Lockout (0-8°, NITE, COOL-HEAT) – Select the number of degrees set temperature can be changed during keypad lockout or select to lockout during NITE period only. COOL-HEAT lockout allows adjustment of the set temperatures to the maximum heat set temperature selected in Step 6 and minimum cool set temperature selected in Step 7.  
\*\* Note: The mode cannot be changed when the thermostat is locked.  
Press the  $\vee$  or  $\wedge$  button to select.  
Press the **PROG** button to advance to the next screen.
6. Maximum Heat Setpoint (45°F - 90°F) (7°C - 32°C)  
Adjust to control the maximum heat set temperature allowed.  
Press the  $\vee$  or  $\wedge$  button to select.  
Press the **PROG** button to advance to the next screen.
7. Minimum Cool Setpoint (45°F - 90°F) (7°C - 32°C)  
Adjust to control the minimum cool set temperature allowed.  
Press the  $\vee$  or  $\wedge$  button to select.  
Press the **PROG** button to advance to the next screen.
8. Room temperature offset (+9°F to -9°F) (+5°C to -5°C).  
Adjust to calibrate displayed room temperature to match actual room temperature.  
Press the **PROG** button to advance to the next screen.
9. Maximum compressor cycles allowed per hour (d, 2-6).  
-- = as many as needed, 2-6 = maximum cycles/hour  
Press the **PROG** button to advance to the next screen.
10. Status indicator light (ON, OFF).  
Press the  $\vee$  or  $\wedge$  button to select.  
To exit configuration mode, press the **PROG** button for 6 seconds.



### Starting the Thermostat

\*\* Note: First button press activates backlight only.

1. Move the Fan Auto/On switch to the Auto position.
2. Press the **MODE** button to enter desired operating mode.




## Testing the Thermostat

Once the thermostat is installed, it should be thoroughly tested.

### Cool Test

1. Press mode button until cool mode is displayed.
2. Adjust set temperature so it is 5 degrees below room temperature.
3. Air conditioning should come on. Green LED turns ON.
4. Adjust the set temperature 2 degrees above the room temperature and the A/C should turn off. There may be a fan delay on your system.


\*\* **Note:** *There is a four-minute time delay to protect the compressor after it turns off.*



### Heat Test

1. Press mode button until heat mode is displayed.
2. Adjust the set temperature so it is 5 degrees above the room temperature.
3. Heat should come on. Red LED turns ON.
4. Adjust the set temperature 2 degrees below the room temperature and the heat should turn off. There may be a fan delay on your system.

\*\* **Note:** *For heat pumps, there is a four-minute delay to protect your compressor.*



### Fan Test

1. Slide fan switch to ON position. Indoor fan turns ON.
2. Slide fan switch to Auto position. Indoor fan turns OFF.



## Mode of Operation

The Daikin 668811001 thermostat is a non-programmable, auto changeover, single stage heat, single stage cool thermostat. It functions with air conditioning, heat pumps, gas, oil or electric heat systems.

The thermostat activates the heating appliance when the room temperature is below the set heat temperature (by the differential temperature) and the red indicator light on the thermostat will light. The Daikin 668811001 thermostat will stop outputting and the red light will turn off when the call for heat has been satisfied. With heat pumps, the thermostat will not let the compressor come on for 4 minutes after it turns off. This protects your compressor.

When the room temperature is greater than the set cool temperature (by the differential temperature), the cooling device is activated and the green indicator light on the thermostat will turn on. The Daikin 668811001 thermostat will stop outputting and the green light will turn off when the call for cooling is satisfied. The thermostat will not let the compressor come on for 4 minutes after it turns off. This protects your compressor.

The Daikin 668811001 thermostat has four possible operating modes: OFF, Heat, Cool, and Heat & Cool mode. In off mode, the thermostat will not turn on heating or cooling devices. The manual fan can be turned on in all operating modes using the fan switch and the fan speed can be set in all operating modes using the fan speed switch. In heat mode, the thermostat controls the heating system. In the Cool mode, the thermostat controls the cooling system. In heat & cool mode, the thermostat controls both the heating and cooling systems.

The Daikin 668811001 thermostat also has a button lockout feature. This enables the thermostat to be set to the proper mode and temperature and locked so it cannot be tampered with.

## Operating Modes

There are five possible operating modes for the Daikin 668811001 thermostat. Off, Cool, Heat, and Cool & Heat modes are accessed by pressing the Mode button. Continuous fan mode is accessed by setting the auto/on switch to ON.

### OFF Mode

- In this mode, the thermostat will not turn on the heat pump.

### Continuous Fan Mode

- The indoor fan can be turned on manually in every operating mode by sliding the auto/on switch to ON.

### Cool Mode

- In this mode, the thermostat controls the cooling system

\*\* **Note:** *There is a four minute delay for your compressor to restart after it has turned off.*



### Heat Mode

- In this mode, the thermostat controls the heating system

\*\* **Note:** *For heat pumps, there is a four minute delay for your compressor to restart after it has turned off.*

### Cool and Heat Mode (Auto Changeover)

- In this mode, the thermostat controls the cooling and heating systems, automatically changing over from one to the other as needed



## Lockout Function

The Daikin 668811001 thermostat thermostat has a button lockout feature so the settings cannot be changed or tampered with. With the lockout activated, any button press will result in "LOC" being displayed.

To activate the LOC function:

1. Press the **MODE** button and hold it in.
2. Also press the **PROG** button and keep both depressed for 10 seconds.
3. LOC will display and all buttons will be disabled.

To deactivate the LOC feature, repeat steps 1 & 2 above.



## Troubleshooting

Symptom	Remedy
No display	Check for 24 VAC at thermostat; display is blank when 24 VAC is not present
System fan does not come on properly	Verify wiring is correct
All thermostat buttons are inoperative	Verify 24 VAC is present; unit locks out when 24 VAC is not present
No response with first button press	First button press activates backlight only
Thermostat turns on and off too frequently	Adjust temperature differential (see "Configuration Mode Setting 2")
Fan runs continuously	Check Fan On/Auto switch, fan runs continuously in On position
Status indicator light not on during call	Turn status indicator function on (see "Configuration Mode Setting 10")
Room temperature is not correct	Verify wall hole for wires is plugged with putty or insulation, calibrate thermostat (see "Configuration Mode Setting 8"). If remote sensor is used, check S1 and S2 terminal connections
LOC displays when any button is pressed	Thermostat has the button lockout function activated (see "Lockout Function")
-- on display instead of room temperature	Check for a bad connection at S1 and S2 terminals, if used
Problem not listed above	Press Reset button once*

\* **Reset Button Function:** Time, day and mode changed to last saved settings (saved after power loss or when exiting).

### Daikin Training and Development

Now that you have made an investment in modern, efficient **Daikin** equipment, its care should be a high priority. For training information on all **Daikin** HVAC products, please visit us at [www.DaikinApplied.com](http://www.DaikinApplied.com) and click on Training, or call 540-248-9646 and ask for the Training Department.

### Warranty

All **Daikin** equipment is sold pursuant to its standard terms and conditions of sale, including Limited Product Warranty. Consult your local Daikin Representative for warranty details. Refer to Form 933-430285Y. To find your local **Daikin** Representative, go to [www.DaikinApplied.com](http://www.DaikinApplied.com).

### Aftermarket Services

To find your local parts office, visit [www.DaikinApplied.com](http://www.DaikinApplied.com) or call **800-37PARTS (800-377-2787)**. To find your local service office, visit [www.DaikinApplied.com](http://www.DaikinApplied.com) or call **800-432-1342**. This document contains the most current product information as of this printing. For the most up-to-date product information, please go to [www.DaikinApplied.com](http://www.DaikinApplied.com).

Products manufactured in an ISO certified facility.

