



Operation and Maintenance Manual

OM 844-6

Group: Applied Air Systems

Part Number: OM 844

Date: July 2019

MD2 Variable Speed Drive Controllers

Commercial Packaged Rooftop Units—MPS 015 to 075 Tons

Indoor and Outdoor Air Handler Units—LAH, CAC, CAH, OAC, and OAH

Packaged Rooftop Units—MPS, RPS, RFS, RDT, RPE, and RDE

Rooftop Air Handler Units—RDS and RAH

Vertical Self-Contained Units—SWP and SWT



Introduction	3	Appendix F — Restoring Default Parameters	46
Applications with MicroTech II and MicroTech III Controls	3	<i>LYP</i> : Default Setting	46
Applications without MicroTech II and MicroTech III Controls	3	Appendix G — Rooftop and Self-Contained SAF, RAF, and EAF Applications	52
Replacement VFD	3	Rooftop and Self-Contained with MicroTech III Controls for SAF, RAF, and EAF Applications	52
Hazardous Information Messages	3	Appendix H — Maverick II for SAF and EAF Applications	54
Before You Begin	4	Maverick II with MicroTech III Controls for SAF and EAF Applications	54
Bus Voltage Measurement Procedure	4	Appendix J — Rooftop and Self-Contained for Speedtrol Control	56
Initial Start-Up	5	Rooftop and Self-Contained with MicroTech III Controls for Speedtrol Condenser Fan Control	56
Control Terminals	6	Appendix K — Rooftop Energy Recovery Wheel Speed Control MicroTech III	58
Switch Settings and Terminal Designations	8	Rooftop Energy Recovery Wheel Speed Control MicroTech III	58
Integrated Display Terminal	9	Appendix L — Parameter Settings for Maverick I Units with DDC Control	60
Programming	10	Appendix M — Controls by Others	61
Mode Access	10	Controls by Others for SAF, RAF, and EAF Applications	61
Parameter Groups	10	Appendix N — Parameter List Drawing Reference	64
Access to Menus and Parameters	11	Appendix O — Scaling the Analog Output Through the FM Terminal	65
AUF Quick Menu	13	Appendix P — MPS 30–35 SpeedTrol with VFD Compressor	67
<i>AUF</i> Quick Menu	13	MPS 30-35 VFD Compressor with MicroTech III Controls for Speedtrol Condenser Fan Control	67
<i>AUF</i> Quick Menu Parameters	14	Appendix Q — MPS 40–50 SpeedTrol with VFD Compressor	72
Setting the Acceleration/Deceleration Ramp Times	15	MPS 40–50 VFD Compressor with MicroTech III Controls for Speedtrol Condenser Fan Control	72
Troubleshooting Fault and Alarm Codes	25	Appendix R — Digital Compressor SpeedTrol Condenser Fan Control	77
Drive Controller Fault Conditions	25	Digital Compressor with MicroTech III Controls for Speedtrol Condenser Fan Control	77
Drive Controller Alarm Conditions	28	Appendix S — Setting up for Smoke Purge with the Return Fan	82
Pre-Alarm Displays	29		
Resetting the Drive Controller after a Fault Condition	29		
Appendix A — Input Terminal Functions	30		
Appendix B — Output Terminal Functions	33		
Appendix C—Receiving and Preliminary Inspection	35		
Storing and Shipping	35		
Lifting and Handling	35		
Appendix D — Wiring Recommendations	39		
Field Control Wiring and General Background for Reconnecting Wiring to a Replacement VFD	39		
Branch Circuit Protection and General Background for Reconnecting a Replacement VFD	40		
Appendix E — Quick Reference Guide	42		
Mode Navigation	43		

 **WARNING**

UNINTENDED EQUIPMENT OPERATION

- Modifying or changing parameters whose function is not described in this manual will affect drive controller operation. Some register changes will take effect as soon as they are entered.
- Do not modify or change parameters whose function is not described in this instruction manual.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

Applications with MicroTech® II and MicroTech® III Controls

The variable speed drive has been selected and coordinated with the Daikin air conditioning equipment's unit controller. The drive that is installed on the Daikin packaged equipment has the parameters modified for the HVAC application. For the standard HVAC system design, no further modifications should need to be made to the drive.

Applications without MicroTech II and MicroTech III Controls

The Daikin variable speed drive has been selected and coordinated with the Daikin air conditioning equipment's unit controller. The drive that is installed on the Daikin packaged equipment has the parameters modified for the HVAC application. For the standard HVAC system design, no further modifications should need to be made to the drive. Information for MicroTech II applications can be found in Appendix sections G, H, J & K. Information for MicroTech II applications for the Maverick II equipment can be found in Appendix section H. Information for MicroTech III applications are located in the Appendix G, H, J & K sections of this manual.

Replacement VFD

When replacing a VFD, the owner/installer must determine which of the above listed applications applies and follow the appropriate procedures within this manual.

Hazardous Information Messages

Read these instructions carefully and look at the equipment to become familiar with the device before trying to install, operate, service, or maintain it. The following special messages may appear throughout this bulletin or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.

 **CAUTION**

Cautions indicate potentially hazardous situations, which can result in personal injury or equipment damage if not avoided.

 **WARNING**

Warnings indicate potentially hazardous situations, which can result in property damage, severe personal injury, or death if not avoided.

 **WARNING**

Warning indicates potentially hazardous situations for PVC (Polyvinyl Chloride) and CPVC (Chlorinated Polyvinyl Chloride) piping in chilled water systems. In the event the pipe is exposed to POE (Polyolester) oil used in the refrigerant system, the pipe can be chemically damaged and pipe failure can occur.

 **DANGER**

Dangers indicate a hazardous electrical situation which will result in death or serious injury if not avoided.

 **DANGER**

Dangers indicate a hazardous gas situation which will result in death or serious injury if not avoided.

 **NOTICE**

Notices give important information concerning a process, procedure, special handling or equipment attributes.

Before You Begin

Read and understand these instructions before performing any procedure on this drive controller.

⚠ DANGER

HAZARDOUS VOLTAGE

- Read and understand this manual before installing or operating the MD2 drive controller. Installation, adjustment, repair, and maintenance must be performed by qualified personnel.
- The user is responsible for compliance with all international and national electrical code requirements with respect to grounding of all equipment.
- Many parts of this drive controller, including the printed circuit boards, operate at the line voltage. **DO NOT TOUCH.** Use only electrically insulated tools.
- Before servicing the drive controller:
 - Disconnect all power.
 - Place a “DO NOT TURN ON” label on all power disconnects.
 - Lock all power disconnects in the open/off position.
- **DO NOT** touch unshielded components or terminal strip screw connections with voltage present.
- **DO NOT** short across terminals PA/+ and PC/- or across the DC bus capacitors.
- Install and close all covers before applying power or starting and stopping the drive controller.
- Disconnect all power, including external control power that may be present, before servicing the drive controller. **WAIT 15 MINUTES** to allow the DC bus capacitors to discharge. Then follow the DC bus voltage measurement procedure on page 6 to verify that the DC voltage is less than 45 V. The drive LEDs are not accurate indicators of the absence of DC bus voltage.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

⚠ CAUTION

IMPROPER DRIVE CONTROLLER OPERATION

- If the drive controller is de-energized for a prolonged period, the performance of the electrolytic capacitors will be reduced.
- Once a year, apply power to the drive controller for at least 5 hours to restore the performance of the capacitors, then check its operation.
- If the drive has not been powered for more than a year, do not connect the drive controller to the line voltage. Gradually increase the voltage using an adjustable AC source.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

⚠ DANGER

AUTOMATIC RESTART ENABLED

- This drive controller can restart under fault conditions.
- Equipment must be shut down, locked out and tagged out to perform servicing or maintenance.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

Bus Voltage Measurement Procedure

⚠ DANGER

HAZARDOUS VOLTAGE

Read and understand the precautions in “Before You Begin” on page 5 before performing this procedure.


Failure to follow this instruction can result in death, serious injury, or equipment damage.

Before working on the drive controller, turn it OFF and wait 15 minutes to allow the DC bus to discharge and then measure the DC bus voltage.

The DC bus voltage can exceed 1000 Vdc. Use a properly rated voltage-sensing device when performing this procedure. To measure the DC bus voltage:

1. Disconnect all power and wait 15 minutes to allow the DC bus to discharge.
2. Measure the voltage of the DC bus between the PA/+ and PC/- terminals to ensure that the voltage is less than 45 Vdc.
3. If the DC bus capacitors do not discharge completely, contact your local Daikin Representative. Do not repair or operate the drive controller.

Figure 1: Capacitor Charging LED



Initial Start-Up

Before providing power to the VFD, refer to the appropriate unit installation/maintenance manual(s) listed below:

- [IM 487](#) for rooftop air handlers (RDS and RAH)
- [IM 708](#) for one-piece self-contained units
- [IM 709](#) for modular self-contained units
- [IM 738](#) for RoofPak® packaged rooftops with air-cooled condensers (RPS, RFS, and RDT)
- [IM 791](#) for packaged rooftops with evaporative condensers (RPE and RDE)
- [IM 843](#) for Maverick® II commercial rooftop units

Perform the following (MicroTech III example) general procedures on the specific unit purchased (yours may differ slightly depending on the unit)

1. Before closing (connecting) the power disconnect switch, open (disconnect) the following unit control circuit switches:
 - a. Turn system switch S1 to OFF
 - b. Turn system switch S7 to OFF
2. Confirm duct static pressure sensor SPS1 is connected to the ductwork.
3. Confirm the VFD lugs for the line voltage are tight.
4. Confirm the horsepower (hp) of the drive matches that of the motor.

Before Starting the Fan and VFD

1. Close the unit disconnect switch. With the control system switch S1 in the OFF position, power should be available only to the control circuit transformer (TI) and the compressor crankcase heaters.
2. Turn the Switch S1 to ON. Power should now be supplied to the control panel.
3. Verify all duct isolation dampers are open. Unit mounted isolation dampers may be mounted in the supply or return sections.
4. Place the unit into the “Fan Only” mode through the keypad menu *Standard Menu\System\Ctrl Mode= Fan Only*.
5. Confirm the power supply matches the setting of the ... parameter.
6. Confirm the power supply frequency matches that of the ... parameter.
7. Confirm the thermal protection level, ... (or amps), matches that of the motor.

NOTE: All of the above parameters can be quickly found in the AUF Quick menu.

Start the Fan and VFD

1. Turn Switch S7 to ON. The controller should enter the “Startup” operating state. If the fan does not run at the completion of the startup mode:
 - a. Check fuses F1 and F3.
 - b. Check that the manual motor protectors or circuit breakers have not tripped.
 - c. Check the optional phase monitor.
2. If the fans are equipped with optional spring isolators, check the fan spring mount adjustment. When the fans are running they should be level.
3. Verify the rotation is correct.
4. Verify the DHL safety is opening at a pressure compatible with duct working pressure limits.

NOTE: Refer to the unit IMs for additional non-VFD instructions.

⚠ DANGER

UNINTENDED EQUIPMENT OPERATION

- The accidental grounding of logic inputs configured for Sink Logic can result in unintended activation of drive controller functions.
- Protect the signal conductors against damage that could result in unintentional conductor grounding.
- Follow NFPA 79 and EN 60204 guidelines for proper control circuit grounding practices.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

⚠ WARNING


RISK OF IMPROPER OPERATION

The MD2 logic input selector switch (SW4) is factory-set to the source position. The switch should never be moved to the PLC or sink position.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

The control terminals are illustrated in [Figure 2](#) (for more details refer to specific wiring schematics and parameter settings in the appropriate Appendix section located at the back of this manual).

Figure 2: Control Terminals



Switch	Factory Setting
SW100 VIA voltage/current selection VIB voltage/PTC selection (1)	Voltage (U) Voltage (U)
SW101 (FM voltage/ current selection)	Voltage (U)
SW102 Selection of logic type	Source
SW103 Selection of communication terminal resistor (2)	Term no resistor

Control terminal wire size and torque:

Applicable wire size:
 - Screw terminals : 0.75 to 2.5 mm² (AWG 18 to 14)
 - Spring terminals : 0.2 to 1 mm² (AWG 24 to 16)
 Tightening torque:
 0.5 to 0.6 N·m (4.4 to 5.3 lb-in)

(1) When SW100 is set to PTC, VIB is configured as PTC input connected to the 3.3 kΩ internal resistor. Connect the PTC probe between CC and VIB terminals.

If the 3.3 kΩ internal resistor does not suit the installation, regarding to the PTC resistor value, set SW100 to VIB, connect the PTC probe between CC and VIB terminals and add an external resistor between PP and VIB terminals.

(2) When SW103 is set to Term, internal 120 Ω termination resistor is connected between A and B terminals.

Table 1: Control Terminal Characteristics

Terminals	Function	Characteristics
PLC	External power supply input	Input for external power supply for logic inputs Max. permissible voltage: 50 Vac
P24	Internal supply	Short-circuit and overload protection: supply (), maximum current: 200 mA
CC	Common	0 V common (2 terminals)
FLA, FLB, FLC	Configurable relay outputs	One relay logic output, one N/C contact, and one N/O contact with common point Minimum switching capacity: Maximum switching capacity: • On resistive load: 5 A for 250 Vac or 30 Vdc • On inductive load: 2 A for 250 Vac or 30 Vdc Max. response time: 7 ms ± 0.5 ms Electrical service life: 100,000 operations
RY, RC		One relay logic output, one N/O contact Minimum switching capacity: Maximum switching capacity: • On resistive load: 5 A for 250 Vac or 30 Vdc • On inductive load: 2 A for 250 Vac or 30 Vdc Max. response time: 7 ms ± 0.5 ms Electrical service life: 100,000 operations
F, R, RES	Logic inputs	Three programmable logic inputs, compatible with level 1 PLC, IEC 65A-68 standard Impedance: 3.5 kΩ Maximum voltage: 30 V Max. sampling time: 2 ms ± 0.5 ms Multiple assignment makes it possible to configure several functions on one input
		Positive logic (Source): State 0 if ≤ 5 V or logic input not wired, state 1 if ≥ 11 V
		Negative logic (Sink): State 0 if ≥ 16 V or logic input not wired, state 1 if ≤ 10 V
FM	Analog output	One switch-configurable voltage or current analog output: • Voltage analog output 0–10 Vdc, minimum load impedance 470Ω • Current analog output X–Y mA by programming X and Y from 0 to 20 mA, maximum load impedance: 500Ω Max. sampling time: 2 ms ± 0.5 ms Resolution: 10 bits Accuracy: ± 1% for a temperature variation of 60°C Linearity: ± 0.2%
PP	Internal supply available	Short-circuit and overload protection: One 10.5 Vdc ± 5% supply for the reference potentiometer (1 to 10 k.), maximum current: 10 mA
VIA	Analog/logic input	dc +/- 3 Vdc
VIB	Analog input	dc

⚠ DANGER

UNINTENDED EQUIPMENT OPERATION


- The accidental grounding of logic inputs configured for Sink Logic can result in unintended activation of drive controller functions.
- Protect the signal conductors against damage that could result in unintentional conductor grounding.
- Follow NFPA 79 and EN 60204 guidelines for proper control circuit grounding practices.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

Table 2: Drive Controller Default Terminal Function Assignments

Terminal	Function
FLA-FLB-FLC relay	De-energized in the event of a fault or when the power supply is disconnected
RY-RC relayspeed (L. L.)	Energized when the speed is greater than or equal to low
F	Forward (2-wire control)
R	Preset speed
RES	Fault reset
VIA	Speed reference 0-10 Vdc
VIB	Not assigned
FM	Output frequency

Figure 3: Switches



NOTE: Refer to specific wiring schematics and parameter settings in the appropriate Appendix section located at the back of this manual for HVAC application and switch settings.

The logic input switch SW4 is set to the source position. The switch should never be moved to the PLC or sink position.


⚠ DANGER

STOP BUTTON CAN CAUSE MOTOR RESTART

- The Stop Button on this drive controller can reset faults and restart the motor if an active run command is present.
- Disable all run commands and inspect the drive system for the cause of the fault before activating a fault reset.
- Disable the panel reset operation (*F 735*) to remove this hazard.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

Figure 4: Description of Display Terminal



The LEDs and keys on the integrated display terminal are illustrated in Figure 4.

NOTE: Display terminal functions described above reflect VFD default settings.

Table 3: Display Terminal Features

LED/Key	Characteristics
1	Display RUN LED <ul style="list-style-type: none"> • Illuminates when a Run command is applied to the drive controller. • Flashes when there is a speed reference present with a Run command.
2	Display PRG LED <ul style="list-style-type: none"> • Illuminates when Programming mode is active. • Flashes in <i>RUF - Gr U</i> modes.
3	Display MON LED <ul style="list-style-type: none"> • Illuminates when Monitoring mode is active. • Flashes in Fault History Display mode.
4	Up/Down Keys <p>Depending on the mode, you can use the arrows to:</p> <ul style="list-style-type: none"> • Navigate between the menus • Change a value • Change the speed reference when the Up/Down LED (5) is illuminated
5	Up/Down LED <p>Illuminates when the navigation arrows are controlling the speed reference.</p>
6	Run LED <p>Illuminates when the Run key is enabled.</p>
7	Run Button <p>Pressing this button/key when the Run LED is illuminated starts the drive controller.</p>
8	Display <p>4-digit, 7-segment LED display</p>
9	Units LEDs <ul style="list-style-type: none"> • The % LED illuminates when the display numeric value is in percentage. • The Hz LED illuminates when the display numeric value is in Hertz.
10	Loc/Rem LED <ul style="list-style-type: none"> • Local/Remote mode indicator. Illuminates when Local mode is selected.
11	Mode Button <p>Press to select the Mode</p> <ul style="list-style-type: none"> • Display mode (default) • Adjustment mode • Monitoring mode <p>Can also be used to go back to the previous menu</p>
12	Loc/Rem Button <p>Switches between Local and Remote modes</p>
13	ENT Button <p>Press to display a parameter's value or to save a changed value</p>
14	Stop Button <ul style="list-style-type: none"> • In Local mode (12), pressing the STOP key decelerates the drive to a stop • In Remote mode (see table item #10), while the VFD is being controlled by the unit controller, pressing the STOP key will allow the drive to freewheel stop (drive display will indicate a flashing "E") • If <i>F 735</i> is set to 0 (default setting), pressing the stop key twice will reset the flashing "E" fault and other resettable faults if the fault condition has been resolved


Mode Access

MD2 drive controllers have three modes of operation described in Table 4. Figure 5 illustrates how to access the modes with the display terminal MODE key.

Table 4: Mode Descriptions

Display mode (default)	<ul style="list-style-type: none"> Active when power is applied to the drive controller Use to display drive controller parameters, alarms, and faults
Adjustment mode	<ul style="list-style-type: none"> Use to modify drive controller parameters
Monitoring mode	<ul style="list-style-type: none"> Use to monitor drive controller status

Figure 5: Mode Access



Parameter Groups

WARNING

UNINTENDED EQUIPMENT OPERATION

- Any parameter values altered from the VFD control panel will affect the operation of the drive.
- If parameter “ P_{5P} ” is selected and changed, altered parameters will be transferred into the VFD memory and may affect safe operation of the equipment.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

MD2 drive controllers are factory programmed per your HVAC application (refer to specific wiring schematics and parameter settings in the appropriate Appendix section located at the back of this manual for application options and settings). To restore Daikin factory settings, use parameter “ P_{5P} ” (see [Default Setting on page 17](#)).

Table 5: MD2 Parameter Groups

Parameter Type	Description
Basic parameters	Parameters that need validation before using the drive controller.
Extended Parameters (menu F_{---})	Parameters for special settings and applications.
User Parameters (menu G_{U-})	Subset of Basic and Extended parameters whose values have changed from the VFD default settings.
Quick menu (menu AUF)	Subset of Basic and Extended parameters frequently used.
History Parameters (menu AUH)	Subset of Basic and Extended parameters displaying the five parameters that were last changed, displayed in reverse chronological order.

Access to Menus and Parameters

Figure 6: Menu Access






Figure 7: Access to Parameters



AUF Quick Menu

Figure 8 illustrates the parameters accessible from the AUF Quick menu.

Figure 8: AUF Quick Menu Parameters



AUF Quick Menu Parameters

Table 6 describes the parameters that can be accessed from the AUF Quick menu. With the exception of ACC and DEC , the parameters cannot be modified while the drive controller is running.

NOTE: With the exception of ACC and DEC , the parameters cannot be modified while the drive controller is running.

Table 6: AUF Quick Menu Parameters

Code	Description	Unit	Adjustment Range
ACC	Acceleration time	Seconds	0.0 to 3200
DEC	Deceleration time	Seconds	0.0 to 3200
LL	Frequency lower limit (minimum motor frequency)	Hz	0.0 to . .
UL	Frequency upper limit (maximum motor frequency)	Hz	0.5 to 200.0
THR	Motor electronic thermal protection level in amperes. Adjust THR to the nominal current value which appears on the motor nameplate.	A	0.1 to 1 times I_n ¹
Fn	Analog output scaling	—	Do not use
Pt	Selection of Volts/Hz control mode (motor control profile)	—	0: V/Hz profile constant torque 1: V/Hz profile variable torque 2: Automatic voltage boost 3: Flux vector control 4: Energy saving 6: Permanent magnet synchronous motor
UL	Base frequency (nominal motor frequency)	Hz	25 to 200.0
ULV	Voltage at base frequency (nominal motor voltage)	V	50 to 330 (230 V drive controllers) 50 to 660 (460 V drive controllers)

¹ I_n is the nominal drive current shown on the drive controller nameplate.

Setting the Acceleration/Deceleration Ramp Times

AUI Acceleration/deceleration ramp adaptation.
Automatically adjusts the acceleration/deceleration ramp times to match the inertia of the load.

ACC Programs the time it takes for the drive controller output frequency to go from 0 Hz to the maximum frequency (parameter **FH**).

DEC Programs the time it takes for drive controller output frequency to go from maximum frequency (parameter **FH**), to 0 Hz.

Refer to specific wiring schematics and parameter settings in the appropriate Appendix section located at the back of this manual for application options and settings.


Table 7: Setting Ramp Time Parameters

Parameter	Name	Range
AUI	Automatic Acceleration/Deceleration Ramp Adaptation	0: Disabled 1: Automatic 2: Automatic acceleration only (Do not use)
ACC	Acceleration Time 1	0.0 to 3200 s
DEC	Deceleration Time 1	0.0 to 3200 s

Acceleration/Deceleration Ramp Adaptation

- **AUI** = 0: Function is disabled.
- **AUI** = 1: Automatically adjusts the acceleration and deceleration ramp times from 1/8–8 times the value set in the **ACC** or **DEC** parameters, depending on the current rating of the drive controller.
- **AUI** = 2: Do not use.


Figure 9: Automatic Ramp Adaptation



Manually Setting Acceleration/Deceleration Ramp Times

During startup, confirm parameters **ACC** and **DEC** match the parameters in the appropriate Appendix section located at the back of this manual for specific HVAC application.

Figure 10: Manually Setting the Acceleration/Deceleration Ramp Times



Setting the Macro Function

Sets the drive controller to one of four macro configurations. The macro configuration selection automatically determines the settings of the following parameters: **CNOd**, **FNOd**, **F110-F113**, and **F201**.

NOTE: The current setting of this parameter is shown on the left side of the display. The number 0 is always displayed on the right. For example, **1 0** indicates that the freewheel stop setting is enabled.

Setting the Mode of Operation

WARNING

UNINTENDED EQUIPMENT OPERATION

- Modifying or changing parameters whose function is not described in this manual will affect drive controller operation. Some register changes will take effect as soon as they are entered.
- Do not modify or change parameters whose function is not described in this instruction bulletin.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

In Remote mode, start and stop commands and the frequency are determined by the settings of *CnOd* (Command mode) and *FnOd* (Frequency Setting mode).

When Local mode is selected with the  key, start/stop commands and frequency settings can only be made from the display terminal. The Local LED illuminates while Local mode is selected. See page 11 for Local/Remote key operation and Local LED.

When service is complete, return the VFD to the remote mode.

Table 8: Parameter *Ru4*

Parameter	Name	Range
<i>Ru4</i>	Macro Function	0: Disabled 1: Freewheel stop 2: 3-wire operation 3: + - speed from logic input(s) 4: 4–20 mA current input operation

Command Mode Selection

Specifies which command source has priority in issuing Start and stop commands.

NOTE: You must stop the drive controller before changing the setting of *CnOd*.

- *CnOd* = 0: Start and stop commands via the logic inputs on the control terminal board.
- *CnOd* = 1: The and keys on the display terminal start and stop the drive controller.
- *CnOd* = 2: The serial link sends start and stop commands to the drive controller.

Some functions, when assigned to an input terminal, are commanded by the input terminal even if *CnOd* is set to 1 (display terminal).

Priority commands via a serial link can take precedence over the setting of *CnOd*.

Table 9: Parameter *CnOd*

Parameter	Name	Range
<i>CnOd</i>	Command Mode Selection	0: Terminal board 1: Display terminal 2: Serial communication

Frequency Mode Selection

FnOd Specifies which input device has priority in issuing a speed reference command.

NOTE: You must stop the drive controller before changing the setting of *FnOd* Preset speed operation is allowed with all settings of *FnOd*

- *FnOd* = 1: Speed Reference command via analog input terminal VIA (0-10 Vdc or 4-20 mAdc).
- *FnOd* = 2: Speed Reference command via analog input terminal VIB (0-10 Vdc) - not used with Daikin controls.
- *FnOd* = 3: Speed reference via the and arrow keys on the display terminal or the optional remote keypad.
- *dOnF* = 4: Speed reference via serial communication link - not used with Daikin controls.
- *FnOd* = 5: Speed reference from +/- speed from logic input(s)

Table 10: Parameter *FnOd*

Parameter	Name	Range
<i>FnOd</i>	Frequency Mode Selection	1: VIA 2: VIB (not used with Daikin controls) 3: Display terminal 4: Serial communication (not used with Daikin controls) 5: +/- speed from logic input(s)

Default Setting

WARNING

UNINTENDED EQUIPMENT OPERATION

- Drive controller default parameter settings will be substituted for the present settings when value 3 (standard default settings) of the tYP parameter is selected.
- Drive controller default parameter settings may not be compatible with the application.
- Contact Daikin product support before initiating standard default settings.

Failure to follow these instructions can result in death, serious injury, or equipment damage

tYP This parameter provides a variety of functions to reset, restore and save parameter settings.

NOTE: You must stop the drive controller before changing the setting of tYP

The following parameters are not affected by settings 1, 2, and 3: F_n , F_{n5L} , F_{109} , F_{470} - F_{473} , and F_{880} .

The setting display of this parameter contains two numbers. The left-most number displays the last operation performed. The right-most number indicates the pending operation and should be adjusted for the action desired.

Table 11: Parameter tYP

Parameter	Name	Range
tYP	Default Setting	0:
		1: 50 Hz default
		2: 60 Hz default
		3: Standard default settings (Initialization)
		4: Clear the fault record
		5: Clear the cumulative operation time
		6: Initialize the type information
		7: Save the user-defined parameters (do not use)
		*8: Recalls your Daikin defined parameters
		9: Clear the cumulative fan operation time

* You may replace Daikin parameters if this is used.

Forward/Reverse Run Selection

F_r Programs the direction of motor rotation when starting the drive from the keypad display.

Table 12: Parameter F_r

Parameter	Name	Range
F_r	Forward/Reverse Run Selection	0: Forward run
		1: Reverse run (do not use)
		2: Forward run with forward/reverse switching (do not use)
		3: Reverse run with forward/reverse switching (do not use)

NOTE: For more information, contact your Daikin Representative.

Maximum Frequency

WARNING

UNINTENDED EQUIPMENT OPERATION

- Do not use above 60Hz.

Failure to follow this instruction can result in death, serious injury, or equipment damage.


F_H Programs the maximum output frequency of the drive controller. This value is used as the maximum frequency reference for the acceleration and deceleration ramps.

Table 13: Parameter F_H

Parameter	Name	Range
F_H	Maximum Frequency	30–200 (Hz)

NOTE: You must stop the drive controller before changing the setting of F_H .

Figure 11: Maximum Frequency



NOTE: F_H can not be adjusted during operation, UL value can not exceed F_H value.


High Speed and Low Speed

$\dot{U}L$ Programs the high speed. $L\dot{L}$ Programs the low speed.

Table 14: Parameters $\dot{U}L$ and $L\dot{L}$

Parameter	Name	Range
$\dot{U}L$	High Speed	0.5 – FH (Hz)
$L\dot{L}$	Low Speed	0.0 – $\dot{U}L$ (Hz)

Figure 12: High Speed and Low Speed




Nominal Motor Frequency and Voltage Settings

$\dot{U}L$, $\dot{U}L\dot{U}$ Use these parameters to set the nominal motor frequency ($\dot{U}L$) and voltage settings ($\dot{U}L\dot{U}$) to the motor nameplate values.

Table 15: Parameters $\dot{U}L$ and $\dot{U}L\dot{U}$

Parameter	Name	Range
$\dot{U}L$	Nominal Motor Frequency	25.0 – 200.0 Hz
$\dot{U}L\dot{U}$	Voltage Setting	50.0 – 330 V: 200 V Class 50.0 – 660 V: 400 V Class

Figure 13: Nominal Motor Frequency and Voltage Settings



V/Hz Control Mode Selection

$P\dot{L}$ Use this parameter to set the V/Hz control mode.

Table 16: Parameter $P\dot{L}$

Parameter	Name	Range
$P\dot{L}$	V/Hz Control Mode Selection	0: V/Hz constant (do not use) 1: Variable torque 2: Automatic voltage boost control 3: Vector control (do not use) 4: Energy saving (do not use) 5: No assignment (do not use) 6: PM motor control (do not use)

Voltage Boost (Energy Recovery Application Only)

$\dot{U}b$ Use this parameter to increase the voltage boost rate. This function is useful for applications where the torque is not adequate at low speeds.


V/Hz Control Mode ($P\dot{L}$) must be set to 0 (V/Hz constant) or 1 (variable torque) to use this function.

The optimum setting for Voltage Boost depends on the drive controller capacity. Increasing Voltage Boost too much can cause the drive controller to fault on an overcurrent at start up.

Table 17: Parameter $\dot{U}b$

Parameter	Name	Range
$\dot{U}b$	Voltage Boost	0.0 – 30.0%

Figure 14: Voltage Boost



Electronic Motor Overload Protection

CAUTION

MOTOR OVERHEATING

This drive controller does not provide direct thermal protection for the motor. Use of a thermal sensor in the motor may be required for protection at all speeds and load conditions. Consult the motor manufacturer for thermal capability of the motor when operated over the desired speed range.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

$\epsilon H r$ Motor rated current value (FLA), $OL n$ Electronic motor overload characteristics, and $F632$ Electronic motor overload memory

These parameters must be set to match the rating and characteristics of the motor (refer to the motor nameplate, full load amps).

Table 18: Electronic Thermal Protection Parameter Settings

Parameter	Name	Adjustment Range																														
$\epsilon H r$	Motor Electronic Thermal Protection	0.1–1.0 In. ¹ Set to the rated current indicated on the motor nameplate.																														
$OL n$	Electronic Thermal Protection Characteristic	<table border="1"> <thead> <tr> <th>Setting Value</th> <th></th> <th>Overload Protection</th> <th>Overload Stall</th> </tr> </thead> <tbody> <tr> <td>0</td> <td rowspan="3">Self Cooled Motor</td> <td>Enabled</td> <td>Disabled</td> </tr> <tr> <td>1</td> <td>Enabled</td> <td>Enabled</td> </tr> <tr> <td>2</td> <td>Disabled</td> <td>Disabled</td> </tr> <tr> <td>3</td> <td rowspan="5">Forced Cooled Motor</td> <td>Disabled</td> <td>Enabled</td> </tr> <tr> <td>4 (do not use)</td> <td>Enabled</td> <td>Disabled</td> </tr> <tr> <td>5 (do not use)</td> <td>Enabled</td> <td>Enabled</td> </tr> <tr> <td>6 (do not use)</td> <td>Disabled</td> <td>Disabled</td> </tr> <tr> <td>7 (do not use)</td> <td>Disabled</td> <td>Enabled</td> </tr> </tbody> </table>	Setting Value		Overload Protection	Overload Stall	0	Self Cooled Motor	Enabled	Disabled	1	Enabled	Enabled	2	Disabled	Disabled	3	Forced Cooled Motor	Disabled	Enabled	4 (do not use)	Enabled	Disabled	5 (do not use)	Enabled	Enabled	6 (do not use)	Disabled	Disabled	7 (do not use)	Disabled	Enabled
		Setting Value		Overload Protection	Overload Stall																											
		0	Self Cooled Motor	Enabled	Disabled																											
		1		Enabled	Enabled																											
		2		Disabled	Disabled																											
		3	Forced Cooled Motor	Disabled	Enabled																											
		4 (do not use)		Enabled	Disabled																											
		5 (do not use)		Enabled	Enabled																											
6 (do not use)	Disabled	Disabled																														
7 (do not use)	Disabled	Enabled																														
$F632$	Electronic Motor Thermal State Memory	0: Disabled 1: Enabled																														

¹ "In." corresponds to the drive rated current indicated on the drive controller nameplate.

Setting $\epsilon H r$, and $OL n$

Use electronic thermal protection characteristics ($OL n$) to enable or disable the motor overload fault function ($OL 2$) and the overload stall function.

While the drive controller overload fault ($OL 1$, see page 25) is always enabled, motor overload fault ($OL 2$) can be selected using parameter $OL n$.

Overload stall is used with variable torque loads such as fans, pumps, and blowers, in which the load current decreases as the operating speed decreases. When the drive controller detects an overload, overload stall automatically lowers the output frequency before the motor overload fault, $OL 2$, is activated. This function maintains the motor at frequencies that allow the load current to remain balanced so that the drive controller can continue operation without tripping.


NOTE: Do not use overload stall with constant torque loads such as conveyor belts in which load current is fixed with no relation to speed.

Self Cooled Motors

To set electronic thermal protection characteristics, $OL n$, for a self-cooled motor, refer to Table 18.

If the capacity of the motor is smaller than the capacity of the drive controller, or the rated current of the motor is smaller than the rated current of the drive controller, set the electronic thermal protection level, $\epsilon H r$, to the motor's nominal rated current value.

Figure 15: Motor Electronic Thermal Protection – Self-Cooled Motor



Motor Electric Thermal Protection Retention, *F632*

The setting of this parameter determines whether electric thermal calculation values are retained when power is removed. Enabling the parameter (*F632* = 1) causes the electric thermal calculation values to be retained when power is removed.

NOTE: For installations to meet Article 430 of the National Electric Code, parameter *F632* must be set to 1.

Input Signal Selection

⚠ DANGER

UNINTENDED EQUIPMENT OPERATION

- The accidental grounding of logic inputs configured for Sink Logic can result in unintended activation of drive controller functions.
- Protect the signal conductors against damage that could result in unintentional conductor grounding.
- Follow NFPA 79 and EN 60204 guidelines for proper control circuit grounding practices.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

F109 VIA terminal function selection

This parameter allows you to select an analog or digital input for the VIA terminal.

When using the VIA terminal as a digital input terminal, set the VIA slide switch to the V position. For switch location see [Figure 2](#).

Table 19: Parameter *F109*

Parameter	Name	Range
<i>F109</i>	Analog/Digital Input Function Selection (VIA Terminal)	0: Analog input 1: Do not use (sinking input assignment) 2: Digital (sourcing) input

Terminal Function Selection

Modifying Input Terminal Functions

The functions selected with parameters *F110* are always active.

Table 20: Parameters *F110*, *F111*, *F112*, *F113*, and *F118*

Terminal Symbol	Parameter	Name	Range
—	<i>F110</i>	Always-Active Function (the control input function assigned to this parameter will always be active)	0–71 (refer to appropriate Appendix for specific parameter settings)
F	<i>F111</i>	Logic Input	
R	<i>F112</i>	Logic Input	
RES	<i>F113</i>	Logic Input	
VIA	<i>F118</i>	Input Terminal	


Modifying Output Terminal Functions

F130 Output terminal selection 1A (RY-RC)

Table 21: Assigning One Function to an Output Terminal

Terminal Symbol	Parameter	Name	Range
RY-RC	<i>F130</i>	Output Terminal Selection 1A	0–255 (refer to appropriate Appendix for specific parameter settings)

Figure 16: Application Example



Jump Frequency (Jumping Resonant Frequencies)

$F 2 7 0$ Jump Frequency 1, $F 2 7 1$ Jumping Width 1

$F 2 7 2$ Jump Frequency 2, $F 2 7 3$ Jumping Width 2

$F 2 7 4$ Jump Frequency 3, $F 2 7 5$ Jumping Width 3

Resonance due to the natural frequency of the mechanical system can be avoided by jumping the resonant frequency during operation.

Table 22: Jump Frequency Parameter Setting


Parameter	Name	Range
$F 2 7 0$	Jump Frequency 1	0.0 – $F H$ (Hz)
$F 2 7 1$	Jump Width 1	0.0 – 30.0 (Hz)
$F 2 7 2$	Jump Frequency 2	0.0 – $F H$ (Hz)
$F 2 7 3$	Jump Width 2	0.0 – 30.0 (Hz)
$F 2 7 4$	Jump Frequency 3	0.0 – $F H$ (Hz)
$F 2 7 5$	Jump Width 3	0.0 – 30.0 (Hz)

NOTE:

The jump frequency plus jump width may not overlap another jump frequency plus jump width.

During acceleration or deceleration, the jumping function is disabled for the operation frequency.

Figure 17: Jump Frequency Timing Diagram



Switching Frequency

$F 3 0 0$ Switching Frequency, $F 3 1 2$ Random Mode

The $F 3 0 0$ parameter allows the audible noise from the motor to be changed by altering the switching frequency.

In addition, the $F 3 0 0$ parameter reduces the electromagnetic noise generated by the drive controller. Decrease the switching frequency to reduce electromagnetic noise.

The $3 1 2$ parameter (random mode) reduces motor electromagnetic and acoustic noise by changing the pattern of the switching frequency.

NOTE: Although the electromagnetic noise level is reduced when decreasing switching frequency, the acoustic noise of the motor is increased.

Table 23: Parameters $F 3 0 0$, $F 3 1 2$

Parameter	Name	Range
$F 3 0 0$	Switching Frequency	6.0 – 16.0 (kHz)
$F 3 1 2$	Random Mode	0: Disabled 1: Enabled

Auto Restart

⚠ DANGER

AUTOMATIC RESTART ENABLED

- This drive controller can restart under fault conditions.
- Equipment must be shut down, locked out and tagged out to perform servicing or maintenance.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

⚠ CAUTION

MOTOR OVERHEATING

- Repeated reset of the thermal overload can result in thermal stress to the motor.
- When faults occur, promptly inspect the motor and driven equipment for problems such as locked shaft and mechanical overload before restarting. Also check the power supplied to the motor for abnormal conditions such as phase loss and phase imbalance.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

F 303 Select the number of restarts.

This parameter resets the drive controller automatically if it is in an alarm state.

Table 24: Parameter F 303

Parameter	Name	Range
F 303	Number of Restarts	0: Disabled 1–10: 1 to 10 restarts

Table 25: Causes of Tripping and Corresponding Restart Processes

Cause of Tripping	Restart Process	Canceling Conditions
Momentary power failure	Up to 10 restarts in succession 1st restart: 1 second after tripping	Auto restart is possible only after the following faults: momentary power failure, overcurrent, overvoltage, or overload. The restart function will be canceled if restarting is not successful within the specified number of times.
Overcurrent	2nd restart: 2 seconds after tripping	
Overvoltage	3rd restart: 3 seconds after tripping	
Overload	10th restart: About 10 seconds after tripping	
Overheating		

Restart is disabled when the faults or errors listed in [Table 26](#) occur.

Table 26: Faults Which Cannot Be Automatically Reset

OCR	Motor overcurrent at start up
OCL	Overcurrent on load side at start up
EPHO	Output phase loss
OH2	External thermal fault
Ot	Overtorque fault
E	External fault stop
UC	Low-current operation fault
UP 1	Undervoltage fault (main circuit)
EF2	Ground fault
EPH 1	Input phase loss
EtYP	Drive controller error
Err2	Main unit RAM fault
Err3	Main unit ROM fault
Err4	CPU fault
Err5	Remote control error
Err7	Current detector fault
Err8	Control circuit board format error
EEP 1	EEPROM fault 1
EEP 2	EEPROM fault 2
EEP 3	EEPROM fault 3
Et n 1	Auto-tuning error
E - 18	VIA input detection error
E - 19	Main unit CPU communication error
E - 20	Excessive voltage boost
E - 21	CPU fault 2

When using Auto Restart, observe the following:

- By default, protective operation detection relay signals (FLA-FLB-FLC terminal signals) are not sent during an auto restart process. To allow a signal to be sent to the protective operation detection relay (FLA-FLB-FLC terminals) during an auto restart process, assign value 36 or 37 to parameter **F 132**
- A calculated cooling time is provided for overload tripping (**OL 1, OL 2, OL r**). In this case, the auto restart function operates after the calculated cooling time and the restart time
- In the event of an overvoltage fault (**OP 1 – OP 3**), the auto restart function is not activated until the voltage in the DC section comes down to a normal level
- In the event of an overheating fault (**OH**), the auto restart function is not activated until the drive controller temperature is low enough to restart operation
- When **F 50 1** is set to 1 (fault retained), the restart function is not performed, regardless of the setting of **F 303**
- During an auto restart process, the display alternates between “r t Y” and the setting specified by display mode selection parameter **F 7 10**
- The number of auto restarts is cleared if the drive controller does not fault for the specified period of time after a successful restart. A successful restart means that the drive controller output frequency reaches the command frequency without causing the drive controller to fault again

Drive Controller Fault Retention

F606 Drive controller fault retention

This parameter can be set to retain fault information for display after power has been cycled.

The causes of up to four trips can be displayed in status monitor mode.

Table 27: Parameter F606

Parameter	Name	Range
F606	Drive Controller Fault Retention Selection	0: Clear the fault information when power is removed 1: Retain the fault information when the power is removed

Output Phase Loss Detection

F605 Output phase loss detection mode

The setting of this parameter determines how the drive controller responds after detecting an output phase loss. If the phase loss status persists for one second or more, the drive controller will fault, the FL relay will be activated, and fault code **EPH0** will be displayed.

Table 28: Parameter F605

Parameter	Name	Range
F605	Output Phase Loss Detection (one second or greater)	0: Disabled 1: At start-up (only one time after power is turned ON) 2: At start-up (each time) 3: During operation 4: At start-up and during operation 5: Detection of cutoff on output side

If the drive controller detects an all-phase loss (i.e. contactor opening), it will restart on completion of recondition. The drive controller does not check for output phase loss when restarting after a momentary power loss.

Input Phase Loss Detection

F608 Input phase loss detection mode selection

Setting this parameter to 1 (default) enables Input Phase Loss Detection. During a complete input phase loss event the drive controller will fault (code **EPH1**) and the **FL** relay will be activated.

Input phase loss nuisance tripping on low source impedance power systems may indicate the need to install an AC input line reactor.

Setting **F608** to 0 (input phase loss detection disabled) may result in damage to the drive controller if operation is continued under a heavy load during an input phase loss.

NOTE: The drive controller may not fault on all input phase imbalance conditions.

Table 29: Parameter F608

Parameter	Name	Range
F608	Input Phase Loss Detection	0: Disabled 1: Enabled

Avoiding Overvoltage Tripping

CAUTION

MOTOR OVERHEATING

- Repetitive braking can cause motor overheating and damage if the Quick Deceleration or Dynamic Quick Deceleration features are active.
- Use of a thermal sensor in the motor is recommended to protect the motor during repetitive braking.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

F 305 Overvoltage limit operation, **F 626** Overvoltage stall protection level


Use these parameters to keep the output frequency constant, or to increase it to prevent overvoltage tripping should the voltage in the DC section rise during deceleration or varying speed operation. The deceleration time during overvoltage limit operation may increase above the designated time. Overvoltage stall protection level sets the percentage of the nominal DC bus level where the drive will modify the output frequency to prevent an Overvoltage fault.

Table 30: Parameters F 305, F 626

Parameter	Name	Range
F 305	Overvoltage Limit Operation	0: Enabled 1: Disabled 2: Enabled (quick deceleration - do not use) 3: Enabled (dynamic quick deceleration - do not use)
F 626	Overvoltage Stall Protection Level	100 – 150%*

* Daikin setting = 140%. If power transients are more common than normal, increase toward 150%.

Figure 18: Overvoltage Limit Operation Level



If **F 305** is set to 2 (quick deceleration), the drive controller will increase the voltage to the motor (over-excitation control) to increase the amount of energy consumed by the motor when the voltage reaches the overvoltage protection level. The motor can therefore be decelerated more quickly than with normal deceleration.

If **F 305** is set to 3 (dynamic quick deceleration), the drive controller will increase the voltage to the motor (over-excitation control) to increase the amount of energy consumed by the motor as soon as the motor begins to slow down. The motor can therefore be decelerated even more quickly than with quick deceleration.

Undervoltage Fault

F 627 Undervoltage fault/alarm selection.

The setting of this parameter determines how the drive controller responds when it detects an undervoltage. The fault code displayed is **UP 1**.

Table 31: Parameter F 627

Parameter	Name	Range
F 627	Undervoltage Fault/Alarm Selection	0: Alarm only (input voltage level below 60%) The drive controller stops but does not fault (the FL relay is not activated). 1: Fault (detection level below 60%) The drive controller stops and faults when the input voltage is less than 60% of it's rating. 2: Alarm only (input voltage level below 50%, input reactor needed) The drive controller stops but does not fault when the input voltage is less than 50% of it's rating. A line reactor must be used with this setting.

Changing the Display Parameter

F 710 Display selection

When power is applied to the drive controller, it is in display mode. The display terminal shows operation frequency as the default setting.

Table 32: Parameter F 710

Parameter	Name	Range
F 710	Display Selection	0: Operation frequency (Hz/free unit/step) 1: Frequency command (Hz/free unit/step) 2: Output current (%/A) 3: Drive controller rated current (A) 4: Drive controller load factor (%) 5: Output power 6: Frequency command after PID control (Hz/free unit/step) 7: Optional item specified from an external control unit 8: Output speed of fan motor 9: Communication counter 10: Normal state communication counter

When an alarm or fault occurs, use [Table 33](#) and [Table 34](#) to diagnose and resolve the problem.

If the problem cannot be resolved by any of the actions described in the tables, refer to the programming guide or contact your Daikin Representative.

Drive Controller Fault Conditions

Table 33: Fault Codes

Error Code	Failure Code	Problem Possible Causes	Remedies
<i>OC1, OC1P</i>	0001 0025	Overcurrent during acceleration Transistor overcurrent	<ul style="list-style-type: none"> The acceleration time . . . is too short The V/Hz setting is improper A restart signal is input to the rotating motor after a momentary stop, etc A special motor (e.g. motor with a small impedance) is used Possible ground fault
<i>OC2, OC2P</i>	0002 0026	Overcurrent during deceleration Transistor overcurrent	<ul style="list-style-type: none"> The deceleration time <i>dEC</i> is too short Possible ground fault
<i>OC3, OC3P</i>	0003 0027	Overcurrent during constant speed operation Transistor overcurrent	<ul style="list-style-type: none"> The load fluctuates abruptly Mechanical blockage
<i>OC1P, OC2P, OC3P</i>	0025 0026 0027	Ground fault Motor overcurrent at start-up (for 15 and 20 hp models only)	<ul style="list-style-type: none"> A current leaked from an output cable or the motor to ground A main circuit elements is defective
<i>OCL</i>	0004	Overcurrent (an overcurrent on the load side at start-up)	<ul style="list-style-type: none"> The insulation of the output main circuit or motor is defective Motor impedance is too low Current is leaked from an output cable or the motor to ground
<i>OCR</i>	0005	Motor overcurrent at start-up	<ul style="list-style-type: none"> A main circuit elements is defective Possible ground fault
<i>EPH1*</i>	0008	Input phase loss	<ul style="list-style-type: none"> Input phase loss, blown fuse Three-phase drive controller used on a single phase line supply Input phase imbalance Transient phase fault

* You can select a trip ON/OFF by parameters.

Error Code	Failure Code	Problem Possible Causes	Remedies
<i>EPH2*</i>	0009	Output phase loss	<ul style="list-style-type: none"> • Loss of phase at drive controller output • Downstream contactor open • Motor not connected • Instability in the motor current • Drive controller oversized for motor <ul style="list-style-type: none"> • Check the main circuit output line, motor, etc. for phase loss • Enable <i>F505</i> (output phase loss detection)
<i>OP1</i>	000A	Overvoltage during acceleration	<ul style="list-style-type: none"> • Line voltage too high • Line supply transients • A restart signal is input to the rotating motor after a momentary stop, etc. • There is possibility of output phase loss <ul style="list-style-type: none"> • Check the line voltage • Compare with the drive controller nameplate rating • Reset the drive controller • Install a line reactor • Use <i>F301</i> (auto-restart) and <i>F302</i> (ride-through control) • Check the main circuit output line, motor, etc. for phase loss
<i>OP2</i>	000B	Overvoltage during deceleration	<ul style="list-style-type: none"> • The deceleration time <i>dEL</i> is too short (regenerative energy is too large) • <i>F305</i> (overvoltage limit operation) is OFF • The input voltage fluctuates abnormally: <ul style="list-style-type: none"> – Overhauling load – There is possibility of output phase loss <ul style="list-style-type: none"> • Increase the deceleration time <i>dEL</i> • Enable <i>F305</i> (overvoltage limit operation) • Check the main circuit output line, motor, etc. for phase loss
<i>OP3</i>	000C	Overvoltage during constantspeed operation	<ul style="list-style-type: none"> • The input voltage fluctuates abnormally • The motor is in a regenerative state because the load causes the motor to run at a frequency higher than the drive controller output frequency • There is possibility of output phase loss <ul style="list-style-type: none"> • Check the main circuit output line, motor, etc. for phase loss.
<i>OL1</i>	000D	Drive controller overload	<ul style="list-style-type: none"> • The acceleration time <i>RLC</i> is too short • The DC braking level is too large • The V/Hz setting is improper • A restart signal is input to the rotating motor after a momentary stop, etc. • The load is too large <ul style="list-style-type: none"> • Increase the acceleration time <i>RLC</i> • Reduce the DC braking amount <i>F251</i> and the DC braking time <i>F252</i> parameter setting • Use <i>F301</i> (auto-restart) and <i>F302</i> (ride-through control) • Use an drive controller with a larger rating
<i>OL2</i>	000E	Motor overload	<ul style="list-style-type: none"> • The V/Hz setting is improper • The motor is locked • Low-speed operation is performed continuously • An excessive load is applied to the motor during operation <ul style="list-style-type: none"> • Check the V/Hz parameter setting • Check the load (operated machine) • Adjust <i>OLn</i> to the overload that the motor can withstand during operation in a low speed range
<i>OE*</i>	0020	Over-torque fault	<ul style="list-style-type: none"> • Over-torque during operation <ul style="list-style-type: none"> • Enable <i>F515</i> (overtorque fault selection) • Check system error
<i>OH</i>	0010	Drive controller over temperature	<ul style="list-style-type: none"> • The cooling fan does not rotate • The ambient temperature is too high • The vent is blocked • A heat generating device is installed close to the drive controller • The thermistor in the unit is broken <ul style="list-style-type: none"> • Restart the operation by resetting the drive controller after it has cooled down • The fan requires replacement if it does not rotate during operation • Ensure sufficient space around the drive controller • Do not place any heat generating device near the drive controller • Contact your Daikin Representative
<i>OH2</i>	002E	External thermal fault	<ul style="list-style-type: none"> • External thermal fault • External PTC probe fault <ul style="list-style-type: none"> • Check the external thermal input • Check the PTC in the motor
<i>E</i>	0011	Emergency stop	<ul style="list-style-type: none"> • During automatic operation or remote operation, a stop command is entered from the operation panel or a remote input device <ul style="list-style-type: none"> • Reset the drive controller
<i>EEP1</i>	0012	EEPROM fault 1	<ul style="list-style-type: none"> • Data writing error <ul style="list-style-type: none"> • Turn OFF the drive controller, then turn it again. If it does not recover from the error, contact your Daikin Representative

* You can select a trip ON/OFF by parameters.

Error Code	Failure Code	Problem Possible Causes	Remedies	
<i>E E P 2</i>	0013	EEPROM fault 2	<ul style="list-style-type: none"> Power supply is cut OFF during <i>E Y P</i> operation and data writing is aborted 	<ul style="list-style-type: none"> Turn the power OFF temporarily and turn it back on, and then try <i>E P Y</i> operation again
<i>E E P 3</i>	0014	EEPROM fault 3	<ul style="list-style-type: none"> A data reading error occurred 	<ul style="list-style-type: none"> Turn OFF the drive controller, then turn it again. If it does not recover from the error, contact your Daikin Representative
<i>E r r 2</i>	0015	Main unit RAM fault	<ul style="list-style-type: none"> The control RAM is defective 	<ul style="list-style-type: none"> Contact your Daikin Representative
<i>E r r 3</i>	0016	Main unit ROM fault	<ul style="list-style-type: none"> The control ROM is defective 	<ul style="list-style-type: none"> Contact your Daikin Representative
<i>E r r 4</i>	0017	CPU fault 1	<ul style="list-style-type: none"> The control CPU is defective 	<ul style="list-style-type: none"> Contact your Daikin Representative
<i>E r r 5*</i>	0018	Communication error	<ul style="list-style-type: none"> An error arises during serial communication 	<ul style="list-style-type: none"> Check the remote control device, cables, etc.
<i>E r r 7</i>	001A	Current detector fault	<ul style="list-style-type: none"> The current detector is defective 	<ul style="list-style-type: none"> Contact your Daikin Representative
<i>E r r 8</i>	001B	Network error	<ul style="list-style-type: none"> The error has occurred during Network communication 	<ul style="list-style-type: none"> Check the Network device and wiring
<i>U C*</i>	001D	Low-current operation fault	<ul style="list-style-type: none"> The output current decreased to a low current detection level during operation 	<ul style="list-style-type: none"> Enable <i>F 5 1 0</i> (low-current detection) Check the suitable detection level for the system (<i>F 5 1 1</i>, <i>F 5 1 2</i>)
<i>U P 1*</i>	001E	Undervoltage fault (main circuit)	<ul style="list-style-type: none"> The input voltage (in the main circuit) is too low 	<ul style="list-style-type: none"> Check the input voltage Enable <i>F 5 2 7</i> (undervoltage fault selection) To cope with a momentary stop due to undervoltage, enable <i>F 3 0 2</i> (ride-through control) and <i>F 3 0 1</i> (autorestart)
<i>E F 2</i>	0022	Ground fault	<ul style="list-style-type: none"> A ground fault occurs in the output cable or the motor 	<ul style="list-style-type: none"> Check the cable and the motor for ground faults
<i>E t n*</i>	0054	Auto-tuning error	<ul style="list-style-type: none"> Check the motor parameter <i>F 4 0 1</i> to <i>F 4 9 4</i> The motor with the capacity of 2 classes or less than the drive controller is used The output cable is improperly sized The motor is rotating The drive controller is used for loads other than those of three-phase induction motors 	
<i>E t Y P</i>	0029	Drive controller type error	<ul style="list-style-type: none"> Circuit board is changed (or main circuit/ drive circuit board) 	<ul style="list-style-type: none"> Contact your Daikin Representative
<i>E - 1 7</i>	HMI error		<ul style="list-style-type: none"> A graphic display option key has been held down for more than 20 seconds. A graphic display option key may not be operating properly. 	<ul style="list-style-type: none"> Release the graphic display option key. If this does not clear the error, replace the drive.
<i>E - 1 8*</i>	0032	Break in analog signal cable	<ul style="list-style-type: none"> The signal input via VIA is below the analog signal detection level set with <i>F 5 3 3</i> 	<ul style="list-style-type: none"> Check the cables for breaks. And check the setting of input signal or setting value of <i>F 5 3 3</i>
<i>E - 1 9</i>	0033	CPU communication error	<ul style="list-style-type: none"> A communications error occurs between control CPUs 	<ul style="list-style-type: none"> Contact your Daikin Representative
<i>E - 2 0</i>	0034	Excessive voltage boost	<ul style="list-style-type: none"> The voltage boost parameter <i>F 4 0 2</i> is set too high Impedance of the motor is too low 	<ul style="list-style-type: none"> Decrease the setting of the voltage boost parameter <i>F 4 0 2</i>
<i>E - 2 1</i>	0035	CPU fault 2	<ul style="list-style-type: none"> The control CPU is defective 	<ul style="list-style-type: none"> Contact your Daikin Representative
<i>S O U L E</i>	002F	Step-out (for PM motor only)	<ul style="list-style-type: none"> The motor shaft is locked One output phase is open An impact load is applied 	<ul style="list-style-type: none"> Unlock the motor shaft Check the interconnect cables between the drive controller and the motor

* You can select a trip ON/OFF by parameters.

Drive Controller Alarm Conditions

Alarms do not cause the drive controller to fault.

Table 34: Alarm Codes

Error Code	Problem	Possible Causes	Remedies
<i>OFF</i>	ST terminal OFF	<ul style="list-style-type: none"> The ST-CC circuit is opened 	<ul style="list-style-type: none"> Close the ST-CC circuit
<i>nOFF</i>	Undervoltage in main circuit	<ul style="list-style-type: none"> The supply voltage between R, S and T is under voltage 	<ul style="list-style-type: none"> Measure the main circuit supply voltage. If the voltage is at a normal level, the drive controller requires repairing
<i>rt r y</i>	Restart in process	<ul style="list-style-type: none"> The drive controller is in the process of restart A momentary stop occurred 	<ul style="list-style-type: none"> The drive controller is operating normally if it restarts after several tens of seconds
<i>Err 1</i>	Frequency point setting error alarm	<ul style="list-style-type: none"> The frequency setting signals at points 1 and 2 are set too close to each other 	<ul style="list-style-type: none"> Set the frequency setting signals at points 1 and 2 apart from each other
<i>CLR</i>	Clear command acceptable	<ul style="list-style-type: none"> This message is displayed when pressing the STOP key while an error code is displayed 	<ul style="list-style-type: none"> Press the STOP key again to clear the fault
<i>EOFF</i>	Emergency stop command acceptable	<ul style="list-style-type: none"> The operation panel is used to stop the operation in automatic control or remote control mode 	<ul style="list-style-type: none"> Press the STOP key for an emergency stop. To cancel the emergency stop, press any other key.
<i>H I L D</i>	Setting error alarm/an error code and data are displayed alternately twice each	<ul style="list-style-type: none"> An error is found in a setting when data is reading or writing 	<ul style="list-style-type: none"> Check whether the setting is made correctly
<i>HEA d/E n d</i>	Display of first/last data items	<ul style="list-style-type: none"> The first and last data item in the data group is displayed 	<ul style="list-style-type: none"> Press MODE key to exit the data group
<i>db</i>	DC braking	<ul style="list-style-type: none"> DC braking in process 	<ul style="list-style-type: none"> The message goes off in several tens of seconds if no problem occurs
<i>E 1</i>	Flowing out of excess number of digits	<ul style="list-style-type: none"> The number of digits such as frequencies is more than 4 (The upper digits have a priority) 	<ul style="list-style-type: none"> Lower the frequency free unit magnification <i>F 7 0 2</i>
<i>StOP</i>	Momentary power failure slowdown stop prohibition function activated	<ul style="list-style-type: none"> The slowdown stop prohibition function set with <i>F 3 0 2</i> (momentary power failure ridethrough operation) is activated 	<ul style="list-style-type: none"> To restart operation, reset the drive controller or input an operation signal again
<i>L StP</i>	Auto-stop because of continuous operation at the lowerlimit frequency	<ul style="list-style-type: none"> The automatic stop function selected with <i>F 2 5 5</i> was activated 	<ul style="list-style-type: none"> To deactivate the automatic stop function, increase the frequency command above the lower-limit frequency (<i>L L</i>) + 0.2 Hz or turn OFF the operation command
<i>in it</i>	Parameters in the process of initialization	<ul style="list-style-type: none"> Parameters are being initialized to default values 	<ul style="list-style-type: none"> Normal if the message disappears after a while (several seconds to several tens of seconds)
<i>E - 17</i>	Operation panel key fault	<ul style="list-style-type: none"> The RUN or STOP key is held down for more than 20 seconds The RUN or STOP key is faulty 	<ul style="list-style-type: none"> Check the operation panel
<i>Rt n 1</i>	Auto-tuning	<ul style="list-style-type: none"> Auto-tuning in process 	<ul style="list-style-type: none"> Normal if it the message disappears after a few seconds
<i>h999</i>	Integral input power	<ul style="list-style-type: none"> Integral input power is more than 999.99 kWh 	<ul style="list-style-type: none"> Press and hold down the key for 3 seconds or more when power is OFF or when the input terminal function CKWH is turned ON or displayed.
<i>H999</i>	Integral output power	<ul style="list-style-type: none"> Integral output power is more than 999.99 kWh 	<ul style="list-style-type: none"> Press and hold down the key for 3 seconds or more when power is OFF or when the input terminal function CKWH is turned ON or displayed.

Pre-Alarm Displays

CAUTION

MOTOR OVERHEATING

- Repeated reset of the thermal state after a thermal overload can result in thermal stress to the motor.
- When faults occur, promptly inspect motor and driven equipment for problems (locked shaft, mechanical overload, etc.) before restarting. Also check power supplied to the motor for abnormal conditions (phase loss, phase imbalance, etc.).

Failure to follow this instruction can result in death, serious injury, or equipment damage.

The pre-alarms are displayed, blinking, in the following order from left to right: **C**, **P**, **L**, **H**.

If two or more problems arise simultaneously, one of the following alarms appears and blinks: **CP**, **PL**, **CPH**.

Table 35: Pre-alarm codes

C	Overcurrent alarm	Same as OC (overcurrent)
P	Overvoltage alarm	Same as OP (overvoltage)
L	Overload alarm	Same as OL 1 and OL 2 (overload)
H	Overheating alarm	Same as OH (overheating)

Resetting the Drive Controller after a Fault Condition

Do not reset the drive controller when faulted because of a failure or error before eliminating the cause of the fault. Resetting the tripped drive controller before eliminating the problem causes it to fault again.

The drive controller can be reset after a fault with any of the following operations:

1. Turning OFF the power.
2. Using external signal.
3. Using the Stop key on the display terminal:
 - a. Press the STOP key and make sure that **CLR** is displayed.
 - b. Eliminate the cause of the fault.
 - c. Press the STOP key again to reset the drive controller.
4. Inputting a fault clear signal from a remote communication device.

With the Graphic/Embedded Display Terminals

The **STOP** key can be used to clear a drive detected fault if parameter [Command mode sel] (**Cmd**) is set to 1. To clear a drive detected fault, press the **STOP** key. If it is possible to reset the drive, it will display **CLR**. To clear the detected fault, press the **STOP** key a second time. If the cause of the interruption is still present, the **CLR** display will not appear. Diagnose and clear the detected fault before attempting to reset the drive. The use of the **STOP** key as a clear detected fault can be managed by parameter [HMI reset button] (**F735**).

When any overload function (**OL 1** or **OL 2**) is active, the drive controller cannot be reset by inputting a reset signal from an external device or with the Stop key on the display terminal if the calculated cooling time has not expired. Calculated cooling time:

- **OL 1**: 30 seconds after the fault has occurred
- **OL 2**: 120 seconds after the fault has occurred

The input terminals F, R, and RES can be configured with the settings in [Table 36](#).

Table 36: Input Terminal Functions

Function No.	Code	Function	Action
0	—	No function is assigned	Disabled
1*	ST	Standby terminal	ON: Ready for operation OFF: Coast stop (gate off)
2	F	Forward run command	ON: Forward run OFF: Slowdown stop
3	R	Reverse run command	ON: Reverse run OFF: Slowdown stop
5	AD2	Acceleration/deceleration 2 pattern selection	ON: Acceleration/deceleration 2 OFF: Acceleration/deceleration 1 or 3
6	SS1	Preset-speed command 1	Selection of 7-speed with SS1 to SS3 (3 bits)
7	SS2	Preset-speed command 2	
8	SS3	Preset-speed command 3	
10*	RES	Reset command	ON: Acceptance of reset command ON → OFF: Fault reset
11*	EXT	Fault stop command from external input device	ON: \bar{E} Fault stop
13	DB	DC braking command	ON: DC braking
14	PID	PID control prohibited	ON: PID control prohibited OFF: PID control permitted
15	PWENE	Permission of parameter editing	ON: Parameter editing permitted OFF: Parameter editing prohibited (If $F700 = 1$)
16*	ST+RES	Combination of standby and reset commands	ON: Simultaneous input from ST and RES
20	F+AD2	Combination of forward run and acceleration/deceleration 2	ON: Simultaneous input from F and AD2
21	R+AD2	Combination of reverse run and acceleration/deceleration 2	ON: Simultaneous input from R and AD2
22	F+SS1	Combination of forward run and preset-speed command 1	ON: Simultaneous input from F and SS1
23	R+SS1	Combination of reverse run and preset-speed command 1	ON: Simultaneous input from R and SS1
24	F+SS2	Combination of forward run and preset-speed command 2	ON: Simultaneous input from F and SS2
25	R+SS2	Combination of reverse run and preset-speed command 2	ON: Simultaneous input from R and SS2
26	F+SS3	Combination of forward run and preset-speed command 3	ON: Simultaneous input from F and SS3
27	R+SS3	Combination of reverse run and preset-speed command 3	ON: Simultaneous input from R and SS3
30	F+SS1+AD2	Combination of forward run, preset-speed command 1 and acceleration/deceleration 2	ON: Simultaneous input from F, SS1 and AD2
31	R+SS1+AD2	Combination of reverse run, preset-speed command 1 and acceleration/deceleration 2	ON: Simultaneous input from R, SS1 and AD2
32	F+SS2+AD2	Combination of forward run, preset-speed command 2 and acceleration/deceleration 2	ON: Simultaneous input from F, SS2 and AD2
33	R+SS2+AD2	Combination of reverse run, preset-speed command 2 and acceleration/deceleration 2	ON: Simultaneous input from R, SS2 and AD2
34	F+SS3+AD2	Combination of forward run, preset-speed command 3 and acceleration/deceleration 2	ON: Simultaneous input from F, SS3 and AD2

* When function 1, 10, 11, 16, 38, 41, 42, 43, 44, 45, 46, 47, 51, 52, 53, 54, 55, 62, or 64 is assigned to an input terminal board, the input terminal board is enabled even if the parameter command mode selection $Cn0d$ is set at 1 (panel).

Function No.	Code	Function	Action
35	R+SS3+AD2	Combination of reverse run, preset-speed command 3 and acceleration/deceleration 2	ON: Simultaneous input from R, SS3 and AD2
38*	FCHG	Frequency command forced switching	ON: $F200$ (if $F200 = 0$) OFF: $Fn0d$
39	VF2	No.2 Switching of V/Hz setting	ON: No.2 V/Hz setting ($Pt=0, F170, F171, F172, F173$) (Set value of Pt, UL, ULU, Ub, tHr)
40	MOT2	No.2 motor switching (VF2 + AD2 + OCS2)	ON: No.2 motor ($Pt=0, F170, F171, F172, F173, F185, FF500, FF501, F503$) OFF: No.1 motor (set value of $Pt, UL, ULU, Ub, tHr, RCC, dEC, F502, F501$)
41*	UP	Frequency UP signal input from external contacts	ON: Increase in frequency
42*	DOWN	Frequency DOWN signal input from external contacts	ON: Reduction in frequency
43*	CLR	Frequency UP/DOWN cancellation signal input from external contacts	OFF → ON: Resetting of UP/DOWN frequency by means of external contacts
44*	CLR+RES	Combination of frequency UP/DOWN cancellation and reset by means of external contacts	ON: Simultaneous input from CLR and RES
45*	EXTN	Inversion of fault stop command from external device	OFF: E Fault stop
46*	OH	Thermal fault stop signal input from external device	ON: $OH2$ Fault stop
47*	OHN	Inversion of thermal fault stop command from external device	OFF: $OH2$ Fault stop
48	SC/LC	Forced switching from remote to local control	Enabled when remote control is exercised ON: Local control (setting of $Ln0d, Fn0d$ and $F207$) OFF: Remote control
49	HD	Operation holding (stop of 3-wire operation)	ON: F (forward run)/R: (reverse run) held, 3-wire operation OFF: Slowdown stop
51*	CKWH	Display cancellation of the cumulative power amount (kWh)	ON: Monitor display cancellation of the cumulative power amount (kWh)
52*	FORCE	Forced operation (factory configuration required)	ON: Forced operation mode in which operation is not stopped in the event of the occurrence of a soft fault (preset speed operation frequency 15) To use this function, the inverter needs to be so configured at the factory. OFF: Normal operation
53*	FIRE	Fire-speed control	ON: Fire-speed operation ($F244$) Forced fire speed setting frequency OFF: Normal operation
54*	STN	Freewheel stop (gate off)	ON: Freewheel stop (gate off)
55*	RESN	Inversion of RES	ON: Acceptance of reset command OFF → ON: Fault reset
56	F+ST	Combination of forward run and standby	ON: Simultaneous input from F and ST
57	R+ST	Combination of reverse run and standby	ON: Simultaneous input from R and ST
61	OCS2	Forced switching of stall prevention level 2	ON: Enabled at the value of $F185$ OFF: Enabled at the value of $F501$
62*	HDRY	Holding of RY-RC terminal output	ON: Once turned ON, RY-RC are held ON. OFF: The status of RY-RC changes in real time according to conditions
64*	PRUN	Cancellation (clearing) of operation command from panel	0: Operation command cancelled (cleared) 1: Operation command retained
65	ICLR	PID control integral value clear	ON: PID control integral value always zero OFF: PID control permitted Table 36: Input Terminal Functions (continued)
66	ST+F+SS1	Combination of standby, forward run and preset speed command 1	ON: Simultaneous input from ST, F and SS1
67	ST+R+SS1	Combination of standby, reverse run and preset speed command 1	ON: Simultaneous input from ST, R and SS1
68	ST+F+SS2	Combination of standby, forward run and preset speed command 2	ON: Simultaneous input from ST, F and SS2

* When function 1, 10, 11, 16, 38, 41, 42, 43, 44, 45, 46, 47, 51, 52, 53, 54, 55, 62, or 64 is assigned to an input terminal board, the input terminal board is enabled even if the parameter command mode selection $Ln0d$ is set at 1 (panel).

Function No.	Code	Function	Action
69	ST+R+SS2	Combination of standby, reverse run and preset speed command 2	ON: Simultaneous input from ST, R and SS2
70	ST+F+SS3	Combination of standby, forward run and preset speed command 3	ON: Simultaneous input from ST, F and SS3
71	ST+R+SS3	Combination of standby, reverse run and preset speed command 3	ON: Simultaneous input from ST, R and SS3

* When function 1, 10, 11, 15, 38, 41, 42, 43, 44, 45, 46, 47, 51, 52, 53, 54, 55, 62, or 64 is assigned to an input terminal board, the input terminal board is enabled even if the parameter command mode selection *Cmd* is set at 1 (panel).

The output terminals FLA, FLB, FLC, RY, and RC can be configured with the settings in [Table 37](#).

Table 37: Output Terminal Functions

Function No.	Code Function	Action	
0	LL	Low speed	ON: The output frequency is above the LL set value OFF: The output frequency is equal to or less than the LL set value
1	LLN	Inversion of low speed Inversion of LL setting	
2	UL	High speed	ON: Output frequency is equal to or higher than UL value OFF: Output frequency is lower than UL value
3	ULN	Inversion of high speed	Inversion of UL setting
4	LOW	Low-speed detection signal	ON: Output frequency is equal to or higher than F100 value OFF: Output frequency is lower than F100 value
5	LOWN	Inversion of low-speed detection signal	Inversion of LOW setting
6	RCH	Designated frequency attainment signal (completion of acceleration/deceleration)	ON: The output frequency is equal to or less than the specified frequency ± frequency set with F102 OFF: The output frequency is above the specified frequency ± frequency set with F102
7	RCHN	Inversion of designated frequency attainment signal (inversion of completion of acceleration/deceleration)	Inversion of RCH setting
8	RCHF	Set frequency attainment signal	ON: The output frequency is equal to or less than the frequency set with F101 ± F102 OFF: The output frequency is above the frequency set with F101 ± F102
9	RCHFN	Inversion of set frequency attainment signal	Inversion of RCHF setting
10	FL	Failure signal (fault output)	ON: When inverter is tripped OFF: When inverter is not tripped
11	FLN	Inversion of failure signal (inversion of fault output)	Inversion of FL setting
12	OT	Over-torque detection	ON: Torque current is equal to or larger than set value and longer than F518 set time OFF: The torque current is equal to or less than (F515 set value – F519 set value)
13	OTN	Inversion of over-torque detection	Inversion of OT
14	RUN	Start/Stop	ON: When operation frequency is output or during (db) OFF: Operation stopped
15	RUNN	Inversion of RUN/STOP	Inversion of RUN setting
16	POL	OL pre-alarm	ON: 50% or more of calculated value of overload protection level OFF: Less than 50% of calculated value of overload protection level
17	POLN	Inversion of OL pre-alarm	Inversion of POL setting
20	POT	Over-torque detection pre-alarm	ON: Torque current is equal to or larger than 70% of F515 set value OFF: The torque current is below (F515 set value × 70% – F519 set value)
21	POTN	Inversion of over-torque detection pre-alarm	Inversion of POT setting
22	PAL	Pre-alarm	One of the following is turned on: ON POL, POHR, POT, MOFF, UC, OT, LL, stop, COT, and momentary power failure slowdown stop Or L, P, or H issues an alarm All the following are turned OFF: OFF POL, POHR, POT, MOFF, UC, OT, LL, stop, COT, and momentary power failure slowdown stop Or L, P, or H issues no alarm
23	PALN	Inversion of pre-alarm	Inversion of PAL setting
24	UC	Low-current detection	ON: The output current is equal to or less than F511 (set value) for F512 (set time)
26	UCN	Inversion of low-current detection	Inversion of UC setting

Function No.	Code Function	Action	
27	HFL	Significant failure	ON: <i>OCF, OCL, OLe, E, EEP1, Ekn, EPK0, Err2-5, OH2, UP1, EF2, UC, EkyP, or EPH1</i> OFF: Failure other than the above
27	HFLN	Inversion of significant failure	Inversion of HFL setting
28	LFL	Insignificant failure	ON: <i>(OC1-3, OP1-3, OH, OL1-2, OLr)</i> OFF: Failure other than the above
29	LFLN	Inversion of insignificant failure	Inversion of LFL setting
30	RDY1	Ready for operation (including ST/RUN)	ON: Ready for operation (ST and RUN are also ON) OFF: Others
31	RDY1N	Inversion of ready for operation (including ST/RUN)	Inversion of RDY1 setting
32	RDY2	Ready for operation (excluding ST/RUN)	ON: Ready for operation (ST and RUN are not ON) OFF: Others
33	RDY2N	Inversion of ready for operation (excluding ST/RUN)	Inversion of RDY2
34	FCVIB	Frequency VIB selection	ON: VIB selected as frequency command OFF: Terminal other than VIB selected as frequency command
35	FCVIBN	Inversion of frequency VIB selection	Inversion of FCVIB
36	FLR	Fault signal (put out also at the time of a restart)	ON: When inverter trips or restarts OFF: When inverter does not trip or restart
37	FLRN	Inversion of failure signal (put out also at the time of a restart)	Inversion of FLR
38	OUT0	Specified data output 1	ON: Specified data from remote control FA50: BIT0= 1 OFF: Specified data from remote control FA50: BIT0= 0
39	OUT0N	Inversion of specified data output 1	Inversion of OUT0 setting
42	COT	Cumulative operation time alarm	ON: Cumulative operation time is equal to or longer than <i>F521</i> OFF: Cumulative operation time is shorter than <i>F521</i>
43	COTN	Inversion of cumulative operation time alarm	Inversion of COT
44	LTA	Parts replacement alarm	ON: Calculation for parts replacement time is equal to or longer than the preset time ON: Calculation for parts replacement time is shorter than the preset time
45	LTAN	Inversion of replacement alarm	Inversion of LTA
48	LI1	F terminal input signal	ON: The signal input to F terminal is ON OFF: The signal input to F terminal is OFF
49	LI1N	Inversion of F terminal input signal	Inversion of LI1
50	LI2	R terminal input signal	ON: The signal input to R terminal is ON OFF: The signal input to R terminal is OFF
51	LI2N	Inversion of R terminal input signal	Inversion of LI2
52	PIDF	Signal in accordance of frequency command (VIA)	ON: Frequency commanded by <i>Fnd</i> or <i>F207</i> and that by VIA show the same value OFF: Frequency commanded by <i>Fnd</i> or <i>F207</i> and that by VIA show different values
53	PIDFN	Inversion of signal in accordance of frequency command (VIA)	Inversion of PIDF setting
54	MOFF	Undervoltage detection	ON: Undervoltage detected OFF: Other than undervoltage
55	MOFFN	Inversion of undervoltage detection	Inversion of MOFF
56	LOC	Local/remote switching	ON: Local mode OFF: Remote mode
57	LOCN	Inversion of local/remote switching	Inversion of LOC
58	PTC	PTC thermal alarm	ON: 60% and over the protection level by PTC OFF: Normal condition
59	PTCN	Inversion of PTC thermal alarm	Inversion of PTC
60	PIDFB	Signal in accordance of frequency command (VIB)	ON: Frequency commanded by <i>Fnd</i> or <i>F207</i> and that by VIB show the same value OFF: Frequency commanded by <i>Fnd</i> or <i>F207</i> and that by VIB show different values
61	PIDFBN	Inversion of signal in accordance of frequency command (VIB)	Inversion of PIDFB setting
62-253	Disabled	Invalid settings, always OFF (ignored)	Invalid settings, always OFF (ignored)
254	AOFF	Always OFF	Always OFF
255	AON	Always ON	Always ON

⚠ WARNING

DAMAGED PACKAGING

If the packaging appears damaged, it can be dangerous to open it or handle it.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

⚠ WARNING

DAMAGED EQUIPMENT

Do not operate or install any drive controller that appears damaged.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

⚠ WARNING

HANDLING AND LIFTING HAZARD

Keep the area below any equipment being lifted clear of all personnel and property. Use the lifting method illustrated in the figure.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

⚠ WARNING

RISK OF TOPPLING

- Do not stand the drive upright.
- Keep the drive on pallet until ready to install.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

⚠ DANGER

UNINTENDED EQUIPMENT OPERATION

Before turning on the drive controller or upon exiting the configuration menus, ensure that the inputs assigned to the Run command are in a state that will not cause the drive controller to run. Otherwise, the motor can start immediately

Failure to follow this instruction can result in death, serious injury, or equipment damage.

⚠ CAUTION

INCOMPATIBLE LINE VOLTAGE

Before turning on and configuring the drive controller, ensure that the line voltage is compatible with the line voltage range specified on the drive controller nameplate. The drive controller can be damaged if the line voltage is not compatible.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

This appendix only applies to replacing VFD drives on existing equipment. Before installing the drive controller, read this manual thoroughly and follow all precautions.

Before removing the drive controller from its packaging, verify that the carton is not damaged from shipping. Damage to the carton usually indicates improper handling. If any damage is found, notify the carrier and your Daikin Representative.

Storing and Shipping

If the drive controller is not immediately installed, store it in a clean, dry area where the ambient temperature is between -25.F and +158.F (-32.C and +70.C). If the drive controller must be shipped to another location, use the original shipping material and carton to protect the drive controller.

Lifting and Handling

- MD2 drive controllers up to 25 hp can be removed from their packaging and installed without a handling device.
- A hoist must be used for handling and lifting drive controllers of higher ratings.
- After removing the drive controller from its packaging, inspect it for damage. If any damage is found, notify the carrier and your sales representative.
- Verify that the drive controller nameplate and label conform to the packing slip and corresponding purchase order.




Table 38: Outside Dimensions and Weight


The symbols used in Table 38 are as follows:

- W: Width
- H: Height
- D: Depth
- W1: Mounting dimension (horizontal)
- H1: Mounting dimension (vertical)
- H2: Height of EMC plate mounting area


Voltage class	Applicable motor hp	Dimensions in. (mm)						Refer to drawing:	Approx. weight lb (kg)
		W	H	D	W1	H1	H2		
3-phase 230 V	1	4 (105)	5.6 (143)	5.9 (150)	3.6 (93)	4.7 (121.5)	2 (50)	A	4.0 (1.8)
	2								
	3								
	4	5.5 (140)	7.2 (184)	5.9 (150)	4.9 (126)	6.1 (157)	1.8 (48)	B	6.7 (3.1)
	5								
	7.5	7 (180)	9.1 (232)	6.7 (170)	6.3 (160)	8.2 (210)	2.95 (75)	C	13.5 (6.1)
	10								
	15								
	20	9.6 (245)	13 (329.5)	7.5 (190)	8.8 (225)	11.6 (295)	2.95 (75)	D	25.4 (11.5)
	25								
30	9.4 (240)	16.5 (420)	8.4 (214)	8.1 (206)	15.8 (403)	4.8 (122)	E	60.6 (27.4)	
40									
3-phase 460 V	1	4 (105)	5.6 (143)	5.9 (150)	3.6 (93)	4.7 (121.5)	2 (50)	A	4.4 (2.0)
	2								
	3								
	4	5.5 (140)	7.2 (184)	5.9 (150)	4.9 (126)	6.1 (157)	1.8 (48)	B	7.4 (3.4)
	5								
	7.5	7 (180)	9.1 (232)	6.7 (170)	6.3 (160)	8.2 (210)	2.95 (75)	C	14.3 (6.5)
	10								
	15								
	20	9.6 (245)	13 (329.5)	7.5 (190)	8.8 (225)	11.6 (295)	2.95 (75)	D	25.75 (11.7)
	25								
	30	9.4 (240)	16.5 (420)	8.4 (214)	8.1 (206)	15.8 (403)	4.8 (122)	E	51.81 (23.5)
	40								
	50	9.4 (240)	21.7 (550)	11.4 (290)	8.1 (206)	20.8 (529)	5.29 (113)	G	58.3 (26.4)
	60								
	75	12.5 (320)	24.8 (630)	11.4 (290)	11.0 (280)	23.8 (604.5)	4.7 (118)	G	87.5 (39.7)
100									

NOTE: In the following figures, dimensions common to all drive controllers are shown with numeric values, not with symbols. The model shown in Drawing A is fixed at two points: in the upper left and lower right corners.


Drawing A




Drawing C




Drawing B




Drawing D




Drawing E



Drawing F



Drawing G



⚠ WARNING

IMPROPER WIRING PRACTICES

- Follow the wiring practices described in this document in addition to those already required by the [National Electrical Code](#) and local electrical codes.
- The drive controller will be damaged if input line voltage is applied to the output terminals (U/T1, V/T2, W/T3).
- Check the power connections before energizing the drive controller.
- If replacing another drive controller, verify that all wiring connections to the MD2 drive controller comply with all wiring instructions in this manual.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

⚠ WARNING

INADEQUATE OVERCURRENT PROTECTION

- Overcurrent protective devices must be properly coordinated.
- The National Electrical Code and the [Canadian Electricity Code](#) require branch circuit protection. Use the fuses recommended on the drive controller nameplate to achieve published fault withstand current ratings.
- Do not connect the drive controller to a power feeder whose short circuit capacity exceeds the drive controller withstand fault rating listed on the drive controller nameplate.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

⚠ DANGER

HAZARDOUS VOLTAGE

Ground the equipment using the provided ground connecting point as shown in [Figure 19](#). The drive controller panel must be properly grounded before power is applied.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

Field Control Wiring and General Background for Reconnecting Wiring to a Replacement VFD

Good wiring practice requires the separation of control wiring from all power (line) wiring. In addition, power wiring to the motor must have the maximum possible separation from all other power wiring, whether from the same drive controller or other drive controllers. **Do not run power and control wiring, or multiple power wiring, in the same conduit.** This separation reduces the possibility of coupling electrical transients from power circuits into control circuits or from motor power wiring into other power circuits.

Follow the practices below when wiring MD2 drive controllers:

- Verify that the voltage and frequency of the input supply line and the voltage, frequency, and current of the motor match the rating on the drive controller nameplate
- Use metallic conduit for all drive controller wiring. Do not run control and power wiring in the same conduit
- Separate the metallic conduits carrying power wiring or low-level control wiring by at least 76 mm (3 in.)
- Separate the non-metallic conduits or cable trays carrying power wiring from the metallic conduit carrying control wiring by at least 305 mm (12 in.)
- Whenever power and control wiring cross, the metallic conduits and non-metallic conduits or trays must cross at right angles
- Equip all inductive circuits near the drive (such as relays, contactors, and solenoid valves) with noise suppressors, or connect them to a separate circuit

No field wiring is required except in the following instances:

Controls by others – Daikin provides examples of typical control wiring (see [Controls by Others for SAF, RAF, and EAF Applications on page 61](#)), but control wiring ultimately is the customer’s responsibility. All power wiring is factory installed and must not be changed.

Replacing a drive in an existing unit – Any replacement VFD must be wired exactly as the original VFD. This applies to power and control wiring. Carefully examine the original wiring and the wiring schematic before removing the original VFD.

Branch Circuit Protection and General Background for Reconnecting a Replacement VFD

Daikin factory installed all necessary branch circuit protection and grounding wires for the original VFD and fan motor. No further wiring is required except for field control wiring on [Controls by Others for SAF, RAF, and EAF Applications on page 61](#) applications.

Factory branch circuit protection, ground wiring, or any factory wiring, must not be changed.

The motor size must not be changed and any replacement motor nameplate amps must not exceed the original motor nameplate amps.

Refer to NEC Article 430 for sizing of branch circuit conductors. Ensure that all branch circuit components and equipment (such as transformers, feeder cables, disconnect devices, and protective devices) are rated for the input current of the MD2 drive controller, or for the rated output current, whichever value is larger. Rated input and output current values are shown on the drive controller nameplate.

NOTE: Ensure that the branch circuit feeder protection rating is not less than the rated output current of the drive controller.


Grounding

For safe, dependable operation, ground the drive controller according to the [National Electrical Code](#) and all local codes.

- To comply with current regulations concerning high leakage currents (above 3.5 mA), use at least a 10 mm² (6 AWG) protective conductor, or two protective conductors with the same cross-section as the power section AC supply conductors
- Verify that resistance to ground is one ohm or less. Improper grounding causes intermittent and unreliable operation

Make certain Daikin factory installed grounding is maintained (see “Proper Grounding” in [Figure 19](#)). Do not loop the ground cables or connect them in series (see “Improper Grounding” in [Figure 19](#)).

Figure 19: Grounding Multiple Drive Controllers



208 – 230 Volt, 7.5 – 10 HP VFDs


208 – 230 V, 7.5 – 10 HP VFD nameplate amps may be rated 1 amp less than the motor nameplate amps. Amp disparity between VFD and motor nameplates is normal for this application.

Power Terminals

To access the power terminals, open the cover using one of the methods illustrated in [Figure 20](#).

Figure 20: Power Terminal Access

Example MD2, 2 hp



Example MD2, 30 hp




Table 39: Power Terminal Functions

Terminals	Function
⊕	Ground terminal
R/L1 S/L2 T/L3	Power supply
U/T1 V/T2 W/T3	Outputs to the motor
PO	DC bus (+) polarity (do not use)
PA/+	DC bus (+) polarity
PB	DC bus connection (do not use)
PC/-	DC bus (-) polarity

NOTE: The PA/+, and PC/- terminals can only be used to measure the DC bus voltage. Do not remove the jumper between PA/+ and PO.

Table 40: Power Terminal Characteristics

MD2H		Maximum Wire Size		Tightening Torque
Voltage	hp	mm ²	AWG	Nm (lb-in)
230 V	1 – 3	6	10	1.3 (10.7)
	4	6	10	1.3 (10.7)
	5	6	10	1.3 (10.7)
	7.5	16	6	2.5 (22.3)
	10	16	6	2.5 (22.3)
	15	25	3	4.5 (40.1)
	20	25	3	4.5 (40.1)
	25	25	3	2.5 (22.3)
	30	50	1/0	12 (106.2)
460 V	40	150	300 kcmil	41 (362.9)
	1 – 7.5	6	10	1.3 (10.7)
	10	16	6	2.5 (22.3)
	15	16	6	2.5 (22.3)
	20	25	3	4.5 (40.1)
	25	25	3	4.5 (40.1)
	30	50	1/0	12 (106.2)
	40	50	1/0	12 (106.2)
	50	50	1/0	12 (106.2)
60	50	1/0	12 (106.2)	
75 – 100	150	300 kcmil	41 (360)	





Table 41: Display Terminal Description


Item	LED/Key	Characteristics
1	Display RUN LED	<ul style="list-style-type: none"> • Illuminates when a Run command is applied to the drive controller • Flashes when there is a speed reference present with a Run command
2	Display PRG LED	<ul style="list-style-type: none"> • Illuminates when Programming mode is active • Flashes in <i>RUF - Gr U</i> modes.
3	Display MON LED	<ul style="list-style-type: none"> • Illuminates when Monitoring mode is active • Flashes in Fault History Display mode
4	Up/Down Keys	Depending on the mode, you can use the arrows to: <ul style="list-style-type: none"> • Navigate between the menus • Change a value • Change the speed reference when the Up/Down LED (5) is illuminated
5	Up/Down LED	<ul style="list-style-type: none"> • Illuminates when the navigation arrows are controlling the speed reference
6	Run LED	<ul style="list-style-type: none"> • Illuminates when the Run key is enabled
7	Run Button	<ul style="list-style-type: none"> • Pressing this button/key when the Run LED is illuminated starts the drive controller
8	Display	<ul style="list-style-type: none"> • 4-digit, 7-segment LED display
9	Units LEDs	<ul style="list-style-type: none"> • The % LED illuminates when the display numeric value is in percentage • The Hz LED illuminates when the display numeric value is in Hertz
10	Loc/Rem LED	<ul style="list-style-type: none"> • Local/Remote mode indicator. Illuminates when Local mode is selected
11	Mode Button	Press to select the Mode: <ul style="list-style-type: none"> • Display mode (default) • Adjustment mode • Monitoring mode Can also be used to go back to the previous menu
12	Loc/Rem Button	<ul style="list-style-type: none"> • Switches between Local and Remote modes
13	ENT Button	<ul style="list-style-type: none"> • Press to display a parameter's value or to save a changed value
14	Stop Button	<ul style="list-style-type: none"> • In Local mode (12), pressing the STOP key decelerates the drive to a stop • In Remote mode (see table item #10), while the VFD is being controlled by the unit controller, pressing the STOP key will allow the drive to freewheel stop (drive display will indicate a flashing "E") • If <i>F 735</i> is set to 0 (default setting), pressing the stop key twice will reset the flashing "E" fault and other resettable faults if the fault condition has been resolved

Mode Navigation



Monitoring Mode

The Monitoring mode displays drive controller operational data in real time. To access the Monitoring mode, press the MODE key until the MON LED is illuminated. Then press the UP and Down keys to view up to 30 different types of data.



Menu Navigation

Figure 21 illustrate how to navigate through the programming menus and submenus.

Figure 21: Menu Navigation








Figure 21 continued: Menu Navigation



1. Pressing the UP key searches the parameter list starting with the first one changed.
2. Pressing the DOWN key searches the parameter list starting with the last one changed.
3. The number of parameters displayed within the GRU menu depends upon how many have been altered from their factory settings.
4. When all the changed parameters have been displayed, the display returns to GRU.



The MD2 drive controller offers three options to return parameters to their factory default settings:

- Factory reset: set parameter tYP to 3
- 50 Hz reset: set parameter tYP to 1
- 60 Hz reset: set parameter tYP to 2

NOTE: To restore the MD2 drive to 60Hz Factory default setting you would first set parameter $P\text{yL}$ to 3, press enter followed by setting parameter $P\text{yL}$ to 2 and pressing enter again. The operation specific Daikin parameters would then need to be changed for proper unit operation.

tYP : Default Setting

Function

Allows setting of all parameters to the standard default setting, etc. at one time.

Note that F_n , F_n5L , $F109$, $F470$ - $F473$, $F669$, and $F880$ will not be reset to their factory default settings.

- The function will be displayed as 0 during reading on the right. This previous setting is displayed.

Example: 3 0

- tYP cannot be set while the inverter is operating. Always stop the inverter first and then program.

Title	Function	Adjustment Range	Default Setting
tYP	Default Setting	0: — 1: 50Hz default setting 2: 60 Hz default setting 3: Standard default setting (initialization) 4: Trip record clear 5: Cumulative operating time clear 6: Initialization of type information 7: Save user-defined parameters 8: Call user-defined parameters 9: Cumulative fan operation time record clear	0

Programmed Value

- 50 Hz default setting ($\text{tYP} = 1$)

Setting tYP at 1 causes the following parameters to be set for operation using a base frequency of 50 Hz (this does not change the setting of any other parameters).

Parameter FH , UL , uL , $F170$, $F204$, $F213$, $F814$: 50 Hz

Parameter $F417$: According to model

- 60 Hz default setting ($\text{tYP} = 2$)

Setting tYP at 2 causes the following parameters to be set for operation using a base frequency of 60 Hz (this does not change the setting of any other parameters).

Parameter FH , UL , uL , $F170$, $F204$, $F213$, $F814$: 60 Hz

Parameter $F417$: According to model

- Default setting ($\text{tYP} = 3$)

Setting tYP to 3 will return all parameters to the standard values that were programmed at the factory.

When tYP is set to 3, $in1t$ will be displayed for a short time after the setting and will then be erased and the original indication 0_0 will be displayed. Trip history data will be cleared at this time.

- Trip clear ($\text{tYP} = 4$)

Setting tYP to 4 initializes the past four sets of recorded error history data.

The parameter does not change.

- Cumulative operation time clear ($\text{tYP} = 5$)

Setting tYP to 5 resets the cumulative operation time to the initial value of zero.

- Save user setting parameters ($\text{tYP} = 7$)

Setting tYP to 7 saves the current settings of all parameters.

- Load user setting parameters ($\text{tYP} = 8$)

Setting tYP to 8 loads parameter settings to (calls up) those saved by setting tYP to 7

By setting tYP to 7 or 8, you can use parameters as your own default parameters.

- Cumulative fan operation time record clear ($\text{tYP} = 9$)

Setting tYP to 9 resets the fan cumulative operation time to the initial value of zero.

Set this parameter when replacing the cooling fan.

NOTE: You must stop the drive controller before changing the setting of tYP .

The following parameters are not affected by ... setting of 1, 2, and 3: F_n , F_n5L , $F109$, $F470$ through $F473$, and $F880$.

The setting display of this parameter contains two numbers. The left-most number displays the last operation performed. The right-most number indicates the pending operation and should be adjusted for the action desired.

When changing parameters the last parameter to save is " tYP ". After making the changes necessary go to tYP and select "save" #7 the drive will then save all the parameters, cycle power to the drive, you can re-apply power after the screen goes blank.

NOTE: Remember to do this last!

When changing parameters the last parameter to save is " tYP ". After making the changes necessary go to tYP and select "SAVE" #7 the drive will then save all the parameters, cycle power to the drive, you can re-apply power after the screen goes blank. When drive is up and running again cycle power to the entire unit. All parameters are saved and functional after the final power cycling.

Table 42: Parameters whose values do not change if a reset is performed

Parameter	Description	Unit	Min.Value	Max.Value	Default Value
<i>F_n</i>	Meter adjustment	1	1	1280	145
<i>F_{n5L}</i>	Meter selections	1	0	19	0
<i>F₁₀₉</i>	Analog/contact input function selection (VIA/VIB)	1	0	2	0
<i>F₄₇₀</i>	VIA bias	1	0	225	128
<i>F₄₇₁</i>	VIA gain	1	0	255	148
<i>F₄₇₂</i>	VIB bias	1	0	255	128
<i>F₄₇₃</i>	VIB gain	1	0	255	148
<i>F₈₈₀</i>	Free notes	1	0	65535	0

NOTE: A 60 Hz reset on a 460V drive controller sets the rated voltage (*U_L* and *F₄₇₁*) to 400V.

Table 43: Default Parameters

Code	Function Description	Unit	Min. Value	Max. Value	Default Value
<i>R_{U1}</i>	Automatic acceleration/deceleration	1	0	2	1
<i>R_{U4}</i>	Automatic function setting	1	0	4	0
<i>C_{MOd}</i>	Command mode selection	1	0	2	0
<i>F_{nOd}</i>	Frequency setting mode selection 1	1	1	1	5
<i>F_{n5L}</i>	Meter selection	1	0	19	0
<i>F_n</i>	Meter adjustment	1	1	1280	145
<i>t_{YP}</i>	Default setting	1	0	9	0
<i>F_r</i>	Forward/reverse run selection (Operation panel)	1	0	3	0
<i>R_{CC}</i>	Acceleration time 1	0.1sec	0	3200	10
<i>d_{EC}</i>	Deceleration time 1	0.1sec	0	3200	10
<i>F_H</i>	Maximum frequency	0.01Hz	30	200	50
<i>U_L</i>	Upper limit frequency	0.01Hz	1	80	50
<i>L_L</i>	Lower limit frequency	0.01Hz	0	60	0
<i>u_L</i>	Base frequency 1	0.01Hz	25	200	50
<i>u_{Lv}</i>	Base frequency voltage 1	0.1V	50	660	—
<i>P_t</i>	V/F control mode selection 1	1	1	0	6
<i>u_b</i>	Torque boost 1	0.10%	0	30	5
<i>t_{HR}</i>	Motor electronic-thermal protection level 1	1%	10	100	100
<i>Q_{LN}</i>	Electric-thermal protection characteristic selection	1	0	7	0
<i>S_{r1}</i>	Preset-speed operation frequency 1	0.01Hz	0	60	15
<i>S_{r2}</i>	Preset-speed operation frequency 2	0.01Hz	0	60	20
<i>S_{r3}</i>	Preset-speed operation frequency 3	0.01Hz	0	60	25
<i>S_{r4}</i>	Preset-speed operation frequency 4	0.01Hz	0	60	30
<i>S_{r5}</i>	Preset-speed operation frequency 5	0.01Hz	0	60	35
<i>S_{r6}</i>	Preset-speed operation frequency 6	0.01Hz	0	60	40
<i>S_{r7}</i>	Preset-speed operation frequency 7	0.01Hz	0	60	45
<i>F₁₀₀</i>	Low-speed signal output frequency	0.01Hz	0	80	0
<i>F₁₀₁</i>	Speed reach setting frequency	0.01Hz	0	80	0
<i>F₁₀₂</i>	Speed reach detection band	0.01Hz	0	80	2.5
<i>F₁₀₈</i>	2nd always-active function selection	1	0	71	0
<i>F₁₀₉</i>	Analog/contact input function selection (VIA/VIB)	1	0	2	0
<i>F₁₁₀</i>	Always-active function selection	1	0	71	1
<i>F₁₁₁</i>	Input terminal selection1 (F)	1	0	71	2
<i>F₁₁₂</i>	Input terminal selection 2 (R)	1	0	71	6
<i>F₁₁₃</i>	Input terminal selection 3 (RST)	1	0	71	10
<i>F₁₁₈</i>	Input terminal selection 8 (VIA)	1	0	71	7
<i>F₁₃₀</i>	Output terminal selection 1A (RY-RC)	1	0	255	4

Code	Function Description	Unit	Min. Value	Max. Value	Default Value
F 132	Output terminal selection 3 (FL)	1	0	255	11
F 137	Output terminal selection 1B (RY-RC)	1	0	255	255
F 139	Output terminal logic selection (RY-RC/OUT-NO)	1	0	1	0
F 167	Frequency command agreement detection range	0.01Hz	0	80	2.5
F 170	Base frequency 2	0.01Hz	25	200	50
F 171	Base frequency voltage 2	0.1V	50	660	—
F 172	Torque boost 2	0.10%	0	30	5
F 175	Motor electronic-thermal protection level 2	1%	10	100	100
F 185	Stall prevention level 2	1%	10	111	110
F 200	Frequency priority selection	1	0	1	0
F 201	VIA input point 1 setting	1%	0	100	0
F 202	VIA input point 1 frequency	0.01Hz	0	200	0
F 203	VIA input point 2 setting	1%	0	100	100
F 204	VIA input point 2 frequency	0.01Hz	0	200	50
F 207	Frequency setting mode selection 2	1	1	5	2
F 210	VIB input point 1 setting	1%	0	100	0
F 211	VIB input point 1 frequency	0.01Hz	0	200	0
F 212	VIB input point 2 setting	1%	0	100	100
F 213	VIB input point 2 frequency	0.01Hz	0	200	50
F 240	Starting frequency setting	0.01Hz	1	10	0.5
F 241	Operation starting frequency	0.01Hz	0	80	0
F 242	Operation starting frequency hysteresis	0.01Hz	0	80	0
F 250	DC braking starting frequency	0.01Hz	0	80	0
F 251	DC braking current	1%	0	100	50
F 252	DC braking time	0.1sec	0	20	1
F 256	Time limit for lower-limit frequency operation	0.1sec	0	600	0
F 264	Input from external contacts-UP response time	0.1sec	0	10	0.1
F 265	Input from external contacts-UP frequency step width	0.01Hz	0	80	0.1
F 266	Input from external contacts-DOWN response time	0.1sec	0	10	0.1
F 267	Input from external contacts-DOWN freq step width	0.01Hz	0	80	0.1
F 268	Initial value of UP/DOWN frequency	0.01Hz	0	60	0
F 269	Saving of changed value of UP/DOWN frequency	1	0	1	1
F 270	Jump frequency 1	0.01Hz	0	80	0
F 271	Jump width 1	0.01Hz	0	30	0
F 272	Jump frequency 2	0.01Hz	0	80	0
F 273	Jump width 2	0.01Hz	0	30	0
F 274	Jump frequency 3	0.01Hz	0	80	0
F 275	Jump width 3	0.01Hz	0	30	0
F 294	Preset-speed operation frequency 15	0.01Hz	0	60	50
F 295	Selection of bump-less	1	0	1	1
F 300	PWM carrier frequency	0.1kHz	6	16	—
F 301	Auto-restart control selection	1	0	4	3
F 302	Regeneration power ride-through control (Deceleration stop)	1	0	2	0
F 303	Retry selection (number of times)	1	0	10	3
F 305	Over-voltage limit operation (Slowdown stop mode selection)	1	0	3	2
F 307	Supply voltage correction (limitation of output voltage)	1	0	3	3
F 311	Reverse-run prohibition	1	0	2	1
F 312	Random mode	1	0	1	0
F 316	Carrier frequency control mode selection	1	0	3	1
F 320	Drooping gain	1%	0	100	0
F 323	Drooping insensitive torque band	1%	0	100	10
F 359	PID control waiting time	1sec	0	2400	0
F 360	PID control	1	0	2	0

Code	Function Description	Unit	Min. Value	Max. Value	Default Value
F362	Proportional gain	0.01	0	100	0.3
F363	Integral gain	0.01	0	100	0.2
F366	Differential gain	0.01	0	3	0
F400	Auto-tuning	1	0	2	0
F401	Slip frequency gain	1%	0	150	50
F402	Motor constant #1 (primary resistance)	0.10%	0	30	—
F415	Motor rated current	0.1A	0	200	—
F416	Motor no-load current	1%	10	100	—
F417	Motor rated speed	1min-1	100	15000	—
F418	Speed control response coefficient	1	1	150	40
F419	Speed control stability coefficient	1	1	100	20
F470	VIA bias	1	0	255	128
F471	VIA gain	1	0	255	148
F472	VIB bias	1	0	255	128
F473	VIB gain	1	0	255	148
F480	Exciting strengthening coefficient	1%	100	130	100
F481	Factory adjustment1	1	0	9999	0
F482	Factory adjustment2	1	0	9999	442
F483	Factory adjustment3	0.1	0	300	100
F485	Stall cooperation gain at field weakening zone 1	1	10	250	100
F492	Stall cooperation gain at field weakening zone 2	1	50	150	100
F494	Motor adjustment factor	1	0	200	70
F495	Maximum voltage adjustment factor	1%	90	120	104
F496	Carrier change adjustment factor	0.1kHz	0	14	14
F500	Acceleration time 2	0.1sec	0	3200	20
F501	Deceleration time 2	0.1sec	0	3200	20
F502	Acceleration/deceleration 1 pattern	1	0	2	0
F503	Acceleration/deceleration 2 pattern	1	0	2	0
F504	Acceleration/deceleration selection (1/2/3)	1	1	2	1
F505	Acceleration/deceleration 1 and 2 switching frequency	0.01Hz	0	60	0
F506	S-pattern lower-limit adjustment amount	1%	0	50	10
F507	S-pattern upper-limit adjustment amount	1%	0	50	10
F601	Stall prevention level 1	1%	10	111	110
F602	Inverter trip retention selection	1	0	1	0
F603	Emergency stop selection	1	0	2	0
F604	Emergency DC braking time	0.1sec	0	20	1
F605	Output phase failure detection mode selection	1	0	5	3
F607	Motor 150%-overload time limit	1sec	10	2400	300
F608	Input phase failure detection mode selection	1	0	1	1
F609	Hysteresis for small current detection	1%	1	20	10
F610	Low current trip/alarm	1	0	1	0
F611	Small current detection current	1%	0	100	0
F612	Small current detection time	1sec	0	255	0
F613	Detection of output short-circuit during start-up	1	0	3	0
F615	Over-torque trip/alarm selection	1	0	1	0
F616	Over-torque detection level	1%	0	250	130
F618	Over-torque detection time	0.1sec	0	10	0.5
F619	Over-torque detection level hysteresis	1%	0	100	10
F621	Cumulative operation time alarm setting	0.1	0	1000	610
F626	Over-voltage stall protection level	1%	100	150	140
F627	Under-voltage trip/alarm selection	1	0	2	0
F632	Thermal memory selection	1	0	1	0
F633	Trip at VIA low level input mode	1%	0	100	0

Code	Function Description	Unit	Min. Value	Max. Value	Default Value
F634	Annual avg ambient temp (calculation for life alarms)	1	1	6	3
F645	Selection of PTC thermal	1	0	2	0
F646	Detection level of PTC	1ohm	100	9999	3000
F650	Forced/Fire-speed control selection	1	0	1	0
F691	Inclination characteristic of analog output	1	0	1	1
F692	Meter bias	1%	0	100	0
F700	Prohibition of change of parameter settings	1	0	1	0
F701	Unit selection	1	0	1	1
F702	Free unit selection	0.01	0	200	0
F705	Inclination characteristic of free unit display	1	0	1	1
F706	Free unit display bias	0.01Hz	0	80	0
F707	Free step 1 (pressing a panel key once)	0.01Hz	0	80	0
F708	Free step 2 (panel display)	1	0	255	0
F710	Standard monitor display selection	1	0	10	0
F721	Panel stop pattern	1	0	1	0
F730	Prohibition of freq. setting on the operation panel (FC)	1	0	1	0
F732	Panel operation prohibition (Local/Remote keys)	1	0	1	0
F733	Panel operation prohibition (RUN/STOP keys)	1	0	1	0
F734	Prohibition of panel emergency stop operation	1	0	1	0
F735	Prohibition of panel reset operation	1	0	1	0
F738	Selection of AUF	1	0	1	0
F748	Selection of watt hour memory	1	0	1	1
F749	Display unit selection of watt hour	1	0	3	0
F800	Communication band speed	1	0	1	1
F801	Parity	1	0	2	1
F802	Inverter number; SAF=1;RAF=2;HW=3	1	0	247	1
F803	Communication error trip time	1sec	0	100	3
F805	Communication waiting time	0.01sec	0	2	0
F806	Setting master & slave for comm between inverters	1	0	4	0
F811	Communication input point 1 setting	1%	0	100	0
F812	Communication input point 1 frequency	0.01Hz	0	200	0
F813	Communication input point 2 setting	1%	0	100	100
F814	Communication input point 2 frequency	0.01Hz	0	200	0
F829	Selection of communication protocol	1	0	4	1
F851	Inverter action at network & communication break	1	0	4	0
F856	Number of motor poles for comm speed calculation	1	1	8	2
F870	Block write data 1	1	0	6	0
F871	Block write data 2	1	0	6	0
F875	Block read data 1	1	0	11	0
F876	Block read data 2	1	0	11	0
F877	Block read data 3	1	0	11	0
F878	Block read data 4	1	0	11	0
F879	Block read data 5	1	0	11	0
F880	Free notes	1	0	65535	0
F890	Parameter for option 1	1	0	65535	0
F891	Parameter for option 2	1	0	65535	0
F892	Parameter for option 3	1	0	65535	0
F893	Parameter for option 4	1	0	65535	0
F894	Parameter for option 5	1	0	65535	0
F895	Parameter for option 6	1	0	65535	0
F896	Parameter for option 7	1	0	65535	0
F897	Parameter for option 8	1	0	65535	0
F898	Parameter for option 9	1	0	65535	0

Code	Function Description	Unit	Min. Value	Max. Value	Default Value
<i>F899</i>	Parameter for option 10	1	0	65535	0
<i>F910</i>	Step-out detection current level (for PM motors)	1%	10	150	100
<i>F911</i>	Step-out detection time (for PM motors)	0.1sec	0	25	0.0
<i>F912</i>	q-axis self-inductance (for PM)	0.01mH	0	650	0.00

Rooftop and Self-Contained with MicroTech III Controls for SAF, RAF, and EAF Applications


WARNING

UNINTENDED EQUIPMENT OPERATION

- Modifying or changing parameters whose function is not described in this manual will affect drive controller operation. Some register changes will take effect as soon as they are entered.
- Do not modify or change parameters whose function is not described in this instruction bulletin.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

Figure 22: VFD 10 and 20 Wiring Diagram



NOTE: Contacts and terminations are in the unit control panel.

Switch Settings

Switch Label	Switch Function	Proper Switch Position
SW 100	Voltage	Left
SW 101	Voltage	Right
SW 102	Source	Right

Some early MicroTech III installations used the RJ45 comm connections which require a different settings for parameter F807 dependent on the connection will determine the setting for parameter F807.

RJ45 = 0

Two terminal A(-) & B(+) = 1

Parameter Settings:

The MD2 VFD has been made to Daikin specifications. All factory installed MD2 VFDs with MicroTech III controls are also factory configured and started. Table 44 lists the parameters that have been specifically configured for Daikin or else may need owner adjustment as described in this manual.

- “VFD Default” settings are the vendor defaults.
- “Daikin Settings” are the recommended settings for Daikin units.
- No other parameters should be needed or adjusted.

NOTE: To restore the MD2 drive to 60Hz Factory default setting you would first set parameter *P46* to 3, press enter followed by setting parameter *P46* to 2 and pressing enter again. The operation specific Daikin parameters would then need to be changed for proper unit operation.

NOTE: Remember to do this last!

When changing parameters the last parameter to save is “*tYP*” After making the changes necessary go to *tYP* and select “*SAVE*” #7 the drive will then save all the parameters, cycle power to the drive, you can re-apply power after the screen goes blank. When drive is up and running again cycle power to the entire unit. All parameters are saved and functional after the final power cycling.

Table 44: Parameter Settings

Code	Comm #	Function	Default Value	Daikin Value
<i>RU1</i>	0	Automatic acceleration/deceleration	1	0
<i>RU4</i>	40	Automatic function setting	0	1
<i>CMD</i>	3	Command mode selection	0	2
<i>FMD</i>	4	Frequency setting mode selection 1	1	4
<i>LYP</i>	7	Default setting	0	7
<i>FN</i>	6	Meter adjustment	145	318
<i>ACC</i>	9	Acceleration time 1	10	60
<i>DEC</i>	10	Deceleration time 1	10	60
<i>FH</i>	11	Maximum frequency	50	60
<i>UL</i>	12	Upper limit frequency	50	60
<i>LL</i>	13	Lower limit frequency	0	20
<i>UL</i>	14	Base frequency 1	50	60
<i>ULV</i>	409	Base frequency voltage 1	—	Motor
<i>OLN</i>	17	Electric-thermal protection characteristic selection	0	1
<i>F111</i>	111	Input terminal selection1 (F)	2	45
<i>F112</i>	112	Input terminal selection 2 (R)	6	0
<i>F130</i>	130	Output terminal selection 1A (RY-RC)	4	14
<i>F170</i>	170	Base frequency 2	50	60
<i>F268</i>	268	Initial value of UP/DOWN frequency	0	20
<i>F303</i>	303	Retry selection (number of times)	3	5
<i>F605</i>	605	Output phase failure detection mode selection	3	5
<i>F732</i>	732	Panel operation prohibition (Local/Remote keys)	0	1
<i>F801</i>	801	Parity	1	1
<i>F802</i>	802	Inverter number; SAF=1;RAF=2;HW=3	1	=1; Daikin ¹
<i>F803</i>	803	Communication error trip time	3	10
<i>F814</i>	814	Communication input point 2 frequency	0	=60; Daikin
<i>F821</i>	821	Parity	1	0; Daikin
<i>F851</i>	851	Inverter action at communication break	4	0
<i>F880</i>	880	Free notes	0	321

¹ *F802* parameter setting will vary depending on application. 1= Supply Air Fan, 2= Return Air Fan, 3= Heat Wheel.

Maverick II with MicroTech III Controls for SAF and EAF Applications


WARNING

UNINTENDED EQUIPMENT OPERATION

- Modifying or changing parameters whose function is not described in this manual will affect drive controller operation. Some register changes will take effect as soon as they are entered.
- Do not modify or change parameters whose function is not described in this instruction bulletin.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

Figure 23: AF (10) and EAF (51) Wiring Diagram



NOTE: Contacts and terminations are in the unit control panel.

Switch Settings

Switch Label	Switch Function	Proper Switch Position
SW 100	Voltage	Left
SW 101	Voltage	Right
SW 102	Source	Right

NOTE: To restore the MD2 drive to 60Hz Factory default setting you would first set parameter *P4t* to 3, press enter followed by setting parameter *P4t* to 2 and pressing enter again. The operation specific Daikin parameters would then need to be changed for proper unit operation.

Parameter Settings:

The MD2 VFD has been made to Daikin specifications. All factory installed MD2 VFDs with MicroTech III controls are also factory configured and started. Table 45 lists the parameters that have been specifically configured for Daikin or else may need owner adjustment as described in this manual.

- “VFD Default” settings are the vendor defaults.
- “Daikin Settings” are the recommended settings for Daikin units.
- No other parameters should be needed or adjusted.

NOTE: Remember to do this last!

When changing parameters the last parameter to save is “*tYP*”. After making the changes necessary go to *tYP* and select “*SRU*” #7 the drive will then save all the parameters, cycle power to the drive, you can re-apply power after the screen goes blank. When drive is up and running again cycle power to the entire unit. All parameters are saved and functional after the final power cycling.

Table 45: MPS Parameter Settings

Code	Comm #	Function	Default Value	Daikin Value
<i>RU1</i>	0	Automatic acceleration/deceleration	1	0
<i>RU4</i>	40	Automatic function setting	0	1
<i>ENOd</i>	3	Command mode selection	0	2
<i>FN0d</i>	4	Frequency setting mode selection 1	1	4
<i>FN</i>	6	Meter adjustment	145	318
<i>LYP</i>	7	Default setting	0	7
<i>ACC</i>	9	Acceleration time 1	10	60
<i>DEC</i>	10	Deceleration time 1	10	60
<i>FH</i>	11	Maximum frequency	50	60
<i>UL</i>	12	Upper limit frequency	50	60
<i>uL</i>	14	Base frequency 1	50	60
<i>uLv</i>	409	Base frequency voltage 1	—	Motor volts
<i>PE</i>	15	V/F control mode selection 1	1	0
<i>EHr</i>	600	Motor electronic-thermal protection level 1	100	Motor FLA
<i>OLn</i>	17	Electric-thermal protection characteristic selection	0	1
<i>F130</i>	130	Output terminal selection 1A (RY-RC)	4	14
<i>F303</i>	303	Retry selection (number of times)	3	5
<i>F605</i>	605	Output phase failure detection mode selection	3	5
<i>F632</i>	632	Thermal memory selection	0	1
<i>F732</i>	732	Panel operation prohibition	0	1
<i>F801</i>	801	Parity	1	1
<i>F802</i>	802 ¹	Inverter number	1	1, 2, 3
<i>F803</i>	803	Communication error trip time	3	10
<i>F807</i>	807	Comm Port	1	See note ²
<i>F821</i>	821	Parity	1	0: Daikin
<i>F829</i>	829	Selection of communication protocol	1	1
<i>F851</i>	851	Inverter action at communication break	4	0
<i>F880</i>	880	Free notes	0	207

1. *802* parameter setting will vary depending on application. 1= Supply Air Fan, 2= Return Air Fan, 3= Heat Wheel.

2. *F807* = 0 if RJ45 plug used for communications port, 1 if terminals A & B used for Modbus connections

Rooftop and Self-Contained with MicroTech III Controls for Speedtrol Condenser Fan Control


WARNING

UNINTENDED EQUIPMENT OPERATION

- Modifying or changing parameters whose function is not described in this manual will affect drive controller operation. Some register changes will take effect as soon as they are entered.
- Do not modify or change parameters whose function is not described in this instruction bulletin.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

Figure 24: SpeedTrol Wiring Diagram



PT21 is a refrigerant pressure sensing transducer

R17 is a compressor interlocking relay

NOTE: Contacts and terminations are in the unit control panel.

Switch Settings

Switch Label	Switch Function	Proper Switch Position
SW 100	Voltage	Left
SW 101	Voltage	Right
SW 102	Source	Right

NOTE: To restore the MD2 drive to 60Hz Factory default setting you would first set parameter $P44$ to 3 , press enter followed by setting parameter $P44$ to 2 and pressing enter again. The operation specific Daikin parameters would then need to be changed for proper unit operation.

Parameter Settings:

The MD2 VFD has been made to Daikin specifications. All factory installed MD2 VFDs with MicroTech III controls are also factory configured and started. Table 46 lists the parameters that have been specifically configured for Daikin or else may need owner adjustment as described in this manual.

- “VFD Default” settings are the vendor defaults.
- “Daikin Settings” are the recommended settings for Daikin units.
- No other parameters should be needed or adjusted.

NOTE: Remember to do this last!

When changing parameters the last parameter to save is “ $44P$ ” After making the changes necessary go to $44P$ and select “ $SAVE$ ” #7 the drive will then save all the parameters, cycle power to the drive, you can re-apply power after the screen goes blank. When drive is up and running again cycle power to the entire unit. All parameters are saved and functional after the final power cycling.

Table 46: Parameter Settings

Code	Comm #	Function	Default Value	Daikin Setting
<i>RU1</i>	0	Automatic acceleration/deceleration	1	0
<i>RU4</i>	40	Automatic function setting	0	1
<i>tYP</i>	7	Default setting	0	7
<i>ACC</i>	9	Acceleration time 1	10	10
<i>dEC</i>	10	Deceleration time 1	10	30
<i>FH</i>	11	Maximum frequency	50	60
<i>UL</i>	12	Upper limit frequency	50	60
<i>LL</i>	13	Lower limit frequency	0	23
<i>ωL</i>	14	Base frequency 1	50	60
<i>ωLω</i>	409	Base frequency voltage 1	—	Daikin to set at Factory
<i>tHr</i>	600	Motor electronic thermal protection level in amperes. Adjust thr to the nominal current value which appears on the motor nameplate.	100	Daikin to set at Factory
<i>QLR</i>	17	Electric-thermal protection characteristic selection	0	2
<i>F110</i>	110	Always-active function selection	1	0
<i>F111</i>	111	Input terminal selection1 (F)	2	56
<i>F112</i>	112	Input terminal selection 2(R)	6	0
<i>F113</i>	113	Input terminal selection 3 (RST)	10	0
<i>F118</i>	118	Input terminal selection 8 (VIA)	7	0
<i>F130</i>	130	Output terminal selection 1A (RY-RC)	4	14
<i>F132</i>	132	Output terminal selection 3 (FL)	11	5
<i>F170</i>	170	Base frequency 2	50	60
<i>F201</i>	201	VIA input point 1 setting	0	10
<i>F202</i>	202	VIA input point 1 frequency	0	23
<i>F203</i>	203	VIA input point 2 setting	100	50
<i>F204</i>	204	VIA input point 2 frequency	50	60
<i>F213</i>	213	VIB input point 2 frequency	50	60
<i>F240</i>	240	Starting frequency	0.5	10
<i>F300</i>	300	PWM carrier frequency	—	6
<i>F496</i>	496	Carrier change adjustment factor	14	1
<i>F821</i>	821	Parity	1	0; Daikin
<i>F880</i>	880	Free notes	0	119

Rooftop Energy Recovery Wheel Speed Control MicroTech III


WARNING

UNINTENDED EQUIPMENT OPERATION

- Modifying or changing parameters whose function is not described in this manual will affect drive controller operation. Some register changes will take effect as soon as they are entered.
- Do not modify or change parameters whose function is not described in this instruction bulletin.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

Figure 25: ERW Wiring Diagram



NOTE: Contacts and terminations are in the unit control panel.

Switch Settings

Switch Label	Switch Function	Proper Switch Position
SW 100	Voltage	Left
SW 101	Voltage	Right
SW 102	Source	Right

Parameter Settings:

The MD2 VFD has been made to Daikin specifications. All factory installed MD2 VFDs with MicroTech III controls are also factory configured and started. Table 47 lists the parameters that have been specifically configured for Daikin or else may need owner adjustment as described in this manual.

- “VFD Default” settings are the vendor defaults.
- “Daikin Settings” are the recommended settings for Daikin units.
- No other parameters should be needed or adjusted.

NOTE: To restore the MD2 drive to 60Hz Factory default setting you would first set parameter P45 to 3, press enter followed by setting parameter P45 to 2 and pressing enter again. The operation specific Daikin parameters would then need to be changed for proper unit operation.

NOTE: Remember to do this last!

When changing parameters the last parameter to save is “E4P” After making the changes necessary go to E4P and select “SAVE” #7 the drive will then save all the parameters, cycle power to the drive, you can re-apply power after the screen goes blank. When drive is up and running again cycle power to the entire unit. All parameters are saved and functional after the final power cycling.

Table 47: Parameter Settings

Code	Comm #	Function	Default	Daikin Setting
<i>RU1</i>	0	Automatic acceleration/deceleration	1	0
<i>RU4</i>	40	Automatic function setting	0	1
<i>CR0d</i>	3	Command mode selection	0	2
<i>FR0d</i>	4	Frequency setting mode selection 1	1	4
<i>FR</i>	6	Meter adjustment	145	318
<i>LYP</i>	7	Default setting	0	7
<i>ACC</i>	9	Acceleration time 1	10	60
<i>DEC</i>	10	Deceleration time 1	10	60
<i>FM</i>	11	Maximum frequency	50	60
<i>UL</i>	12	Upper limit frequency	50	60
<i>LL</i>	13	Lower limit frequency	0	6; Daikin
<i>UL</i>	14	Base frequency 1	50	60
<i>ULV</i>	409	Base frequency voltage 1	—	Daikin to set at Factory
<i>OLN</i>	17	Electric-thermal protection characteristic selection	0	1
<i>F109</i>	109	Analog/contact input function selection (VIA/VIB)	0	2
<i>F110</i>	110	Always-active function selection	1	0
<i>F111</i>	111	Input terminal selection1 (F)	2	0
<i>F112</i>	112	Input terminal selection 2 (R)	6	0
<i>F130</i>	130	Output terminal selection	4	14
<i>F170</i>	170	Base frequency 2	50	60
<i>F268</i>	268	Initial value of UP/DOWN frequency	0	15
<i>F303</i>	303	Retry selection (number of times)	3	5
<i>F605</i>	605	Output phase failure	3	5
<i>F732</i>	732	Panel operation prohibition (local/remote)	0	1
<i>F801</i>	801	Parity	1	1
<i>F802</i>	802	Inverter number, SAF=1, RAF=2	1	=3, Daikin
<i>F803</i>	803	Communication trip time	3	10
<i>F814</i>	814	Communication input point 2 frequency	0	=60, Daikin
<i>F821</i>	821	Parity	1	0; Daikin
<i>F851</i>	851	Inverter action at communication break	4	0
<i>F880</i>	880	Free notes	0	321

Table 48: VFD Parameter Settings

Code	Logical Address	Function Description	Default Value	Revised Value Rev -01
<i>RU1</i>	0	Automatic acceleration/deceleration	1	0
<i>FROd</i>	4	Frequency setting mode selection 1	1	4
<i>tYP</i>	7	Default setting	0	2
<i>ACC</i>	9	Acceleration time 1	10	20
<i>dEC</i>	10	Deceleration time 1	10	20
<i>FH</i>	11	Maximum frequency	50	60
<i>UL</i>	12	Upper limit frequency	50	60
<i>LL</i>	13	Lower limit frequency	0	29.9
<i>uL</i>	14	Base frequency 1	50	60
<i>uLu</i>	409	Base frequency voltage 1	—	208, 230, 460
<i>tHr</i>	600	Motor electronic thermal protection level in amperes. Adjust thr to the nominal current value which appears on the motor nameplate.	100	100
<i>Sr1</i>	18	Preset-speed operation frequency 1	15	30
<i>Sr2</i>	19	Preset-speed operation frequency 2	20	30
<i>Sr3</i>	20	Preset-speed operation frequency 3	25	30
<i>F111</i>	111	Input terminal selection1 (F)	2	56
<i>F112</i>	112	Input terminal selection 2 (R)	6	0
<i>F113</i>	113	Input terminal selection 3 (RST)	10	0
<i>F118</i>	118	Input terminal selection 8 (VIA)	7	0
<i>F130</i>	130	Output terminal selection 1A (RY-RC)	4	14
<i>F170</i>	170	Base frequency 2	50	60
<i>F202</i>	202	VIA input point 1 frequency	0	60
<i>F204</i>	204	VIA input point 2 frequency	50	60
<i>F213</i>	213	VIB input point 2 frequency	50	60
<i>F268</i>	268	Initial value of UP/DOWN frequency	0	30
<i>F300</i>	300	PWM carrier frequency	—	8
<i>F732</i>	732	Panel operation prohibition (Local/Remote keys)	0	1
<i>F800</i>	800	Communication band speed (RJ45)	1	1
<i>F801</i>	801	Parity (RJ45)	1	1
<i>F802</i>	802	Inverter number	1	5
<i>F803</i>	803	Communication error trip time	3	0
<i>F807</i>	807	Communication channel choice	1	1
<i>F820</i>	820	Communication band speed (screw terminal)	1	0
<i>F821</i>	821	Parity (screw terminal)	1	0
<i>F829</i>	829	Selection of communication protocol	0	1
<i>F851</i>	851	Inverter action at network & communication break	0	1
<i>F856</i>	856	Number of motor poles for communication speed calc	2	4

uL u (Base frequency voltage 1) is factory set to 230 or 460V and must be adjusted for 208V operation.

Controls by Others for SAF, RAF, and EAF Applications

⚠ WARNING

UNINTENDED EQUIPMENT OPERATION

- Modifying or changing parameters whose function is not described in this manual will affect drive controller operation. Some register changes will take effect as soon as they are entered.
- Do not modify or change parameters whose function is not described in this instruction bulletin.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

The MD2 has been made to Daikin’s specifications. However, Daikin assumes no responsibility for field installed controls. Commonly used control connections and switch positions are shown in Figure 26 and Figure 27. Table 49 lists parameters settings that are often used with analog control or often require field adjustment. The user or installer should consult the OEM vendor’s operation and maintenance manual for more details at www.us.schneider-electric.com.

Switch Settings

Switch Label	Switch Function	Proper Switch Position
SW 100	Voltage	Left
SW 101	Voltage	Right
SW 102	Source	Right

NOTE: To restore the MD2 drive to 60Hz Factory default setting you would first set parameter *P₄t* to 3, press enter followed by setting parameter *P₄t* to 2 and pressing enter again. The operation specific Daikin parameters would then need to be changed for proper unit operation.

The parameters listed above are used to factory test run the drive only. Additional parameter changes may be required to meet field application requirements.


NOTE: Remember to do this last!

When changing parameters the last parameter to save is “*t₄P*” After making the changes necessary go to *t₄P* and select “*S R U E*” #7 the drive will then save all the parameters, cycle power to the drive, you can re-apply power after the screen goes blank. When drive is up and running again cycle power to the entire unit. All parameters are saved and functional after the final power cycling.

Table 49: Parameter Settings

Code	Comm #	Function Description	Default Value	Daikin Value
<i>R U 1</i>	0	Automatic acceleration/deceleration	1	0
<i>F 0</i>	6	Meter Adjustment	0	318
<i>t₄P</i>	7	Default setting	0	2
<i>R C C</i>	9	Acceleration time 1	10	60
<i>d E C</i>	10	Deceleration time 1	10	60
<i>F H</i>	11	Maximum frequency	50	60
<i>U L</i>	12	Upper limit frequency	50	60
<i>L L</i>	13	Lower limit frequency	0	20
<i>u L</i>	14	Base frequency 1	50	60
<i>u L u</i>	409	Base frequency voltage 1	—	Daikin to set at Factory
<i>t H r</i>	600	Motor electronic-thermal protection level 1	100	Daikin to set at Factory
<i>F 1 0 8</i>	108	Second always active function	50	0
<i>F 1 1 1</i>	111	Input terminal selection 1 (F)	60	56
<i>F 1 1 2</i>	112	Input terminal selection 2 (R)	6	0

Figure 26: Typical Example of Controls by Others Wiring (Trip Stop)



NOTE: Contacts and wire terminations are in the unit control panel. Terminal numbers designations are not applicable to Vision, Skyline, and Destiny units.

Typical Example of programming (IN THIS ORDER)

- Set "t 4 P" = 3 (factory defaults)
- Set "t 4 P" = 2 (60Hz defaults)
- Set "R U 1" = 0 (analog control)
- Set "L L" = 20 (for a 20Hz minimum speed)
- Set "U L U" = motor nominal voltage
- Set "t H r" = motor FLA
- Set "O L" = 0
- Set "F 1 0 9" = 0 (VIA to be speed reference terminal)
- Set "F 1 1 1" = 56 (F terminal standby + forward run command)

Additional settings required for Trip Stop option

- Set "F 1 1 2" = 45 (inverse trip selection for terminal R)
- Set "F 1 1 3" = 10 (RES to clear trip stop at transition from ON to OFF)

Table 50 contains a list of drawings that reference the most current parameter settings for the MD-2 Drive.

Table 50: Parameter List Drawing Reference

Drawing Reference	Description	Application
170637000	CONTROL BY OTHERS	ROOF
170636***	MAVERICK II	MAVERICK
170636700	208V R410A SPEEDTROL	ROOF
170636800	230V R410A SPEEDTROL	ROOF
170636900	460V R410A SPEEDTROL	ROOF
170636300	MTIII, SAF	SWP/ROOF
170636400	MTIII, RAF/EXHAUST	ROOF
170636500	MTIII, ENG REC WHEEL	ROOF
170636600	MTIII, EVAP COND SPEEDTROL	ROOF

NOTE: Contact the Daikin Warranty Service Group to request the most current parameter list drawing.

One analog output is supplied with the drive controller. Terminal FM located on the bottom right terminal strip of the main unit control board is the analog output. FM is a multifunctional programmable analog output supplying an output frequency signal as the factory default.

The FM terminal can output a voltage or current signal:

- When the red switch 2 (SW2) is set to V (voltage), FM outputs a 0-10 VDC signal at 1 mA
- When SW2 is set to I (current), FM outputs a 0-20 mA signal up to 24 VDC

The specific type of signal that the FM terminal will output can be adjusted through parameter F_{n5L} . There are 19 different values that can be programmed through parameter F_{n5L} that effect what type of signal the FM terminal will output.

Scaling of the analog output through the FM terminal can be done in order to output a specific range of analog signal. The FM terminal will output a default 0-10 VDC signal if SW2 is set to V. The FM terminal will output a 0-20 mA signal if SW2 is set to I. In order to output any range other than the drive default, the following procedure must be carried out.

1. Set SW2 to the desired output, V (Voltage) or I (Current).
2. Change parameter F_{n5L} to either 15 or 17 depending on the desired output. For current output, select 15; for voltage output, select 17.
3. Go to parameter F_n on the VFD display. Press Enter. 100 should be displayed.
4. Disconnect all control wiring at terminal FM on the main unit control board.
5. With a digital multimeter measure the voltage or current at the FM terminal. For a voltage measurement, measure across FM and any common (CC) terminal.
6. Use the Up or Down keys to adjust the desired output range while measuring the value at the FM terminal with a digital multimeter. Notice that 100 is flashing on the display of the keypad even while voltage or current readings on the digital multimeter change.
7. Once the desired range has been set, press Enter on the drive keypad. F_n and 100 should flash back and forth on the screen. This means that the desired output value has been locked in or set within the drive controller.

8. Go back to parameter F_{n5L} on the drive display. Set it back to the desired type of output (output frequency, output current, etc.). Parameter F_n has an adjustable range of 1 – 1280 and is a unit less parameter. To find out what value was set at parameter F_n (to achieve the desired output) in steps 1 through 8, follow steps 9 through 11. This procedure is not necessary, but sometimes beneficial to record the actual value that was set at parameter F_n for future reference in case this parameter would happen to be changed, or set back to default at any point in the future.
9. Change parameter F_{n5L} to 19. This setting displays the set value at parameter F_n .
10. Go to parameter F_n on the VFD display. Press Enter. The true value that was locked or set at parameter F_n in steps 1 through 8 should be displayed.
11. Go back to parameter F_{n5L} on the drive display. Set it back to the desired type of output (output frequency, output torque, etc.).

Table 51: Analog Output Function Selection (Meter Selection)

Parameter	Factory Setting	Value	Function	Maximum Signal
Fn5L	0	0	Output frequency	Maximum frequency (FH)
		1	Output current	150% of drive controller's rated current
		2	Speed reference	Maximum frequency (FH)
		3	DC bus voltage	150% of drive controller's rated current
		4	Output motor voltage	150% of drive controller's rated current
		5	Input power	185% of drive controller's rated current
		6	Output power	185% of drive controller's rated current
		7	Estimated motor torque	250% of rated motor torque
		8	Motor torque current	Current at 250% of rated motor torque
		9	Motor thermal state	100% of motor's rating
		10	Drive controller thermal state	100%
		11	DO NOT USE	
		12	Internal speed reference (after PID)	Maximum frequency (FH)
		13	VIA input value	Maximum input value
		14	VIB input value	Maximum input value
		15	Fixed output – 100% signal (Selection 1 – output current)	
		16	Fixed output – 50% signal (Selection 1 – output current)	
		17	Fixed output – 100% signal (Selections 0, 2, 3, 4, 5, 6, 7, 8, 9, 10, 12, 13, 14, 18)	
		18	Serial communication data	FA51 = 1000
19	DO NOT USE			

MPS 30-35 VFD Compressor with MicroTech III Controls for Speedtrol Condenser Fan Control


WARNING

UNINTENDED EQUIPMENT OPERATION

- Modifying or changing parameters whose function is not described in this manual will affect drive controller operation. Some register changes will take effect as soon as they are entered.
- Do not modify or change parameters whose function is not described in this instruction bulletin.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

Figure 28: SpeedTrol Wiring Diagram for MPS 30–35



PT21 is a refrigerant pressure sensing transducer

R17 is a compressor interlocking relay

NOTE: Contacts and terminations are in the unit control panel.

Switch Settings

Switch Label	Switch Function	Proper Switch Position
SW 100	Voltage	Left
SW 101	Voltage	Right
SW 102	Source	Right

NOTE: To restore the MD2 drive to 60Hz Factory default setting you would first set parameter *P46* to *3*, press enter followed by setting parameter *P46* to *2* and pressing enter again. The operation specific Daikin parameters would then need to be changed for proper unit operation.

Parameter Settings:

The MD2 VFD has been made to Daikin specifications. All factory installed MD2 VFDs with MicroTech III controls are also factory configured and started. [Table 52](#) lists the parameters that have been specifically configured for Daikin or else may need owner adjustment as described in this manual.

- “VFD Default” settings are the vendor defaults.
- “Daikin Settings” are the recommended settings for Daikin units.
- No other parameters should be needed or adjusted.

NOTE: Remember to do this last!

When changing parameters the last parameter to save is “*EEP*”. After making the changes necessary go to *EEP* and select “*SAVE*” #7 the drive will then save all the parameters, cycle power to the drive, you can re-apply power after the screen goes blank. When drive is up and running again cycle power to the entire unit. All parameters are saved and functional after the final power cycling.

Table 52: Parameter Settings – MPS 30–35 VFD Compressor

Code	Description	Unit	Minimum Value	Maximum Value	Default Value	New Value	Logical Address	Decimal Address	Value to Enter
<i>RU1</i>	Automatic acceleration/deceleration	1	0	2	1	0	0	0	0
<i>RU4</i>	Automatic function setting	1	0	4	0	1	40	64	1
<i>CMD</i>	Command mode selection	1	0	2	0		3	3	
<i>FMD</i>	Frequency setting mode selection	1	1	5	1		4	4	
<i>FNSL</i>	Meter selection	1	0	19	0		5	5	
<i>FA</i>	Meter adjustment	1	1	1280	145		6	6	
<i>LYP</i>	Default setting	1	0	9	0	7	7	7	7
<i>Fr</i>	Forward/reverse run selection (Operation panel)	1	0	3	0	8	8		
<i>ACC</i>	Acceleration time 1	0.1sec	0,0	3200,0	10	5	9	9	50
<i>DEC</i>	Deceleration time 1	0.1sec	0,0	3200,0	10	30	10	16	300
<i>FH</i>	Maximum frequency	0.01Hz	30,00	200,00	50	60	11	17	6000
<i>UL</i>	Upper limit frequency	0.01Hz	0,50	80,00	50	60	12	18	6000
<i>LL</i>	Lower limit frequency	0.01Hz	0,00	60,00	0	23	13	19	2300
<i>uL</i>	Base frequency 1	0.01Hz	25,00	200,00	50	60	14	20	6000
<i>uLv</i>	Base frequency voltage 1	0.1V	50,0	660,0		208	409	1033	2080
<i>PE</i>	V/F control mode selection 1	1	0	6	1		15	21	
<i>ub</i>	Torque boost 1	0.10%	0,0	30,0			16	22	
<i>THR</i>	Motor electronic-thermal protection level 1	1%	10	100	100	100	600	1536	100
<i>ELN</i>	Electric-thermal protection characteristic selection	1	0	7	0	2	17	23	2
<i>sr1</i>	Preset-speed operation frequency 1	0.01Hz	0,00	60,00	15		18	24	
<i>sr2</i>	Preset-speed operation frequency 2	0.01Hz	0,00	60,00	20		19	25	
<i>sr3</i>	Preset-speed operation frequency 3	0.01Hz	0,00	60,00	25		20	32	
<i>sr4</i>	Preset-speed operation frequency 4	0.01Hz	0,00	60,00	30		21	33	
<i>sr5</i>	Preset-speed operation frequency 5	0.01Hz	0,00	60,00	35		22	34	
<i>sr6</i>	Preset-speed operation frequency 6	0.01Hz	0,00	60,00	40		23	35	
<i>sr7</i>	Preset-speed operation frequency 7	0.01Hz	0,00	60,00	45		24	36	
<i>F100</i>	Low-speed signal output frequency	0.01Hz	0,00	80,00	0		100	256	
<i>F101</i>	Speed reach setting frequency	0.01Hz	0,00	80,00	0		101	257	
<i>F102</i>	Speed reach detection band	0.01Hz	0,00	80,00	2.5		102	258	
<i>F108</i>	2nd always-active function selection	1	0	71	0		108	264	
<i>F109</i>	Analog/contact input function selection (VIA/VIB)	1	0	2	0		109	265	
<i>F110</i>	Always-active function selection	1	0	71	1	0	110	272	0
<i>F111</i>	Input terminal selection 1 (F)	1	0	71	2	56	111	273	56
<i>F112</i>	Input terminal selection 2 (R)	1	0	71	6	0	112	274	0
<i>F113</i>	Input terminal selection 3 (RST)	1	0	71	10	0	113	275	0
<i>F118</i>	Input terminal selection 8 (VIA)	1	0	71	7	0	118	280	0
<i>F130</i>	Output terminal selection 1A (RY-RC)	1	0	255	4	14	130	304	14
<i>F132</i>	Output terminal selection 3 (FL)	1	0	255	11	5	132	306	5
<i>F137</i>	Output terminal selection 1B (RY-RC)	1	0	255	255		137	311	
<i>F139</i>	Output terminal logic selection (RY-RC/OUT-NO)	1	0	1	0		139	313	
<i>F167</i>	Frequency command agreement detection range	0.01Hz	0,00	80,00	2.5		167	359	
<i>F170</i>	Base frequency 2	0.01Hz	25,00	200,00	50	60	170	368	6000
<i>F171</i>	Base frequency voltage 2	0.1V	50,0	660,0			171	369	
<i>F172</i>	Torque boost 2	0.10%	0,0	30,0			172	370	
<i>F173</i>	Motor electronic-thermal protection level 2	1%	10	100	100		173	371	
<i>F185</i>	Stall prevention level 2	1%	10	111	110		185	389	
<i>F200</i>	Frequency priority selection	1	0	1	0		200	512	
<i>F201</i>	VIA input point 1 setting	1%	0	100	0	10	201	513	10
<i>F202</i>	VIA input point 1 frequency	0.01Hz	0,00	200,00	0	23	202	514	2300
<i>F203</i>	VIA input point 2 setting	1%	0	100	100	50	203	515	50
<i>F204</i>	VIA input point 2 frequency	0.01Hz	0,00	200,00	50	60	204	516	6000
<i>F207</i>	Frequency setting mode selection 2	1	1	5	2		207	519	
<i>F210</i>	VIB input point 1 setting	1%	0	100	0		210	528	
<i>F211</i>	VIB input point 1 frequency	0.01Hz	0,00	200,00	0		211	529	
<i>F212</i>	VIB input point 2 setting	1%	0	100	100		212	530	
<i>F213</i>	VIB input point 2 frequency	0.01Hz	0,00	200,00	50	60	213	531	6000
<i>F240</i>	Starting frequency setting	0.01Hz	0,50	10,00	0.5	10	240	576	1000
<i>F241</i>	Operation starting frequency	0.01Hz	0,00	80,00	0		241	577	
<i>F242</i>	Operation starting frequency hysteresis	0.01Hz	0,00	80,00	0		242	578	
<i>F250</i>	DC braking starting frequency	0.01Hz	0,00	80,00	0		250	592	
<i>F251</i>	DC braking current	1%	0	100	50		251	593	

NOTE: Remember to do this last!

When changing parameters the last parameter to save is "*LYP*". After making the changes necessary go to *LYP* and select "*SRUE*" #7 the drive will then save all the parameters, cycle power to the drive, you can re-apply power after the screen goes blank. When drive is up and running again cycle power to the entire unit. All parameters are saved and functional after the final power cycling.

Code	Description	Unit	Minimum Value	Maximum Value	Default Value	New Value	Logical Address	Decimal Address	Value to Enter
F 252	DC braking time	0.1sec	0,0	20,0	1		252	594	
F 255	Time limit for lower-limit frequency operation	0.1sec	0,0	600,0	0		256	598	
F 264	Input from external contacts-UP response time	0.1sec	0,0	10,0	0.1		264	612	
F 265	Input from external contacts-UP frequency step width	0.01Hz	0,00	80,00	0.1		265	613	
F 266	Input from external contacts-DOWN response time	0.1sec	0,0	10,0	0.1		266	614	
F 267	Input from external contacts-DOWN frequency step width	0.01Hz	0,00	80,00	0.1		267	615	
F 268	Initial value of UP/DOWN frequency	0.01Hz	0,00	60,00	0		268	616	
F 269	Saving of changed value of UP/DOWN frequency	1	0	1	1		269	617	
F 270	Jump frequency 1	0.01Hz	0,00	80,00	0		270	624	
F 271	Jump width 1	0.01Hz	0,00	30,00	0		271	625	
F 272	Jump frequency 2	0.01Hz	0,00	80,00	0		272	626	
F 273	Jump width 2	0.01Hz	0,00	30,00	0		273	627	
F 274	Jump frequency 3	0.01Hz	0,00	80,00	0		274	628	
F 275	Jump width 3	0.01Hz	0,00	30,00	0		275	629	
F 294	Preset-speed operation frequency 15	0.01Hz	0,00	60,00	50		294	660	
F 295	Selection of bumpless	1	0	1	1		295	661	
F 300	PWM carrier frequency	0.1kHz	6,0	16,0		6	300	768	60
F 301	Auto-restart control selection	1	0	4	3		301	769	
F 302	Regeneration power ride-through control (Deceleration stop)	1	0	2	0		302	770	
F 303	Retry selection (number of times)	1	0	10	3		303	771	
F 305	Over-voltage limit operation (Slowdown stop mode selection)	1	0	3	2		305	773	
F 307	Supply voltage correction (limitation of output voltage)	1	0	3	3		307	775	
F 311	Reverse-run prohibition	1	0	2	1		311	785	
F 312	Random mode	1	0	1	0		312	786	
F 316	Carrier frequency control mode selection	1	0	3	1		316	790	
F 320	Drooping gain	1%	0	100	0		320	800	
F 323	Drooping insensitive torque band	1%	0	100	10		323	803	
F 359	PID control waiting time	1sec	0	2400	0		359	857	
F 360	PID control	1	0	2	0		360	864	
F 362	Proportional gain	0.01	0,01	100,00	0.3		362	866	
F 363	Integral gain	0.01	0,01	100,00	0.2		363	867	
F 366	Differential gain	0.01	0,00	2,55	0		366	870	
F 400	Auto-tuning	1	0	2	0		400	1024	
F 401	Slip frequency gain	1%	0	150	50		401	1025	
F 402	Motor constant #1 (primary resistance)	0.10%	0,0	30,0			402	1026	
F 415	Motor rated current	0.1A	0,1	200,0		13.7	415	1045	137
F 416	Motor no-load current	1%	10	100			416	1046	
F 417	Motor rated speed	1min-1	100	15000			417	1047	
F 418	Speed control response coefficient	1	1	150	40		418	1048	
F 419	Speed control stability coefficient	1	1	100	20		419	1049	
F 470	VIA bias	1	0	255	128		470	1136	
F 471	VIA gain	1	0	255	148		471	1137	
F 472	VIB bias	1	0	255	128		472	1138	
F 473	VIB gain	1	0	255	148		473	1139	
F 480	Exciting strengthening coefficient	1%	100	130	100		480	1152	
F 481	Factory adjustment 1	1	0	9999	0		481	1153	
F 482	Factory adjustment 2	1	0	9999	442		482	1154	
F 483	Factory adjustment 3	0.1	0,0	300,0	100		483	1155	
F 485	Stall cooperation gain at field weakening zone 1	1	10	250	100		485	1157	
F 492	Stall cooperation gain at field weakening zone 2	1	50	150	100		492	1170	
F 494	Motor adjustment factor	1	0	200			494	1172	
F 495	Maximum voltage adjustment factor	1%	90	120	104		495	1173	
F 496	Carrier change adjustment factor	0.1kHz	0,1	14,0	14	1	496	1174	10
F 500	Acceleration time 2	0.1sec	0,0	3200,0	20		500	1280	
F 501	Deceleration time 2	0.1sec	0,0	3200,0	20		501	1281	
F 502	Acceleration/deceleration 1 pattern	1	0	2	0		502	1282	
F 503	Acceleration/deceleration 2 pattern	1	0	2	0		503	1283	
F 504	Acceleration/deceleration selection (1/2/3)	1	1	2	1		504	1284	
F 505	Acceleration/deceleration 1 and 2 switching frequency	0.01Hz	0,00	60,00	0		505	1285	
F 506	S-pattern lower-limit adjustment amount	1%	0	50	10		506	1286	
F 507	S-pattern upper-limit adjustment amount	1%	0	50	10		507	1287	
F 601	Stall prevention level 1	1%	10	111	110		601	1537	
F 602	Inverter trip retention selection	1	0	1	0		602	1538	

NOTE: Remember to do this last!

When changing parameters the last parameter to save is "tYP". After making the changes necessary go to tYP and select "SAVE" #7 the drive will then save all the parameters, cycle power to the drive, you can re-apply power after the screen goes blank. When drive is up and running again cycle power to the entire unit. All parameters are saved and functional after the final power cycling.

Code	Description	Unit	Minimum Value	Maximum Value	Default Value	New Value	Logical Address	Decimal Address	Value to Enter
F603	Emergency stop selection	1	0	2	0		603	1539	
F604	Emergency DC braking time	0.1sec	0,0	20,0	1		604	1540	
F605	Output phase failure detection mode selection	1	0	5	3		605	1541	
F607	Motor 150%-overload time limit	1sec	10	2400	300		607	1543	
F608	Input phase failure detection mode selection	1	0	1	1		608	1544	
F609	Hysteresis for small current detection	1%	1	20	10		609	1545	
F610	Low current trip/alarm	1	0	1	0		610	1552	
F611	Small current detection current	1%	0	100	0		611	1553	
F612	Small current detection time	1sec	0	255	0		612	1554	
F613	Detection of output short-circuit during start-up	1	0	3	0		613	1555	
F615	Over-torque trip/alarm selection	1	0	1	0		615	1557	
F616	Over-torque detection level	1%	0	250	130		616	1558	
F618	Over-torque detection time	0.1sec	0,0	10,0	0.5		618	1560	
F619	Over-torque detection level hysteresis	1%	0	100	10		619	1561	
F621	Cumulative operation time alarm setting	0.1	0,0	999,9	610		621	1569	
F626	Over-voltage stall protection level	1%	100	150	140		626	1574	
F627	Under-voltage trip/alarm selection	1	0	2	0		627	1575	
F632	Thermal memory selection	1	0	1	0		632	1586	
F633	Trip at VIA low level input mode	1%	0	100	0		633	1587	
F634	Annual average ambient temperature (calculation for life alarms)	1	1	6	3		634	1588	
F645	Selection of PTC thermal	1	0	2	0		645	1605	
F646	Detection level of PTC	1ohm	100	9999	3000		646	1606	
F650	Rorced/Fire-speed control selection	1	0	1	0		650	1616	
F691	Inclination characteristic of analog output	1	0	1	1		691	1681	
F692	Meter bias	1%	0	100	0		692	1682	
F700	Prohibition of change of parameter settings	1	0	1	0		700	1792	
F701	Unit selection	1	0	1	1		701	1793	
F702	Free unit selection	0.01	0,00	200,00	0		702	1794	
F705	Inclination characteristic of free unit display	1	0	1	1		705	1797	
F706	Free unit display bias	0.01Hz	0,00	80,00	0		706	1798	
F707	Free step 1 (pressing a panel key once)	0.01Hz	0,00	80,00	0		707	1799	
F708	Free step 2 (panel display)	1	0	255	0		708	1800	
F710	Standard monitor display selection	1	0	10	0		710	1808	
F721	Panel stop pattern	1	0	1	0		721	1825	
F730	Prohibition of frequency setting on the operation panel (FC)	1	0	1	0		730	1840	
F732	Panel operation prohibition (Local/Remote keys)	1	0	1	0		732	1842	
F733	Panel operation prohibition (RUN/STOP keys)	1	0	1	0		733	1843	
F734	Prohibition of panel emergency stop operation	1	0	1	0		734	1844	
F735	Prohibition of panel reset operation	1	0	1	0		735	1845	
F738	Selection of AUF	1	0	1	0		738	1848	
F748	Selection of watt hour memory	1	0	1	1		748	1864	
F749	Display unit selection of watt hour	1	0	3	0		749	1865	
F800	Communication band speed	1	0	1	1		800	2048	
F801	Parity	1	0	2	1		801	2049	
F802	Inverter number	1	0	247	1		802	2050	
F803	Communication error trip time	1sec	0	100	3		803	2051	
F805	Communication waiting time	0.01sec	0,00	2,00	1		805	2053	
F806	Setting of master and slave for communication between inverters	1	0	4	4		806	2054	
F807	Communication Channel Choice	1	0	1	1		807	2055	
F811	Communication input point 1 setting	1%	0	100	2		811	2065	
F812	Communication input point 1 frequency	0.01Hz	0,00	200,00	0		812	2066	
F813	Communication input point 2 setting	1%	0	100	0		813	2067	
F814	Communication input point 2 frequency	0.01Hz	0,00	200,00	0		814	2068	
F820	Communication band speed (screw terminal)	1	0	1	1		820	2080	
F821	Parity (screw terminal)	1	0	2	1	0	821	2081	0
F829	Selection of communication protocol	1	0	4	0		829	2089	
F851	Inverter action at network & communication break	1	0	4	0		851	2129	
F856	Number of motor poles for communication speed calculation	1	1	8	0		856	2134	
F870	Block write data 1	1	0	6	0		870	2160	
F871	Block write data 2	1	0	6	0		871	2161	
F875	Block read data 1	1	0	11	0		875	2165	

NOTE: Remember to do this last!

When changing parameters the last parameter to save is "L Y P". After making the changes necessary go to L Y P and select "S R E" #7 the drive will then save all the parameters, cycle power to the drive, you can re-apply power after the screen goes blank. When drive is up and running again cycle power to the entire unit. All parameters are saved and functional after the final power cycling.

Code	Description	Unit	Minimum Value	Maximum Value	Default Value	New Value	Logical Address	Decimal Address	Value to Enter
F876	Block read data 2	1	0	11	0		876	2166	
F877	Block read data 3	1	0	11	0		877	2167	
F878	Block read data 4	1	0	11	0		878	2168	
F879	Block read data 5	1	0	11	0		879	2169	
F880	Free notes	1	0	65535	0	119	880	2176	119
F890	Parameter for option 1	1	0	65535	0		890	2192	
F891	Parameter for option 2	1	0	65535	0		891	2193	
F892	Parameter for option 3	1	0	65535	0		892	2194	
F893	Parameter for option 4	1	0	65535	0		893	2195	
F894	Parameter for option 5	1	0	65535	0		894	2196	
F895	Parameter for option 6	1	0	65535	0		895	2197	
F896	Parameter for option 7	1	0	65535	0		896	2198	
F897	Parameter for option 8	1	0	65535	0		897	2199	
F898	Parameter for option 9	1	0	65535	0		898	2200	
F899	Parameter for option 10	1	0	65535	0		899	2201	
F910	Step-out detection current level (for PM motors)	1%	10	150	100		910	2320	
F911	Step-out detection time (for PM motors)	0.1sec	0,0	25,0	0,0		911	2321	
F912	q-axis self-inductance (for PM)	0.01mH	0,00	650,00	0,00		912	2322	

NOTE: Remember to do this last!

When changing parameters the last parameter to save is “*tYP*” After making the changes necessary go to *tYP* and select “*SRU*” #7 the drive will then save all the parameters, cycle power to the drive, you can re-apply power after the screen goes blank. When drive is up and running again cycle power to the entire unit. All parameters are saved and functional after the final power cycling.

MPS 40–50 VFD Compressor with MicroTech III Controls for Speedtrol Condenser Fan Control


WARNING

UNINTENDED EQUIPMENT OPERATION

- Modifying or changing parameters whose function is not described in this manual will affect drive controller operation. Some register changes will take effect as soon as they are entered.
- Do not modify or change parameters whose function is not described in this instruction bulletin.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

Figure 29: SpeedTrol Wiring Diagram for MPS 40–50



PT11 is a refrigerant pressure sensing transducer

R38 is a compressor interlocking relay

NOTE: Contacts and terminations are in the unit control panel.

Switch Settings

Switch Label	Switch Function	Proper Switch Position
SW 100	Voltage	Left
SW 101	Voltage	Right
SW 102	Source	Right

NOTE: To restore the MD2 drive to 60Hz Factory default setting you would first set parameter *P46* to 3, press enter followed by setting parameter *P46* to 2 and pressing enter again. The operation specific Daikin parameters would then need to be changed for proper unit operation.

Parameter Settings:

The MD2 VFD has been made to Daikin specifications. All factory installed MD2 VFDs with MicroTech III controls are also factory configured and started. Table 53 lists the parameters that have been specifically configured for Daikin or else may need owner adjustment as described in this manual.

- “VFD Default” settings are the vendor defaults.
- “Daikin Settings” are the recommended settings for Daikin units.
- No other parameters should be needed or adjusted.

NOTE: Remember to do this last!

When changing parameters the last parameter to save is “*EEP*”. After making the changes necessary go to *EEP* and select “*SAVE*” #7 the drive will then save all the parameters, cycle power to the drive, you can re-apply power after the screen goes blank. When drive is up and running again cycle power to the entire unit. All parameters are saved and functional after the final power cycling.

Table 53: Parameter Settings – MPS 40–50 VFD Compressor

Code	Description	Unit	Minimum Value	Maximum Value	Default Value	New Value	Logical Address
<i>RU1</i>	Automatic acceleration/deceleration	1	0	2	1	0	0
<i>RU4</i>	Automatic function setting	1	0	4	0	1	40
<i>CMD</i>	Command mode selection	1	0	2	0		3
<i>FMD</i>	Frequency setting mode selection 1	1	1	5	1		4
<i>FMSL</i>	Meter selection	1	0	19	0		5
<i>FA</i>	Meter adjustment	1	1	1280	145		6
<i>LYP</i>	Default setting	1	0	9	0	7	7
<i>FR</i>	Forward/reverse run selection (Operation panel)	1	0	3	0		8
<i>ACC</i>	Acceleration time 1	0.1sec	0,0	3200,0	10	5	9
<i>DEC</i>	Deceleration time 1	0.1sec	0,0	3200,0	10	30	10
<i>FH</i>	Maximum frequency	0.01Hz	30,00	200,00	50	60	11
<i>UL</i>	Upper limit frequency	0.01Hz	0,50	80,00	50	60	12
<i>LL</i>	Lower limit frequency	0.01Hz	0,00	60,00	0	10	13
<i>uL</i>	Base frequency 1	0.01Hz	25,00	200,00	50	60	14
<i>uL u</i>	Base frequency voltage 1	0.1V	50,0	660,0		208	409
<i>Pt</i>	V/F control mode selection 1	1	0	6	1		15
<i>ub</i>	Torque boost 1	0.10%	0,0	30,0			16
<i>THR</i>	Motor electronic-thermal protection level 1	1%	10	100	100	100	600
<i>DLN</i>	Electric-thermal protection characteristic selection	1	0	7	0	2	17
<i>Sr1</i>	Preset-speed operation frequency 1	0.01Hz	0,00	60,00	15		18
<i>Sr2</i>	Preset-speed operation frequency 2	0.01Hz	0,00	60,00	20		19
<i>Sr3</i>	Preset-speed operation frequency 3	0.01Hz	0,00	60,00	25		20
<i>Sr4</i>	Preset-speed operation frequency 4	0.01Hz	0,00	60,00	30		21
<i>Sr5</i>	Preset-speed operation frequency 5	0.01Hz	0,00	60,00	35		22
<i>Sr6</i>	Preset-speed operation frequency 6	0.01Hz	0,00	60,00	40		23
<i>Sr7</i>	Preset-speed operation frequency 7	0.01Hz	0,00	60,00	45		24
<i>F100</i>	Low-speed signal output frequency	0.01Hz	0,00	80,00	0		100
<i>F101</i>	Speed reach setting frequency	0.01Hz	0,00	80,00	0		101
<i>F102</i>	Speed reach detection band	0.01Hz	0,00	80,00	2.5		102
<i>F108</i>	2nd always-active function selection	1	0	71	0		108
<i>F109</i>	Analog/contact input function selection (VIA/VIB)	1	0	2	0		109
<i>F110</i>	Always-active function selection	1	0	71	1	0	110
<i>F111</i>	Input terminal selection1 (F)	1	0	71	2	56	111
<i>F112</i>	Input terminal selection 2 (R)	1	0	71	6	0	112
<i>F113</i>	Input terminal selection 3 (RST)	1	0	71	10	0	113
<i>F118</i>	Input terminal selection 8 (VIA)	1	0	71	7	0	118
<i>F130</i>	Output terminal selection 1A (RY-RC)	1	0	255	4	14	130
<i>F132</i>	Output terminal selection 3 (FL)	1	0	255	11	5	132
<i>F137</i>	Output terminal selection 1B (RY-RC)	1	0	255	255		137
<i>F139</i>	Output terminal logic selection (RY-RC/OUT-NO)	1	0	1	0		139
<i>F167</i>	Frequency command agreement detection range	0.01Hz	0,00	80,00	2.5		167
<i>F170</i>	Base frequency 2	0.01Hz	25,00	200,00	50	60	170
<i>F171</i>	Base frequency voltage 2	0.1V	50,0	660,0			171
<i>F172</i>	Torque boost 2	0.10%	0,0	30,0			172
<i>F173</i>	Motor electronic-thermal protection level 2	1%	10	100	100		173
<i>F185</i>	Stall prevention level 2	1%	10	111	110		185
<i>F200</i>	Frequency priority selection	1	0	1	0		200
<i>F201</i>	VIA input point 1 setting	1%	0	100	0	10	201
<i>F202</i>	VIA input point 1 frequency	0.01Hz	0,00	200,00	0	10	202
<i>F203</i>	VIA input point 2 setting	1%	0	100	100	50	203
<i>F204</i>	VIA input point 2 frequency	0.01Hz	0,00	200,00	50	60	204
<i>F207</i>	Frequency setting mode selection 2	1	1	5	2		207
<i>F210</i>	VIB input point 1 setting	1%	0	100	0		210
<i>F211</i>	VIB input point 1 frequency	0.01Hz	0,00	200,00	0		211
<i>F212</i>	VIB input point 2 setting	1%	0	100	100		212

NOTE: Remember to do this last!

When changing parameters the last parameter to save is “LYP” After making the changes necessary go to LYP and select “SRU” #7 the drive will then save all the parameters, cycle power to the drive, you can re-apply power after the screen goes blank. When drive is up and running again cycle power to the entire unit. All parameters are saved and functional after the final power cycling.

Code	Description	Unit	Minimum Value	Maximum Value	Default Value	New Value	Logical Address
F213	VIB input point 2 frequency	0.01Hz	0,00	200,00	50	60	213
F240	Starting frequency setting	0.01Hz	0,50	10,00	0.5	10	240
F241	Operation starting frequency	0.01Hz	0,00	80,00	0	15	241
F242	Operation starting frequency hysteresis	0.01Hz	0,00	80,00	0	5	242
F250	DC braking starting frequency	0.01Hz	0,00	80,00	0		250
F251	DC braking current	1%	0	100	50		251
F252	DC braking time	0.1sec	0,0	20,0	1		252
F256	Time limit for lower-limit frequency operation	0.1sec	0,0	600,0	0		256
F264	Input from external contacts-UP response time	0.1sec	0,0	10,0	0.1		264
F265	Input from external contacts-UP frequency step width	0.01Hz	0,00	80,00	0.1		265
F266	Input from external contacts-DOWN response time	0.1sec	0,0	10,0	0.1		266
F267	Input from external contacts-DOWN frequency step width	0.01Hz	0,00	80,00	0.1		267
F268	Initial value of UP/DOWN frequency	0.01Hz	0,00	60,00	0		268
F269	Saving of changed value of UP/DOWN frequency	1	0	1	1		269
F270	Jump frequency 1	0.01Hz	0,00	80,00	0		270
F271	Jump width 1	0.01Hz	0,00	30,00	0		271
F272	Jump frequency 2	0.01Hz	0,00	80,00	0		272
F273	Jump width 2	0.01Hz	0,00	30,00	0		273
F274	Jump frequency 3	0.01Hz	0,00	80,00	0		274
F275	Jump width 3	0.01Hz	0,00	30,00	0		275
F294	Preset-speed operation frequency 15	0.01Hz	0,00	60,00	50		294
F295	Selection of bumpless	1	0	1	1		295
F300	PWM carrier frequency	0.1kHz	6,0	16,0		6	300
F301	Auto-restart control selection	1	0	4	3		301
F302	Regeneration power ride-through control (Deceleration stop)	1	0	2	0		302
F303	Retry selection (number of times)	1	0	10	3		303
F305	Over-voltage limit operation (Slowdown stop mode selection)	1	0	3	2		305
F307	Supply voltage correction (limitation of output voltage)	1	0	3	3		307
F311	Reverse-run prohibition	1	0	2	1		311
F312	Random mode	1	0	1	0		312
F316	Carrier frequency control mode selection	1	0	3	1		316
F320	Drooping gain	1%	0	100	0		320
F323	Drooping insensitive torque band	1%	0	100	10		323
F359	PID control waiting time	1sec	0	2400	0		359
F360	PID control	1	0	2	0		360
F362	Proportional gain	0.01	0,01	100,00	0.3		362
F363	Integral gain	0.01	0,01	100,00	0.2		363
F366	Differential gain	0.01	0,00	2,55	0		366
F400	Auto-tuning	1	0	2	0		400
F401	Slip frequency gain	1%	0	150	50		401
F402	Motor constant #1 (primary resistance)	0.10%	0,0	30,0			402
F415	Motor rated current	0.1A	0,1	200,0		4.6	415
F416	Motor no-load current	1%	10	100			416
F417	Motor rated speed	1min-1	100	15000			417
F418	Speed control response coefficient	1	1	150	40		418
F419	Speed control stability coefficient	1	1	100	20		419
F470	VIA bias	1	0	255	128		470
F471	VIA gain	1	0	255	148		471
F472	VIB bias	1	0	255	128		472
F473	VIB gain	1	0	255	148		473
F480	Exciting strengthening coefficient	1%	100	130	100		480
F481	Factory adjustment 1	1	0	9999	0		481

NOTE: Remember to do this last!

When changing parameters the last parameter to save is “*ε* *YP*”. After making the changes necessary go to *ε* *YP* and select “*S R U E*” #7 the drive will then save all the parameters, cycle power to the drive, you can re-apply power after the screen goes blank. When drive is up and running again cycle power to the entire unit. All parameters are saved and functional after the final power cycling.

Code	Description	Unit	Minimum Value	Maximum Value	Default Value	New Value	Logical Address
F 482	Factory adjustment 2	1	0	9999	442		482
F 483	Factory adjustment 3	0.1	0,0	300,0	100		483
F 485	Stall cooperation gain at field weakening zone 1	1	10	250	100		485
F 492	Stall cooperation gain at field weakening zone 2	1	50	150	100		492
F 494	Motor adjustment factor	1	0	200			494
F 495	Maximum voltage adjustment factor	1%	90	120	104		495
F 496	Carrier change adjustment factor	0.1kHz	0,1	14,0	14	1	496
F 500	Acceleration time 2	0.1sec	0,0	3200,0	20		500
F 501	Deceleration time 2	0.1sec	0,0	3200,0	20		501
F 502	Acceleration/deceleration 1 pattern	1	0	2	0		502
F 503	Acceleration/deceleration 2 pattern	1	0	2	0		503
F 504	Acceleration/deceleration selection (1/2/3)	1	1	2	1		504
F 505	Acceleration/deceleration 1 and 2 switching frequency	0.01Hz	0,00	60,00	0		505
F 506	S-pattern lower-limit adjustment amount	1%	0	50	10		506
F 507	S-pattern upper-limit adjustment amount	1%	0	50	10		507
F 601	Stall prevention level 1	1%	10	111	110		601
F 602	Inverter trip retention selection	1	0	1	0		602
F 603	Emergency stop selection	1	0	2	0		603
F 604	Emergency DC braking time	0.1sec	0,0	20,0	1		604
F 605	Output phase failure detection mode selection	1	0	5	3		605
F 607	Motor 150%-overload time limit	1sec	10	2400	300		607
F 608	Input phase failure detection mode selection	1	0	1	1		608
F 609	Hysteresis for small current detection	1%	1	20	10		609
F 610	Low current trip/alarm	1	0	1	0		610
F 611	Small current detection current	1%	0	100	0		611
F 612	Small current detection time	1sec	0	255	0		612
F 613	Detection of output short-circuit during start-up	1	0	3	0		613
F 615	Over-torque trip/alarm selection	1	0	1	0		615
F 616	Over-torque detection level	1%	0	250	130		616
F 618	Over-torque detection time	0.1sec	0,0	10,0	0.5		618
F 619	Over-torque detection level hysteresis	1%	0	100	10		619
F 621	Cumulative operation time alarm setting	0.1	0,0	999,9	610		621
F 626	Over-voltage stall protection level	1%	100	150	140		626
F 627	Under-voltage trip/alarm selection	1	0	2	0		627
F 632	Thermal memory selection	1	0	1	0		632
F 633	Trip at VIA low level input mode	1%	0	100	0		633
F 634	Annual average ambient temperature (calculation for life alarms)	1	1	6	3		634
F 645	Selection of PTC thermal	1	0	2	0		645
F 646	Detection level of PTC	1ohm	100	9999	3000		646
F 650	Rorced/Fire-speed control selection	1	0	1	0		650
F 691	Inclination characteristic of analog output	1	0	1	1		691
F 692	Meter bias	1%	0	100	0		692
F 700	Prohibition of change of parameter settings	1	0	1	0		700
F 701	Unit selection	1	0	1	1		701
F 702	Free unit selection	0.01	0,00	200,00	0		702
F 705	Inclination characteristic of free unit display	1	0	1	1		705
F 706	Free unit display bias	0.01Hz	0,00	80,00	0		706
F 707	Free step 1 (pressing a panel key once)	0.01Hz	0,00	80,00	0		707
F 708	Free step 2 (panel display)	1	0	255	0		708
F 710	Standard monitor display selection	1	0	10	0		710
F 721	Panel stop pattern	1	0	1	0		721
F 730	Prohibition of frequency setting on the operation panel (FC)	1	0	1	0		730
F 732	Panel operation prohibition (Local/Remote keys)	1	0	1	0		732
F 733	Panel operation prohibition (RUN/STOP keys)	1	0	1	0		733
F 734	Prohibition of panel emergency stop operation	1	0	1	0		734

NOTE: Remember to do this last!

When changing parameters the last parameter to save is “*ƒ Ƴ P*” After making the changes necessary go to *ƒ Ƴ P* and select “*5 R U E*” #7 the drive will then save all the parameters, cycle power to the drive, you can re-apply power after the screen goes blank. When drive is up and running again cycle power to the entire unit. All parameters are saved and functional after the final power cycling.

Code	Description	Unit	Minimum Value	Maximum Value	Default Value	New Value	Logical Address
F735	Prohibition of panel reset operation	1	0	1	0		735
F738	Selection of AUF	1	0	1	0		738
F748	Selection of watt hour memory	1	0	1	1		748
F749	Display unit selection of watt hour	1	0	3	0		749
F800	Communication band speed	1	0	1	1		800
F801	Parity	1	0	2	1		801
F802	Inverter number	1	0	247	1		802
F803	Communication error trip time	1sec	0	100	3		803
F805	Communication waiting time	0.01sec	0,00	2,00	1		805
F806	Setting of master and slave for communication between inverters	1	0	4	4		806
F807	Communication Channel Choice	1	0	1	1		807
F811	Communication input point 1 setting	1%	0	100	2		811
F812	Communication input point 1 frequency	0.01Hz	0,00	200,00	0		812
F813	Communication input point 2 setting	1%	0	100	0		813
F814	Communication input point 2 frequency	0.01Hz	0,00	200,00	0		814
F820	Communication band speed (screw terminal)	1	0	1	1		820
F821	Parity (screw terminal)	1	0	2	1	0	821
F829	Selection of communication protocol	1	0	4	0		829
F851	Inverter action at network & communication break	1	0	4	0		851
F856	Number of motor poles for communication speed calculation	1	1	8	0		856
F870	Block write data 1	1	0	6	0		870
F870	Block write data 2	1	0	6	0		871
F875	Block read data 1	1	0	11	0		875
F876	Block read data 2	1	0	11	0		876
F877	Block read data 3	1	0	11	0		877
F878	Block read data 4	1	0	11	0		878
F879	Block read data 5	1	0	11	0		879
F880	Free notes	1	0	65535	0	119	880
F890	Parameter for option 1	1	0	65535	0		890
F891	Parameter for option 2	1	0	65535	0		891
F892	Parameter for option 3	1	0	65535	0		892
F893	Parameter for option 4	1	0	65535	0		893
F894	Parameter for option 5	1	0	65535	0		894
F895	Parameter for option 6	1	0	65535	0		895
F896	Parameter for option 7	1	0	65535	0		896
F897	Parameter for option 8	1	0	65535	0		897
F898	Parameter for option 9	1	0	65535	0		898
F899	Parameter for option 10	1	0	65535	0		899
F910	Step-out detection current level (for PM motors)	1%	10	150	100		910
F911	Step-out detection time (for PM motors)	0.1sec	0,0	25,0	0,0		911
F912	q-axis self-inductance (for PM)	0.01mH	0,00	650,00	0,00		912

NOTE: Remember to do this last!

When changing parameters the last parameter to save is "LSP". After making the changes necessary go to LSP and select "SAVE" #7 the drive will then save all the parameters, cycle power to the drive, you can re-apply power after the screen goes blank. When drive is up and running again cycle power to the entire unit. All parameters are saved and functional after the final power cycling.

Digital Compressor with MicroTech III Controls for Speedtrol Condenser Fan Control

WARNING

UNINTENDED EQUIPMENT OPERATION


- Modifying or changing parameters whose function is not described in this manual will affect drive controller operation. Some register changes will take effect as soon as they are entered.
- Do not modify or change parameters whose function is not described in this instruction bulletin.

Failure to follow this instruction can result in death, serious injury, or equipment damage.

Figure 30: SpeedTrol Wiring Diagram for Digital Compressors

PT 21 is a refrigerant pressure transducer, the speed signal is transmitted out of the digital controller to the VFD.

R17 is the enable relay for circuit 2



NOTE: Contacts and terminations are in the unit control panel.

Switch Settings

Switch Label	Switch Function	Proper Switch Position
SW 100	Voltage	Left
SW 101	Voltage	Right
SW 102	Source	Right

Parameter Settings:

The MD2 VFD has been made to Daikin specifications. All factory installed MD2 VFDs with MicroTech III controls are also factory configured and started. [Table 53](#) lists the parameters that have been specifically configured for Daikin or else may need owner adjustment as described in this manual.

- “VFD Default” settings are the vendor defaults.
- “Daikin Settings” are the recommended settings for Daikin units.
- No other parameters should be needed or adjusted.

NOTE: To restore the MD2 drive to 60Hz Factory default setting you would first set parameter *P4t* to 3, press enter followed by setting parameter *P4t* to 2 and pressing enter again. The operation specific Daikin parameters would then need to be changed for proper unit operation.

NOTE: Remember to do this last!

When changing parameters the last parameter to save is “*tYP*”. After making the changes necessary go to *tYP* and select “*SAVE*” #7 the drive will then save all the parameters, cycle power to the drive, you can re-apply power after the screen goes blank. When drive is up and running again cycle power to the entire unit. All parameters are saved and functional after the final power cycling.

Table 54: Parameter Settings – Digital Compressor

Code	Description	Unit	Minimum Value	Maximum Value	Default Value	New Value	Logical Address
RU1	Automatic acceleration/deceleration	1	0	2	1	0	0
RU4	Automatic function setting	1	0	4	0	1	40
ENQd	Command mode selection	1	0	2	0		3
FNDd	Frequency setting mode selection 1	1	1	5	1		4
FNSL	Meter selection	1	0	19	0		5
FN	Meter adjustment	1	1	1280	145		6
LYP	Default setting	1	0	9	0	7	7
Fr	Forward/reverse run selection (Operation panel)	1	0	3	0		8
RLL	Acceleration time 1	0.1sec	0,0	3200,0	10	5	9
dEL	Deceleration time 1	0.1sec	0,0	3200,0	10	30	10
FH	Maximum frequency	0.01Hz	30,00	200,00	50	60	11
UL	Upper limit frequency	0.01Hz	0,50	80,00	50	60	12
LL	Lower limit frequency	0.01Hz	0,00	60,00	0	10	13
uL	Base frequency 1	0.01Hz	25,00	200,00	50	60	14
uLv	Base frequency voltage 1	0.1V	50,0	660,0		460	409
Pt	V/F control mode selection 1	1	0	6	1		15
ub	Torque boost 1	0.10%	0,0	30,0			16
tHr	Motor electronic-thermal protection level 1	1%	10	100	100	100	600
QLN	Electric-thermal protection characteristic selection	1	0	7	0	2	17
5r1	Preset-speed operation frequency 1	0.01Hz	0,00	60,00	15		18
5r2	Preset-speed operation frequency 2	0.01Hz	0,00	60,00	20		19
5r3	Preset-speed operation frequency 3	0.01Hz	0,00	60,00	25		20
5r4	Preset-speed operation frequency 4	0.01Hz	0,00	60,00	30		21
5r5	Preset-speed operation frequency 5	0.01Hz	0,00	60,00	35		22
5r6	Preset-speed operation frequency 6	0.01Hz	0,00	60,00	40		23
5r7	Preset-speed operation frequency 7	0.01Hz	0,00	60,00	45		24
F100	Low-speed signal output frequency	0.01Hz	0,00	80,00	0		100
F101	Speed reach setting frequency	0.01Hz	0,00	80,00	0		101
F102	Speed reach detection band	0.01Hz	0,00	80,00	2.5		102
F108	2nd always-active function selection	1	0	71	0		108
F109	Analog/contact input function selection (VIA/VIB)	1	0	2	0		109
F110	Always-active function selection	1	0	71	1	0	110
F111	Input terminal selection1 (F)	1	0	71	2	56	111
F112	Input terminal selection 2 (R)	1	0	71	6	0	112
F113	Input terminal selection 3 (RST)	1	0	71	10	0	113
F118	Input terminal selection 8 (VIA)	1	0	71	7	0	118
F130	Output terminal selection 1A (RY-RC)	1	0	255	4	14	130
F132	Output terminal selection 3 (FL)	1	0	255	11	5	132
F137	Output terminal selection 1B (RY-RC)	1	0	255	255		137
F139	Output terminal logic selection (RY-RC/OUT-NO)	1	0	1	0		139
F167	Frequency command agreement detection range	0.01Hz	0,00	80,00	2.5		167
F170	Base frequency 2	0.01Hz	25,00	200,00	50	60	170
F171	Base frequency voltage 2	0.1V	50,0	660,0			171
F172	Torque boost 2	0.10%	0,0	30,0		5	172
F173	Motor electronic-thermal protection level 2	1%	10	100	100		173
F185	Stall prevention level 2	1%	10	111	110		185
F200	Frequency priority selection	1	0	1	0		200
F201	VIA input point 1 setting	1%	0	100	0	15	201
F202	VIA input point 1 frequency	0.01Hz	0,00	200,00	0	10	202
F203	VIA input point 2 setting	1%	0	100	100	28	203
F204	VIA input point 2 frequency	0.01Hz	0,00	200,00	50	60	204
F207	Frequency setting mode selection 2	1	1	5	2		207
F210	VIB input point 1 setting	1%	0	100	0		210
F211	VIB input point 1 frequency	0.01Hz	0,00	200,00	0		211
F212	VIB input point 2 setting	1%	0	100	100		212
F213	VIB input point 2 frequency	0.01Hz	0,00	200,00	50	60	213
F240	Starting frequency setting	0.01Hz	0,50	10,00	0.5	10	240
F241	Operation starting frequency	0.01Hz	0,00	80,00	0	15	241
F242	Operation starting frequency hysteresis	0.01Hz	0,00	80,00	0	5	242
F250	DC braking starting frequency	0.01Hz	0,00	80,00	0		250
F251	DC braking current	1%	0	100	50		251

NOTE: Remember to do this last!

When changing parameters the last parameter to save is "LYP". After making the changes necessary go to LYP and select "5RLN" #7 the drive will then save all the parameters, cycle power to the drive, you can re-apply power after the screen goes blank. When drive is up and running again cycle power to the entire unit. All parameters are saved and functional after the final power cycling.

Code	Description	Unit	Minimum Value	Maximum Value	Default Value	New Value	Logical Address
F 2 5 2	DC braking time	0.1sec	0,0	20,0	1		252
F 2 5 6	Time limit for lower-limit frequency operation	0.1sec	0,0	600,0	0		256
F 2 6 4	Input from external contacts-UP response time	0.1sec	0,0	10,0	0.1		264
F 2 6 5	Input from external contacts-UP frequency step width	0.01Hz	0,00	80,00	0.1		265
F 2 6 6	Input from external contacts-DOWN response time	0.1sec	0,0	10,0	0.1		266
F 2 6 7	Input from external contacts-DOWN frequency step width	0.01Hz	0,00	80,00	0.1		267
F 2 6 8	Initial value of UP/DOWN frequency	0.01Hz	0,00	60,00	0		268
F 2 6 9	Saving of changed value of UP/DOWN frequency	1	0	1	1		269
F 2 7 0	Jump frequency 1	0.01Hz	0,00	80,00	0		270
F 2 7 1	Jump width 1	0.01Hz	0,00	30,00	0		271
F 2 7 2	Jump frequency 2	0.01Hz	0,00	80,00	0		272
F 2 7 3	Jump width 2	0.01Hz	0,00	30,00	0		273
F 2 7 4	Jump frequency 3	0.01Hz	0,00	80,00	0		274
F 2 7 5	Jump width 3	0.01Hz	0,00	30,00	0		275
F 2 9 4	Preset-speed operation frequency 15	0.01Hz	0,00	60,00	50		294
F 2 9 5	Selection of bumpless	1	0	1	1		295
F 3 0 0	PWM carrier frequency	0.1kHz	6,0	16,0		6	300
F 3 0 1	Auto-restart control selection	1	0	4	3		301
F 3 0 2	Regeneration power ride-through control (Deceleration stop)	1	0	2	0		302
F 3 0 3	Retry selection (number of times)	1	0	10	3		303
F 3 0 5	Over-voltage limit operation (Slowdown stop mode selection)	1	0	3	2		305
F 3 0 7	Supply voltage correction (limitation of output voltage)	1	0	3	3		307
F 3 1 1	Reverse-run prohibition	1	0	2	1		311
F 3 1 2	Random mode	1	0	1	0		312
F 3 1 6	Carrier frequency control mode selection	1	0	3	1		316
F 3 2 0	Drooping gain	1%	0	100	0		320
F 3 2 3	Drooping insensitive torque band	1%	0	100	10		323
F 3 5 9	PID control waiting time	1sec	0	2400	0		359
F 3 6 0	PID control	1	0	2	0		360
F 3 6 2	Proportional gain	0.01	0,01	100,00	0.3		362
F 3 6 3	Integral gain	0.01	0,01	100,00	0.2		363
F 3 6 6	Differential gain	0.01	0,00	2,55	0		366
F 4 0 0	Auto-tuning	1	0	2	0		400
F 4 0 1	Slip frequency gain	1%	0	150	50		401
F 4 0 2	Motor constant #1 (primary resistance)	0.10%	0,0	30,0			402
F 4 1 5	Motor rated current	0.1A	0,1	200,0		5.1	415
F 4 1 6	Motor no-load current	1%	10	100			416
F 4 1 7	Motor rated speed	1min-1	100	15000			417
F 4 1 8	Speed control response coefficient	1	1	150	40		418
F 4 1 9	Speed control stability coefficient	1	1	100	20		419
F 4 7 0	VIA bias	1	0	255	128		470
F 4 7 1	VIA gain	1	0	255	148		471
F 4 7 2	VIB bias	1	0	255	128		472
F 4 7 3	VIB gain	1	0	255	148		473
F 4 8 0	Exciting strengthening coefficient	1%	100	130	100		480
F 4 8 1	Factory adjustment 1	1	0	9999	0		481
F 4 8 2	Factory adjustment 2	1	0	9999	442		482
F 4 8 3	Factory adjustment 3	0.1	0,0	300,0	100		483
F 4 8 5	Stall cooperation gain at field weakening zone 1	1	10	250	100		485
F 4 9 2	Stall cooperation gain at field weakening zone 2	1	50	150	100		492
F 4 9 4	Motor adjustment factor	1	0	200			494
F 4 9 5	Maximum voltage adjustment factor	1%	90	120	104		495
F 4 9 6	Carrier change adjustment factor	0.1kHz	0,1	14,0	14	1	496
F 5 0 0	Acceleration time 2	0.1sec	0,0	3200,0	20		500
F 5 0 1	Deceleration time 2	0.1sec	0,0	3200,0	20		501
F 5 0 2	Acceleration/deceleration 1 pattern	1	0	2	0		502
F 5 0 3	Acceleration/deceleration 2 pattern	1	0	2	0		503
F 5 0 4	Acceleration/deceleration selection (1/2/3)	1	1	2	1		504
F 5 0 5	Acceleration/deceleration 1 and 2 switching frequency	0.01Hz	0,00	60,00	0		505
F 5 0 6	S-pattern lower-limit adjustment amount	1%	0	50	10		506
F 5 0 7	S-pattern upper-limit adjustment amount	1%	0	50	10		507
F 5 0 1	Stall prevention level 1	1%	10	111	110		601
F 5 0 2	Inverter trip retention selection	1	0	1	0		602

NOTE: Remember to do this last!

When changing parameters the last parameter to save is "t Y P". After making the changes necessary go to t Y P and select "S R U E" #7 the drive will then save all the parameters, cycle power to the drive, you can re-apply power after the screen goes blank. When drive is up and running again cycle power to the entire unit. All parameters are saved and functional after the final power cycling.

Code	Description	Unit	Minimum Value	Maximum Value	Default Value	New Value	Logical Address
F 5 0 3	Emergency stop selection	1	0	2	0		603
F 5 0 4	Emergency DC braking time	0.1sec	0,0	20,0	1		604
F 5 0 5	Output phase failure detection mode selection	1	0	5	3		605
F 5 0 7	Motor 150%-overload time limit	1sec	10	2400	300	607	
F 5 0 8	Input phase failure detection mode selection	1	0	1	1		608
F 5 0 9	Hysteresis for small current detection	1%	1	20	10		609
F 5 1 0	Low current trip/alarm	1	0	1	0		610
F 5 1 1	Small current detection current	1%	0	100	0		611
F 5 1 2	Small current detection time	1sec	0	255	0		612
F 5 1 3	Detection of output short-circuit during start-up	1	0	3	0		613
F 5 1 5	Over-torque trip/alarm selection	1	0	1	0		615
F 5 1 6	Over-torque detection level	1%	0	250	130		616
F 5 1 8	Over-torque detection time	0.1sec	0,0	10,0	0.5		618
F 5 1 9	Over-torque detection level hysteresis	1%	0	100	10		619
F 5 2 1	Cumulative operation time alarm setting	0.1	0,0	999,9	610		621
F 5 2 6	Over-voltage stall protection level	1%	100	150	140		626
F 5 2 7	Under-voltage trip/alarm selection	1	0	2	0		627
F 5 3 2	Thermal memory selection	1	0	1	0		632
F 5 3 3	Trip at VIA low level input mode	1%	0	100	0		633
F 5 3 4	Annual average ambient temperature (calculation for life alarms)	1	1	6	3		634
F 5 4 5	Selection of PTC thermal	1	0	2	0		645
F 5 4 6	Detection level of PTC	1ohm	100	9999	3000		646
F 5 5 0	Rorced/Fire-speed control selection	1	0	1	0		650
F 5 9 1	Inclination characteristic of analog output	1	0	1	1		691
F 5 9 2	Meter bias	1%	0	100	0		692
F 7 0 0	Prohibition of change of parameter settings	1	0	1	0		700
F 7 0 1	Unit selection	1	0	1	1		701
F 7 0 2	Free unit selection	0.01	0,00	200,00	0		702
F 7 0 5	Inclination characteristic of free unit display	1	0	1	1		705
F 7 0 6	Free unit display bias	0.01Hz	0,00	80,00	0		706
F 7 0 7	Free step 1 (pressing a panel key once)	0.01Hz	0,00	80,00	0		707
F 7 0 8	Free step 2 (panel display)	1	0	255	0		708
F 7 1 0	Standard monitor display selection	1	0	10	0		710
F 7 2 1	Panel stop pattern	1	0	1	0		721
F 7 3 0	Prohibition of frequency setting on the operation panel (FC)	1	0	1	0		730
F 7 3 2	Panel operation prohibition (Local/Remote keys)	1	0	1	0		732
F 7 3 3	Panel operation prohibition (RUN/STOP keys)	1	0	1	0		733
F 7 3 4	Prohibition of panel emergency stop operation	1	0	1	0		734
F 7 3 5	Prohibition of panel reset operation	1	0	1	0		735
F 7 3 8	Selection of AUF	1	0	1	0		738
F 7 4 8	Selection of watt hour memory	1	0	1	1		748
F 7 4 9	Display unit selection of watt hour	1	0	3	0		749
F 8 0 0	Communication band speed	1	0	1	1		800
F 8 0 1	Parity	1	0	2	1		801
F 8 0 2	Inverter number	1	0	247	1		802
F 8 0 3	Communication error trip time	1sec	0	100	3		803
F 8 4 5	Communication waiting time	0.01sec	0,00	2,00	1		805
F 8 0 6	Setting of master and slave for communication between inverters	1	0	4	4		806
F 8 0 7	Communication Channel Choice	1	0	1	1		807
F 8 1 1	Communication input point 1 setting	1%	0	100	2		811
F 8 1 2	Communication input point 1 frequency	0.01Hz	0,00	200,00	0		812
F 8 1 3	Communication input point 2 setting	1%	0	100	0		813
F 8 1 4	Communication input point 2 frequency	0.01Hz	0,00	200,00	0		814
F 8 2 0	Communication band speed (screw terminal)	1	0	1	1		820
F 8 2 1	Parity (screw terminal)	1	0	2	1	0	821
F 8 2 9	Selection of communication protocol	1	0	4	0		829
F 8 5 1	Inverter action at network & communication break	1	0	4	0		851
F 8 5 6	Number of motor poles for communication speed calculation	1	1	8	0		856
F 8 7 0	Block write data 1	1	0	6	0		870
F 8 6 1	Block write data 2	1	0	6	0		871
F 8 7 5	Block read data 1	1	0	11	0		875
F 8 7 6	Block read data 2	1	0	11	0		876
F 8 7 7	Block read data 3	1	0	11	0		877

NOTE: Remember to do this last!

When changing parameters the last parameter to save is "L Y P". After making the changes necessary go to L Y P and select "S R U E" #7 the drive will then save all the parameters, cycle power to the drive, you can re-apply power after the screen goes blank. When drive is up and running again cycle power to the entire unit. All parameters are saved and functional after the final power cycling.

Code	Description	Unit	Minimum Value	Maximum Value	Default Value	New Value	Logical Address
F878	Block read data 4	1	0	11	0		878
F879	Block read data 5	1	0	11	0		879
F880	Free notes	1	0	65535	0	119	880
F890	Parameter for option 1	1	0	65535	0		890
F891	Parameter for option 2	1	0	65535	0		891
F892	Parameter for option 3	1	0	65535	0		892
F893	Parameter for option 4	1	0	65535	0		893
F894	Parameter for option 5	1	0	65535	0		894
F895	Parameter for option 6	1	0	65535	0		895
F896	Parameter for option 7	1	0	65535	0		896
F897	Parameter for option 8	1	0	65535	0		897
F898	Parameter for option 9	1	0	65535	0		898
F899	Parameter for option 10	1	0	65535	0		899
F910	Step-out detection current level (for PM motors)	1%	10	150	100		910
F911	Step-out detection time (for PM motors)	0.1sec	0,0	25,0	0,0		911
F912	q-axis self-inductance (for PM)	0.01mH	0,00	650,00	0,00		912

NOTE: Remember to do this last!

When changing parameters the last parameter to save is "tYP". After making the changes necessary go to tYP and select "SR E" #7 the drive will then save all the parameters, cycle power to the drive, you can re-apply power after the screen goes blank. When drive is up and running again cycle power to the entire unit. All parameters are saved and functional after the final power cycling.

To incorporate a smoke purge function into the MicroTech III controls the following changes are required.

1. Change parameter **F 1 1 3** which is the input terminal selection. To 52, which is a forced function, meaning; ON: Forced operation mode in which operation is not stopped in the event of the occurrence of a soft fault (preset speed operation frequency15) To use this function, the inverter needs to be so configured at the factory.
2. Change parameter **F 2 9 4** which is the forced fire-speed setting frequency, typically 60 hzt.
3. Parameter **F 5 5 0** which is the forced fire-speed selection to 1.

Use an isolation relay DP/DT we will call this relay FS1 that resides in the fireman's panel, upon activation of the purge cycle the relay will close a normally open set of contacts between P24 and Res on the drive terminal strip. At the same time it will open the circuit that provides power to the MicroTech III Digital input 4. This action will put the MicroTech III controller into an emergency shut down mode and will activate the return fan to exhaust the smoke from the facility through the gravity relief dampers.

Figure 31: Return Fan Wiring Diagram





Figure 32: Smoke Purge Wiring Diagram





Daikin Applied Training and Development

Now that you have made an investment in modern, efficient Daikin equipment, its care should be a high priority. For training information on all Daikin HVAC products, please visit us at www.DaikinApplied.com and click on Training, or call 540-248-9646 and ask for the Training Department.

Warranty

All Daikin equipment is sold pursuant to its standard terms and conditions of sale, including Limited Product Warranty. Consult your local Daikin Applied Representative for warranty details. To find your local Daikin Applied Representative, go to www.DaikinApplied.com.

Aftermarket Services

To find your local parts office, visit www.DaikinApplied.com or call 800-37PARTS (800-377-2787). To find your local service office, visit www.DaikinApplied.com or call 800-432-1342.

This document contains the most current product information as of this printing. For the most up-to-date product information, please go to www.DaikinApplied.com.

Products manufactured in an ISO Certified Facility.