

Slave Modes

Application 2090: Heat Pump Controller – Single-Stage – Slave Mode

Overview

Application 2090 is the slave mode application for the Heat Pump Controller – Single-Stage (P/N 540-105). Slave mode is the default application that comes up when power is first applied to the controller. Slave mode provides no control. Its purpose is to allow the operator to perform equipment checkout before a control application is put into effect and to set some basic controller parameters (CTLR ADDRESS, APPLICATION, etc.).

Using Auxiliary Points

It is possible to have extra points available on a Heat Pump Controller – Single-Stage in addition to the ones used by the current application that is running in the controller. If these extra points are to be controlled by a field panel, they must be unbundled at the field panel.

Using the Controller as a Point Extension Device

If the controller is used *only* as a point extension device, with no control application in effect, its application must be set to slave mode *and* the points must be unbundled at the field panel. All of these points must be controlled from the field panel in order to be used. See Table 2090-2 for point database information.

All DOs may be used separately. DO 1, DO 2, DO 3, and DO 4 may also be used in pairs, (DO 1 and DO 2) and (DO 3 and DO 4), to control a motor as shown in the example. DO 5 and DO 6 cannot be used in a pair.

NOTE: If using either a motor or DOs as auxiliary points, be sure to set MTR SETUP (Point 58) to the correct value. See Table 2090-1. If using a pair of DOs to control a motor, the DOs cannot be unbundled or commanded separately. Only MTR1 COMD (Point 48) and MTR2 COMD (Point 52) can be unbundled to control the motors.

Table 2090-1. Motor Enable/Reverse Values for MTR SETUP (Point 58).

Motor 1 Not Used	Motor 1 Enabled	Motor 1 Enabled and Reserved
0	1	3

Example

If using DO 1 and DO 2 as the physical terminations for a direct acting motor, follow these steps:

1. Set MTR SETUP to 1 to enable the motor.
2. Unbundle MTR1 COMD at the field panel to command the motor from the field panel.

For other combinations of DOs and motors, see the *APOGEE Automation Start-up Procedures* on InfoLink for complete motor enable/reverse procedures.

Table 2090-2. Point Database for Application 2090.

Point Number	Descriptor	Factory Default (SI Units)	Engr. Units (SI Units)	Slope (SI Units)	Intercept (SI Units)	On Text	Off Text
01	CTLR ADDRESS	99	–	1	0	–	–
02	APPLICATION	2090	–	1	0	–	–
{04}	ROOM TEMP	74.00 (23.45)	DEG F (DEG C)	0.25 (0.14)	48.00 (8.89)	–	–
{13}	RM STPT DIAL	74.00 (23.45)	DEG F (DEG C)	0.25 (0.14)	48.00 (8.89)	–	–
{15}	AUX TEMP	74.00 (23.5)	DEG F (DEG C)	0.5 (0.28)	37.5 (3.056)	–	–
18	WALL SWITCH	NO	–	1	0	YES	NO
{19}	DI OVRD SW	OFF	–	1	0	ON	OFF
{24}	DI 2	OFF	–	1	0	ON	OFF
{25}	DI 3	OFF	–	1	0	ON	OFF
{29}	DAY.NGT	DAY	–	1	0	NIGHT	DAY
{41}	DO 1	OFF	–	1	0	ON	OFF
{42}	DO 2	OFF	–	1	0	ON	OFF
{43}	DO 3	OFF	–	1	0	ON	OFF
{44}	DO 4	OFF	–	1	0	ON	OFF
{45}	DO 5	OFF	–	1	0	ON	OFF
{46}	DO 6	OFF	–	1	0	ON	OFF
{48}	MTR1 COMD	0.00	PCT	0.4	0	–	–
{49}	MTR1 POS	0.00	PCT	0.4	0	–	–
51	MTR1 TIMING	130	SEC	1	0	–	–
{52}	MTR2 COMD	0	PCT	0.4	0	–	–
{53}	MTR2 POS	0	PCT	0.4	0	–	–
55	MTR2 TIMING	130	SEC	1	0	–	–
56	DPR1 ROT ANG	90	–	1	0	–	–
57	DPR2 ROT ANG	90	–	1	0	–	–
58	MTR SETUP	0	–	1	0	–	–
59	DO DIR.REV	0	–	1	0	–	–
96	CAL TIMER	12	HRS	1	0	–	–
{99}	ERROR STATUS	0	–	1	0	–	–

1. Points not listed are not used in this application.

2. A single value in a column means that the value is the same in English units and in SI units.

3. Point numbers that appear in brackets { } may be unbundled at the field panel.

Application 2090: Unit Conditioner Controller – Electronic Output – Slave Mode

Overview

Application 2090 is the slave mode application for the Unit Conditioner Controller – Electronic Output (P/N 540-110). Slave mode is the default application that comes up when power is first applied to the controller. Slave mode provides no control. Its purpose is to allow the operator to perform equipment checkout before a control application is put into effect and to set some basic controller parameters (CTLR ADDRESS, APPLICATION, etc.).

Using Auxiliary Points

It is possible to have extra points available on a Unit Conditioner Controller – Electronic Output in addition to the ones used by the current application that is running in the controller. If these extra points are to be controlled by a field panel, they must be unbundled at the field panel.

Using the Controller as a Point Extension Device

If the controller is used *only* as a point extension device, with no control application in effect, its application must be set to slave mode *and* the points must be unbundled at the field panel. All of these points must be controlled from the field panel in order to be used. See Table 2090-4 for point database information.

All DOs may be used separately. They may also be used in pairs, (DO 1 and DO 2), (DO 3 and DO 4), and (DO 5 and DO 6), to control a motor as shown in the example.

NOTE: If using either a motor or DOs as auxiliary points, be sure to set MTR SETUP (Point 58) to the correct value. See Table 2090-3. If using a pair of DOs to control a motor, the DOs cannot be unbundled or commanded separately. Only MTR 1 COMD (Point 48), MTR 2 COMD (Point 52), and MTR3 COMD (Point 37) can be unbundled to control the motors.

Table 2090-3. Motor Enable/Reverse Values for MTR SETUP (Point 58).

	Motor 1 Enabled			Motor 1 Enabled and Reversed			Motor 1 Not Used		
	Motor 2 Not Used	Motor 2 Enabled	Motor 2 Enabled and Reversed	Motor 2 Not Used	Motor 2 Enabled	Motor 2 Enabled and Reversed	Motor 2 Not Used	Motor 2 Enabled	Motor 2 Enabled and Reversed
Motor 3 Not Used	1	5	13	3	7	15	0	4	12
Motor 3 Enabled	17	21	29	19	23	31	16	20	28
Motor 3 Enabled and Reversed	49	53	61	51	55	63	48	52	60

Example

If using DO 1 and DO 2 as the physical terminations for a direct acting motor, follow these steps:

1. Set MTR SETUP to 1 to enable the motor.
2. Unbundle MTR 1 COMD at the field panel to command the motor from the field panel.

For other combinations of DOs and motors, see the *APOGEE Automation Start-up Procedures* on InfoLink for complete motor enable/reverse procedures.

Table 2090-4. Point Database for Application 2090.

Point Number	Descriptor	Factory Default (SI Units)	Engr. Units (SI Units)	Slope (SI Units)	Intercept (SI Units)	On Text	Off Text
01	CTLR ADDRESS	99.000	–	1.000	0.000	–	–
02	APPLICATION	2090	–	1.000	0.000	–	–
{04}	ROOM TEMP	74.000 (23.449)	DEG F (DEG C)	0.250 (0.140)	48.000 (8.889)	–	–
{13}	RM STPT DIAL	74.000 (23.449)	DEG F (DEG C)	0.250 (0.140)	48.000 (8.889)	–	–
{15}	AUX TEMP	74.000 (23.496)	DEG F (DEG C)	0.500 (0.280)	37.500 (3.056)	–	–
18	WALL SWITCH	NO	–	–	–	YES	NO
{19}	DI OVRD SW	OFF	–	–	–	ON	OFF
{24}	DI 2	OFF	–	–	–	ON	OFF
{25}	DI 3	OFF	–	–	–	ON	OFF
{29}	DAY.NGT	DAY	–	–	–	NIGHT	DAY
{37}	MTR 3 COMD	0.000	PCT	0.400	0.000	–	–
{38}	MTR 3 POS	0.000	PCT	0.400	0.000	–	–
39	MTR 3 TIMING	130.000	SEC	1.000	0.000	–	–
{41}	DO 1	OFF	–	–	–	ON	OFF
{42}	DO 2	OFF	–	–	–	ON	OFF
{43}	DO 3	OFF	–	–	–	ON	OFF
{44}	DO 4	OFF	–	–	–	ON	OFF
{45}	DO 5	OFF	–	–	–	ON	OFF
{46}	DO 6	OFF	–	–	–	ON	OFF
{48}	MTR 1 COMD	0.000	PCT	0.400	0.000	–	–

1. Points not listed are not used in this application.
2. A single value in a column means that the value is the same in English units and in SI units.
3. Point numbers that appear in brackets { } may be unbundled at the field panel.

continued on the next page...

Table 2090-4. Point Database for Application 2090.

Point Number	Descriptor	Factory Default (SI Units)	Engr. Units (SI Units)	Slope (SI Units)	Intercept (SI Units)	On Text	Off Text
{49}	MTR 1 POS	0.000	PCT	0.400	0.000	–	–
51	MTR 1 TIMING	130.000	SEC	1.000	0.000	–	–
{52}	MTR 2 COMD	0.000	PCT	0.400	0.000	–	–
{53}	MTR 2 POS	0.000	PCT	0.400	0.000	–	–
55	MTR 2 TIMING	130.000	SEC	1.000	0.000	–	–
56	MTR1 ROT ANG	90.000	–	1.000	0.000	–	–
57	MTR2 ROT ANG	90.000	–	1.000	0.000	–	–
58	MTR SETUP	0.000	–	1.000	0.000	–	–
59	DO DIR. REV	0.000	–	1.000	0.000	–	–
96	CAL TIMER	12.000	HRS	1.000	0.000	–	–
{99}	ERROR STATUS	–	–	–	–	–	–

1. Points not listed are not used in this application.
2. A single value in a column means that the value is the same in English units and in SI units.
3. Point numbers that appear in brackets { } may be unbundled at the field panel.