

Application 2092 Dual Duct Controller – One Air Velocity Sensor – Electronic Output – Slave Mode

Overview

Application 2092 is the slave mode application for the Dual Duct Controller – One Air Velocity Sensor – Electronic Output (P/N 540-106 and 540-107). Slave mode is the default application that comes up when power is first applied to the controller. Slave mode provides no control. Its purpose is to allow the operator to perform equipment checkout before a control application is put into effect and to set some basic controller parameters (CTRLR ADDRESS, APPLICATION, etc.).

Using auxiliary points

It is possible to have extra points available on a Dual Duct Controller – One Air Velocity Sensor – Electronic Output in addition to the ones used by the current application that is running in the controller. If these extra points are to be controlled by a field panel, then they must be unbundled at the field panel.

Using the controller as a point extension device

If the controller is *only* used as a point extension device, with no control application in affect, then its application must be set to slave mode *and* the points must be unbundled at the field panel. All of these points must be controlled from the field panel in order to be used. Refer to Table 2092-2 for point database information.

All DOs may be used as separate DOs. They may also be used in pairs, (DO 1 and DO 2), (DO 3 and DO 4), and (DO 5 and DO 6), to control a motor as shown in the example.

NOTE: If using either a motor or DOs as auxiliary points, then be sure to set the point MTR SETUP (number 58) to the correct value. Refer to Table 2092-1. If using a pair of DOs to control a motor, then the DOs cannot be unbundled or commanded separately. Only the points MTR 1 COMD (number 48), MTR 2 COMD (number 52), and MTR3 COMD (number 37) can be unbundled to control the motors.

Table 2092-1. Motor Enable/Reverse Values for MTR SETUP (number 58).

	Motor 1 Enabled			Motor 1 Enabled and Reversed			Motor 1 Not Used		
	Motor 2 Not Used	Motor 2 Enabled	Motor 2 Enabled and Reversed	Motor 2 Not Used	Motor 2 Enabled	Motor 2 Enabled and Reversed	Motor 2 Not Used	Motor 2 Enabled	Motor 2 Enabled and Reversed
Motor 3 Not Used	1	5	13	3	7	15	0	4	12
Motor 3 Enabled	17	21	29	19	23	31	16	20	28
Motor 3 Enabled and Reversed	49	53	61	51	55	63	48	52	60

Example

If using DO 1 and DO 2 as the physical terminations for a direct acting motor, then follow these steps:

1. Set MTR SETUP to 1 to enable the motor.
2. Unbundle MTR 1 COMD at the field panel to command the motor from the field panel.

NOTE: Motor 3 (DOs 5 and 6) is available only in slave mode.

For other combinations of DOs and motors, refer to the *System 600 Start-up Manual* (125-1851) for complete motor enable/reverse procedures.

Table 2092-2. Point Database for Application 2092.

Point Number	Descriptor	Factory Default (SI Units)	Engr. Units (SI Units)	Slope (SI Units)	Intercept (SI Units)	On Text	Off Text
01	CTLR ADDRESS	99.000	--	1.000	0.000	--	--
02	APPLICATION	2092	--	1.000	0.000	--	--
{04}	ROOM TEMP	74.000 (23.449)	DEG F (DEG C)	0.250 (0.140)	48.000 (8.889)	--	--
{13}	RM STPT DIAL	74.000 (23.449)	DEG F (DEG C)	0.250 (0.140)	48.000 (8.889)	--	--
{15}	AUX TEMP	74.000 (23.496)	DEG F (DEG C)	0.500 (0.280)	37.500 (3.056)	--	--
18	WALL SWITCH	NO	--	--	--	YES	NO
{19}	DI OVRD SW	OFF	--	--	--	ON	OFF
{24}	DI 2	OFF	--	--	--	ON	OFF
{25}	DI 3	OFF	--	--	--	ON	OFF
{29}	DAY.NGT	DAY	--	--	--	NIGHT	DAY
{35}	AIR VOLUME	0.000	CFM (LPS)	4.000 (1.888)	0.000	--	--
36	FLOW COEFF	1.000	--	0.010	0.000	--	--
{37}	MTR3 COMD	0.000	PCT	0.400	0.000	--	--
{38}	MTR3 POS	0.000	PCT	0.400	0.000	--	--
39	MTR3 TIMING	130.000	SEC	1.000	0.000	--	--
{41}	DO 1	OFF	--	--	--	ON	OFF
{42}	DO 2	OFF	--	--	--	ON	OFF
{43}	DO 3	OFF	--	--	--	ON	OFF
{44}	DO 4	OFF	--	--	--	ON	OFF
{45}	DO 5	OFF	--	--	--	ON	OFF
{46}	DO 6	OFF	--	--	--	ON	OFF
{48}	MTR1 COMD	0.000	PCT	0.400	0.000	--	--
{49}	MTR1 POS	0.000	PCT	0.400	0.000	--	--
51	MTR1 TIMING	95.000	SEC	1.000	0.000	--	--
{52}	MTR2 COMD	0.000	PCT	0.400	0.000	--	--
{53}	MTR2 POS	0.000	PCT	0.400	0.000	--	--
55	MTR2 TIMING	95.000	SEC	1.000	0.000	--	--
56	DPR1 ROT ANG	90.000	--	1.000	0.000	--	--

NOTES:

1. Points not listed are not used in this application.
2. A single value in a column means that the value is the same in English units and in SI units.
3. Point numbers that appear in brackets {} may be unbundled at the field panel.

Table 2092-2. Point Database for Application 2092.

Point Number	Descriptor	Factory Default (SI Units)	Engr. Units (SI Units)	Slope (SI Units)	Intercept (SI Units)	On Text	Off Text
57	DPR2 ROT ANG	90.000	--	1.000	0.000	--	--
58	MTR SETUP	0.000	--	1.000	0.000	--	--
59	DO DIR. REV	0.000	--	1.000	0.000	--	--
60	CLG DMP MIN	0.000	PCT	0.400	0.000	--	--
{94}	CAL AIR	NO	--	--	--	YES	NO
95	CAL SETUP	4.000	--	1.000	0.000	--	--
96	CAL TIMER	12.000	HRS	1.000	0.000	--	--
97	DUCT AREA	1.000 (0.093)	SQ. FT (SQ M)	0.025 (0.002)	0.000	--	--
{99}	ERROR STATUS	0.000	--	1.000	0.000	--	--

NOTES:

1. Points not listed are not used in this application.
2. A single value in a column means that the value is the same in English units and in SI units.
3. Point numbers that appear in brackets {} may be unbundled at the field panel.