

# MICROTECH<sup>®</sup> APPLIED AIR MODBUS<sup>®</sup> NETWORK INTEGRATION GUIDE

## MODBUS RTU AND TCP/IP COMMUNICATION PROTOCOLS

Rebel<sup>®</sup> and Rebel Applied<sup>®</sup> Packaged Rooftop Systems

Model DPSA with R-410A or R-32 including Refrigeration Only Controls (ROC)

Model DPS with R-32 including Refrigeration Only Controls (ROC)

Model DCSA with R-32 Air-Cooled Split Condensing System



|                                          |           |
|------------------------------------------|-----------|
| <b>Introduction</b>                      | <b>3</b>  |
| Hazard Identification                    | 3         |
| Description                              | 3         |
| Application                              | 3         |
| Reference Documents                      | 4         |
| Modbus Protocol Conformance              | 4         |
| <b>Configuration &amp; Commissioning</b> | <b>6</b>  |
| Unit Controller Overview                 | 6         |
| Hardware Setup                           | 6         |
| Network Communication Setup              | 6         |
| Commissioning                            | 6         |
| <b>Modbus Register Mapping</b>           | <b>8</b>  |
| <b>Alarms and Events</b>                 | <b>25</b> |
| Alarm Classes                            | 25        |
| Alarm Notification                       | 25        |
| Alarm Clearing                           | 25        |
| <b>Alarm Data Points</b>                 | <b>26</b> |
| <b>Service Information</b>               | <b>39</b> |
| Troubleshooting and Support              | 39        |
| Parts                                    | 39        |
| Technical Assistance                     | 39        |
| <b>Appendix: ASCII Conversion</b>        | <b>40</b> |
| <b>Revision History</b>                  | <b>41</b> |

©2026 Daikin Applied, Minneapolis, MN. All rights reserved throughout the world. This document contains the most current product information as of this printing. Daikin Applied Americas Inc. has the right to change the information, design, and construction of the product represented within the document without prior notice. For the most up-to-date product information, please go to [www.DaikinApplied.com](http://www.DaikinApplied.com).

™® Rebel Applied, Rebel, MicroTech, and Daikin Applied are trademarks or registered trademarks of Daikin Applied Americas Inc. The following are trademarks or registered trademarks of their respective companies: Modbus from Schneider Electric and Windows from Microsoft Corporation.

# Introduction

## Hazard Identification



### DANGER

Danger indicates a hazardous situation, which will result in death or serious injury if not avoided.



### WARNING

Warning indicates a potentially hazardous situations, which can result in property damage, personal injury, or death if not avoided.



### CAUTION

Caution indicates a potentially hazardous situations, which can result in minor injury or equipment damage if not avoided.

### NOTICE

Notice indicates practices not related to physical injury.

## Description

This manual provides instructions for integrating the MicroTech® 4 Rebel Applied unit controller with a Building Automation System (BAS) using the Modbus® communication protocol. The document supports both Modbus RTU (serial) and Modbus TCP (IP/Ethernet) communication methods.

This manual is intended for BAS integrators, service technicians, commissioning agents, and controls engineers responsible for configuring, commissioning, and maintaining BAS communications.

It is assumed that the user is familiar with the fundamentals of the Modbus protocol, including addressing, function codes, and register mapping.

## Supported Communication Protocols

The MicroTech unit controller communicates with a BAS through a factory installed or field installed Modbus communication module. Depending on the installed module, the controller can communicate using:

- Modbus RTU over RS-485 serial wiring
- Modbus TCP over Ethernet CAT 5 cable wiring

In both cases, the MicroTech controller operates as a Modbus server, responding to read and write requests initiated by a BAS as the Modbus client.

Both Modbus RTU and Modbus TCP BAS networks can access, view, and/or command to all unit controller data points described in this document.

### Modbus RTU

Modbus RTU is a serial communication protocol utilizing RS 485 wiring and a client/server (master/slave) polling architecture. The BAS polls the controller to read operating data and write commands.

### Modbus TCP

Modbus TCP is an Ethernet based implementation of the Modbus protocol operating over standard TCP/IP networks. The BAS communicates with the controller using an IP address and IP port. When equipped with a Modbus TCP communication module, the unit controller operates as a Modbus server when communicating with a BAS using standard function codes.

## Application

### Software

This document supports the latest version of the MicroTech unit controller application software version 250636306 (v3.06) and newer. However, the unit controller applications have compatibility differences as described in [Table 1](#).

**Table 1: MicroTech Controller Compatibility with Modbus RTU and TCP/IP Protocols**

| MT Unit Controller Application                                                            | Model Type | Network Protocols Supported |            |
|-------------------------------------------------------------------------------------------|------------|-----------------------------|------------|
|                                                                                           |            | Modbus RTU                  | Modbus TCP |
| MT4 Rebel Applied Rooftop with R-410A or R-32 including Refrigeration Only Controls (ROC) | DPSA       | Yes                         | Yes        |
| Rebel Applied Rooftop with R-32 Air-Cooled Split Condensing System                        | DCSA       | Yes                         | Yes        |
| Rebel Packaged Rooftop with R-32, including Refrigeration Only Controls (ROC)             | DPS        | Yes                         | Yes        |

## Firmware

The communication module firmware supports the following BSP (Board Support Package) versions:

- Communication module BSP versions 11.54 and newer.
- MicroTech unit controller BSP versions 11.78 and newer.

The MicroTech unit controller software application version is available from the controller HMI under the 'About This AHU' menu.

The Modbus addressing parameters are configured from the unit controller HMI. The Modbus data points

## Network Security

### NOTICE

Network Security - Modbus TCP communication does not include encryption, authentication, or inherent cyber security protections. Network security must be provided by the system integrator or building network infrastructure.

### For Modbus TCP Applications Only

- Keep BAS traffic on a dedicated control network
- Restrict access to authorized devices
- Avoid direct exposure to public or unsecured networks/firewalls are in place

## Reference Documents

| Company        | Number  | Title                                                                                   | Source                                                           |
|----------------|---------|-----------------------------------------------------------------------------------------|------------------------------------------------------------------|
| Daikin Applied | OM 1288 | MicroTech 4 Unit Controller For Rebel Applied Rooftop Systems                           | <a href="http://www.DaikinApplied.com">www.DaikinApplied.com</a> |
|                | IM 1364 | IP communication Module Installation Manual for MicroTech Rebel Applied Unit Controller |                                                                  |
|                | OM 1263 | Rebel DPS MicroTech Refrigeration Only Controls (R-410A)                                |                                                                  |
|                | OM 1373 | Rebel Applied DPSA Controls (R32)                                                       |                                                                  |
|                | OM 1401 | Rebel Applied Refrigeration Only Controls (ROC) DPSA (R-32)                             |                                                                  |
|                | OM 1382 | Rebel DPS MicroTech Controls (R32)                                                      |                                                                  |
| Modbus-IDA.ORG |         | Modbus TCP Application Protocol (V1.1b3)                                                | <a href="http://www.Modbus.org">www.Modbus.org</a>               |
| Modbus-IDA.ORG |         | Modbus over Serial Line Specification and Implementation Guide V1.02                    |                                                                  |

## Modbus Protocol Conformance

The unit controller conforms to Modbus RTU (Remote Terminal Unit) and Modbus TCP protocol requirements.

The MicroTech unit controller and communication module together represent the server device in accordance with the Modbus RTU or Modbus TCP specification.

## Data Transmission

A normal reply from the MicroTech unit controller includes the same function code and a response data field. In the case of a read operation, the response data field contains the requested data. In the case of a write operation, the response data field contains an echo of the write data of the request command. If the unit controller detects an error in the transmission, the reply to the client includes and exception function code and the response data field contains an exception code

## Data Type

Data is represented as either single-bit elements or 16-bit elements. A single-bit element is referred to as a Discrete Input when it refers to read-only data and as a Coil when it refers to read-write data. A 16-bit element is referred to as a Input Register when it refers to read-only data, and as a Holding Register when it refers to read-write data.

*All of the Modbus registers defined in the MicroTech unit controller are 16-bit Holding Registers. Some are read only (R) and some are read-write (W).*

## Holding Registers

There are up to 65,536 elements of each data type in a Modbus device. Data elements are numbered from 1 to 65,536 in each type. Data elements are addressed with an index in the range from 0 to 65,535. The index is not the address of the data element in the unit controller memory, but instead it is used in Modbus PDUs to specify the location of the data in the unit controller. This means, for example, that data element number 1 (i.e., Holding Register 40001) is addressed using index 0 in the PDU.

In addition, the function code field portion of the message already specifies a "Holding Register" operation. Therefore the '4xxxx' reference is implicit. As such, this document represents the Holding Registers without the implicit 4xxxx. For example, Holding Register 8 is actually Holding Register 40008.

## Valid Range

Some properties are standard data types and some are enumerated sets. If the property value represents a range of values (e.g. temperature or pressure) that range of values is shown. If the property value is an enumerated set, all enumerated values and their descriptions are shown as well.

## Function Codes

The MicroTech unit controller supports eight Modbus function codes as shown in [Table 2](#).

**Table 2: Valid Function Codes**

| Function Code | Description              | Definition                                                                         |
|---------------|--------------------------|------------------------------------------------------------------------------------|
| 01 (0x01)     | Read Coil Status         | Reads the On/Off status of discrete outputs                                        |
| 02 (0x02)     | Read Input Status        | Reads the On/Off status of discrete inputs                                         |
| 03 (0x03)     | Read Holding Registers   | Reads one to approximately 125 contiguous input registers in a remote device       |
| 04 (0x04)     | Read Input Registers     | Reads the contents of input registers                                              |
| 05 (0x05)     | Force Single Coil        | Forces a single coil to either On or Off                                           |
| 06 (0x06)     | Write Single Register    | Writes a single Holding Register to a remote device                                |
| 15 (0x0F)     | Write Multiple Coils     | Forces each coil in a sequence of coils to either On or Off                        |
| 16 (0x10)     | Write Multiple Registers | Writes a block of one to approximately 120 contiguous registers in a remote device |

## Valid Error Codes

The MicroTech unit controller supports all exception codes. See [Table 3](#) for a description of valid error codes.

**Table 3: Valid Error Codes**

| Error Codes | Description                             | Definition                                                                                                                                                                                                  |
|-------------|-----------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 01          | Illegal Function                        | The function code received in the query is not an allowable action for the server (or server)                                                                                                               |
| 02          | Illegal Data Address                    | The data address received in the query is not an allowable address for the server (or server)                                                                                                               |
| 03          | Illegal Data Value                      | A value contained in the query data field is not an allowable value for server (or server)                                                                                                                  |
| 04          | Server Device Failure                   | An unrecoverable error occurred while the server (or server) was attempting to perform the requested action                                                                                                 |
| 05          | Acknowledged                            | The server (or server) has accepted and is processing the request                                                                                                                                           |
| 06          | Server Device Busy                      | The server (or server) is busy processing a command. The client (or client) should retransmit when the server (or server) is free                                                                           |
| 08          | Memory Parity Error                     | The server (or server) attempted to read record file, but detected a parity error in the memory. The client (or client) can retry the request, but service may be required on the server (or server) device |
| 0A          | Gateway Path Unavailable                | The gateway may be configured incorrectly or overloaded                                                                                                                                                     |
| 0B          | Gateway Target Device Failed to Respond | No response from the target device                                                                                                                                                                          |

## Modbus Data Point

Unit controller data points are primarily mapped through Holding Registers (4xxxx). Each data point accessible from a Modbus network is described with a table that gives the data type and Holding Register. If the data point represents an enumerated variable, the enumerations are also listed.

When a variable spans multiple Holding Registers, it is important to know how the data is represented in those Holding Registers.

For strings, the interpretation differs. In this case, each Holding Register can contain two characters. If a string spans multiple registers, the first register (lowest register number) contains the two left-most characters of the string. Since the MicroTech unit controller only supports Modbus RTU, use the [Troubleshooting and Support](#) to translate the numerical data to their corresponding ASCII characters.

Application Version is an example of registers that contain string data and is located at Holding Registers 600-604 (40600-40604).

Refer to [Table 4: Modbus Holding Register Data](#) for list of all supported registers.

## Serial Port and Transmission Modes

Serial port communication parameters (baud rate, parity mode, etc), are set during commissioning. The parity mode and serial parameters must be the same for all devices on a Modbus network. Transmission mode determines how information is packed into the message fields and decoded. In RTU mode, each byte contains two hexadecimal characters.

# Configuration & Commissioning

This section defines the minimum requirements to setup, configure, and commission the unit controller for Modbus network integration.

## Unit Controller Overview

The MicroTech unit controller and the Modbus communication module ship with default parameter values. Certain addressing parameters must be configured from the unit controller HMI. Other data are available in both or via the BAS. Parameters must be adjusted to accommodate the specific network.

Also refer to the applicable MicroTech Unit Controller OM and Modbus RTU or Modbus TCP Communication Module IM for details ([Reference Documents](#)).

### Generic (Universal) I/O

When an EMB (expansion module B) is attached to the unit controller, a set of universal and dedicated outputs are available to the network. See registers 300-349 in [Table 4](#) for details.

## Hardware Setup

1. Verify the correct Modbus communication module is installed on the unit controller.
  - **Modbus RTU (MT3041)**
    - Verify RS-485 polarity (A/B)
    - Confirm proper termination
  - **Modbus TCP (MT3041)** for IP/Ethernet

Refer to the [Service Information](#) section for Modbus RTU and Modbus TCP communication module part numbers.

## Network Communication Setup

2. Set the "Control Mode = Off" from the **Daikin AHU Main Menu**.
3. From the unit controller HMI, navigate to the **BMS Communications** menu.
4. Verify **AHU Loc/Net** is set to **Net**.

When the unit controller detects the communication module, the HMI displays the appropriate set-up menu.

### Modbus TCP

5. For Modbus TCP communications, navigate to the **BACnet/Modbus IP Set-Up** menu and set IP Protocol to Modbus.
6. Navigate to the **Modbus IP Set-up** menu for network settings.

**NOTE:** The controller enables DHCP by default. Also see the [Network Considerations](#) section for more information

about multiple IP subnet networks. If required, disable DHCP and set addressing parameters manually:

- a. Change DHCP from Yes to No.
- b. Change the Given IP Address to a unique value on the network.

**NOTE:** The Actual Address matches the Given Address after Apply Changes is selected.

7. Verify Subnet Mask and Given Gateway for the network.

### Modbus RTU

4. From the **Modbus Set-Up** menu:
  - a. Assign a unique Network Address (1-247).
  - b. Match baud rate, parity, and stop bits with the network.

**NOTE:** Parameters above must be configured from the unit controller HMI. Baud rate, parity, and stop bits must be the same for all devices on a Modbus network.

## Commissioning

The controller responds to Modbus read/write requests only when it is configured for network control. Modbus write commands may not override unit safeties, alarms, internal protection logic, or factory-configured operating limits. If conflicting commands are present, the controller defaults to local control.

5. Confirm **Network Control** (Register 264) is set to **0=Network**. If not, write commands may be accepted but overridden.

## Typical Read Points

Before configuring write commands, validate that the controller is enabled for Modbus BAS control for these recommended read points. Note that not all may apply to the specific unit configuration:

- **Discharge Air Temp** (Register 1)  
Read the register repeatedly while the unit is operating. Confirm that the sensor value is reasonable, scaled correctly, and is stable. It must reflect actual discharge air temperature as shown in the unit controller HMI.
- **Return Air Temp** (Register 2)  
Compare the register value against the unit controller HMI. Confirm the sensor value matches expected return air conditions and is within tolerance.
- **Effective Outdoor Air Temp** (Register 8)  
The register value is reasonable given actual outside conditions. Compare against the Outdoor Air Temperature displayed on the unit controller HMI. Confirm effective outdoor air value and that values are functioning across multiple sensor inputs.
- **Unit State** (Register 260)  
The register value reflects the actual operating mode (Off, Heat, Cool, Economizer, etc.) of the unit during operation.

## Typical Writable Points

6. Once communication is stable, test these common writable points to confirm the unit responds to network commands:
  - **Application Mode** (Register 249)
  - **Occupancy Mode** (Register 251)
  - **Occupied Cooling Setpoint** (Register 138)
  - **Occupied Heating Setpoint** (Register 140)

## Alarms and Network Considerations

7. Read any alarms and clear (if needed) during commissioning. If a Problem or Fault alarm is active, Modbus network commands may not write to the controller.
  - **Warning** (Register 155)
  - **Problem** (Register 156)
  - **Fault** (Register 157)
  - **Alarm Value** (Register 158)
  - **Clear Alarm** (Register 400)

## Verify Polling Rate

8. Poll registers during configuration and commissioning to verify points update reliably without missed polls or erratic behavior. Gradually adjust polling rates as needed to prevent communication timeouts, excessive network traffic, or unstable values.

# Modbus Register Mapping

This section describes the MicroTech unit controller data available to the Modbus RTU or Modbus TCP network. Alarms, Events, and Standby Event notifications can be found in the [Alarms and Events](#) tables.

**NOTE:** Most Modbus writeable registers are effective only when the controller is configured for Network Control (see [Network Communication Setup](#)).

**Table 4: Modbus Holding Register Data**

| Description                                  | Holding Register (4xxxx) | Read/Write | Range                                   | Default | Notes                                                                                                                                                                                                                                                                                                                                                                                                              |
|----------------------------------------------|--------------------------|------------|-----------------------------------------|---------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Discharge Air Temperature Sensor             | 1                        | R          | -50-250°F x 10<br>-45.6-121.1°C x 10    | NA      | The current reading from the unit discharge air temperature sensor. Additional alarms are generated for this object. See <a href="#">Alarms and Events</a> .                                                                                                                                                                                                                                                       |
| Return Air Temperature Sensor                | 2                        | R          | -20-200°F x 10<br>28.9-93.3°C x 10      | NA      | The current reading from the return air temperature sensor. Additional alarms are generated for this object. See <a href="#">Alarms and Events</a> .                                                                                                                                                                                                                                                               |
| Effective Space Temperature                  | 3                        | R          | 0-150°F x 10<br>-17.8-65.6°C x 10       | NA      | The space temperature input from a local sensor(s) if installed and configured properly. The space temperature input may be provided by up to three Modbus sensors. Space temperature may also be provided by a network input (SpaceTempInput) if value is present and valid. Otherwise, effective space temperature defaults to an invalid value (327.67°C/621.806°F).                                            |
| Space Temperature Sensor 1                   | 4                        | R          | 0-150°F x 10<br>-17.8-65.6°C x 10       | NA      | The current space or zone temperature. Applies only if the unit is configured for one or more local sensors.<br><br>If the optional space temperature sensor is not installed, set SpaceTCfg = None from the unit controller Unit Configuration display menu. This disables the alarm function associated with an open circuit at the space temperature sensor input. Also see <a href="#">Alarms and Events</a> . |
| Space Temperature Sensor 2                   | 5                        |            |                                         |         |                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Space Temperature Sensor 3                   | 6                        |            |                                         |         |                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Entering Fan/Leaving Coil Temperature Sensor | 7                        | R          | -50-200°F x 10<br>-45.6-93.3°C x 10     | NA      | The current value of the unit entering fan/leaving coil air temperature sensor. Applies only to units configured for this type of sensor. Also see <a href="#">Alarms and Events</a> .                                                                                                                                                                                                                             |
| Effective Outdoor Air Temperature            | 8                        | R          | -50-200°F x 10<br>-45.6-93.3°C x 10     | NA      | The network outdoor air temperature value. Otherwise it The local outdoor air temperature if a valid network is not available. Also see <a href="#">Alarms and Events</a> .                                                                                                                                                                                                                                        |
| Building Static Pressure Sensor              | 9                        | R          | -0.249-0.249 x 1000<br>-62-62 Pa x 1000 | NA      | The current building static pressure based on return plenum static pressure setpoint. Applies to units configured with a return fan BSP sensor.                                                                                                                                                                                                                                                                    |
| Effective Supply Fan Capacity                | 10                       | R          | 0-100% x 10                             | NA      | The effective supply air fan capacity reflects input from unit supply fan motor drives. The SAFCap value depends on the type and number of supply fan motors currently operating.                                                                                                                                                                                                                                  |
| Relative Humidity Sensor 1                   | 11                       | R          | 0-100% x 10                             | NA      | The current reading of the optional space relative humidity sensor(s). Applies only if the unit is configured for one or more local sensors.                                                                                                                                                                                                                                                                       |
| Relative Humidity Sensor 2                   | 12                       |            |                                         |         |                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Space CO <sub>2</sub>                        | 13                       | R          | 0-5000 ppm x 10                         | NA      | The current value of the effective CO <sub>2</sub> input, either provided by the network via SpaceIAQNetIn or optional space CO <sub>2</sub> sensor. CO <sub>2</sub> is configured via the unit controller HMI.                                                                                                                                                                                                    |
| Control Temperature                          | 14                       | R          | -461-525°F x 10<br>-274-274.2°C x 10    | NA      | The current control temperature sensor reading. The sensor is selected with Modbus register 265 (CtrlTempScr).                                                                                                                                                                                                                                                                                                     |
| Energy Recovery Wheel Capacity               | 15                       | R          | 0-100% x 10 x 10                        | NA      | The energy recovery wheel speed feedback parameter. Converted to a percentage of the total capacity. Applies to units with an ECM motor or Daikin VFD.                                                                                                                                                                                                                                                             |
| Energy Recovery Leaving Wheel Temperature    | 16                       | R          | -50-200°F x 10<br>-45.6-93.3°C x 10     | NA      | The current value of the energy recovery leaving wheel temperature sensor.                                                                                                                                                                                                                                                                                                                                         |
| Energy Recovery Entering Wheel Temperature   | 17                       | R          | -50-200°F x 10<br>-45.6-93.3°C x 10     | NA      | The current value of the energy recovery entering wheel temperature sensor.                                                                                                                                                                                                                                                                                                                                        |
| Return Fan Capacity                          | 18                       | R          | 0-100% x 10                             | NA      | The input from the VFD controlling one or more return/exhaust fan motors.                                                                                                                                                                                                                                                                                                                                          |
| Supply Fan Duct Static Pressure              | 19                       | R          | 0.0-5.02" x 10<br>0-1250 Pa x 10        | NA      | The current supply fan duct static pressure. Applies to units configured with a supply fan DSP sensor.                                                                                                                                                                                                                                                                                                             |
| Return Fan Duct Static Pressure              | 20                       | R          | -5.02-0" x 10<br>-1250-0 Pa x 10        | NA      | The current return fan duct static pressure. Applies to units configured with a return fan DSP sensor.                                                                                                                                                                                                                                                                                                             |

| Description                                      | Holding Register (4xxxx) | Read/Write | Range                                 | Default | Notes                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|--------------------------------------------------|--------------------------|------------|---------------------------------------|---------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Filter Pressure Input                            | 21                       | R          | 0.0 -5.02" x 100<br>0.0-1250 Pa x 100 | NA      | Filter pressure input. Used to generate a filter pressure alarm when the setpoint value has been exceeded. Also see <a href="#">Alarms and Events</a> .                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|                                                  | 22                       |            |                                       |         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|                                                  | 23                       |            |                                       |         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| Exhaust Air Plenum Static Pressure               | 24                       | R          | 0-1.0" x 100<br>0-249 Pa x 100        | NA      | Reflects the exhaust air plenum static pressure (PSP) for units with modulating relief dampers. Input is used in conjunction with the return duct static pressure signal to modulate the exhaust/relief dampers and maintain the exhaust plenum static pressure setpoint.<br><br>Exhaust air plenum static pressure control remains active regardless of return/exhaust fan control mode, including when the return/exhaust fan is configured for fan tracking. It is recommended that Return Fan Capacity Control (Holding Register 257) is set to DSP. However, other settings also support PSP control. |
| Return Air Relative Humidity                     | 25                       | R          | 0-100% x 10                           | NA      | The current reading of the optional return air relative humidity sensor. Applies only if the unit is configured for a locally installed and wired sensor.                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Return Air Dewpoint                              | 26                       | R          | -50-150°F x 10<br>-45.6-65.6°C x 10   | NA      | The return air dewpoint temperature value, calculated from the optional return air relative humidity sensor.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| Outdoor Air Relative Humidity                    | 27                       | R          | 0-100% x 10                           | NA      | The current reading of the optional outdoor air relative humidity sensor. Applies only if the unit is configured for a locally installed and wired sensor.                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| Outdoor Air Dewpoint                             | 28                       | R          | -50-150°F x 10<br>-45.6-65.6°C x 10   | NA      | The outdoor air dewpoint temperature value; calculated from the optional outdoor air humidity sensor.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Supply Fan Airflow                               | 29                       | R          | 0-60000 cfm x 10                      | NA      | Displays the current supply airflow value. Parameter is available for monitoring purposes when an outdoor air unit is configured with an outdoor airflow measuring station.                                                                                                                                                                                                                                                                                                                                                                                                                                |
| Return Fan Airflow                               | 30                       | R          | 0-6000 cfm x 10                       | NA      | Displays the effective return/exhaust fan airflow. Available for monitoring purposes when a unit is configured with a return or exhaust airflow measuring station.                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| Particulate Matter 2.5 Return Air                | 31                       | R          | 0-250 mcg/m3 x 10                     | NA      | Indicates the particulate matter (PM) size 2.5 value provided by the return air sensor.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Particulate Matter 10 Value Return Air           | 32                       | R          | 0-430 mcg/m3 x 10                     | NA      | Indicates the particulate matter (PM) size 10 value provided by the return air sensor.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Total VOC Value Return Air                       | 33                       | R          | 0-600 mcg/m3 x 10                     | NA      | Indicates the total volatile organic compounds (VOC) value provided by the return air sensor.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Particulate Matter 2.5 Discharge Air             | 34                       | R          | 0-250 mcg/m3 x 10                     | NA      | Indicates the particulate matter (PM) size 2.5 value provided by the discharge air sensor.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| Particulate Matter 10 Value Discharge Air        | 35                       | R          | 0-430 mcg/m3 x 10                     | NA      | Indicates the particulate matter (PM) size 10 value provided by the discharge air sensor.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Total VOC Value Discharge Air                    | 36                       | R          | 0-600 mcg/m3 x 10                     | NA      | Indicates the total volatile organic compounds (VOC) value provided by the discharge air sensor.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| Particulate Matter 2.5 Outdoor Air               | 37                       | R          | 0-250 mcg/m3 x 10                     | NA      | Indicates the particulate matter (PM) size 2.5 value provided by the outdoor air sensor.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| Particulate Matter 10 Value Outdoor Air          | 38                       | R          | 0-430 mcg/m3 x 10                     | NA      | Indicates the particulate matter (PM) size 10 value provided by the outdoor air sensor.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Suction Refrigerant Temperature Circuit 1        | 39                       | R          | -83-392°F x 10<br>-64-200°C x 10      | NA      | The current reading of the circuit 1 suction refrigerant temperature sensor. <sup>1</sup>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Suction Refrigerant Pressure Circuit 1           | 40                       | R          | 0-725 psi x 10<br>0-5000 kPa x 10     | NA      | The current reading of the circuit 1 suction line refrigerant pressure sensor. <sup>1</sup>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| Discharge Refrigerant Pressure Circuit 1         | 41                       | R          | 0-725 psi x 10<br>0-5000 kPa x 10     | NA      | The current reading of the circuit 1 discharge refrigerant pressure sensor. <sup>1</sup>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| Liquid Line Refrigerant Temperature Circuit 1    | 42                       | R          | -83-212°F x 10<br>-64-100°C x 10      | NA      | The current reading of the circuit 1 liquid line refrigerant temperature sensor. <sup>1</sup>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Variable Compressor 1 Temperature                | 43                       | R          | -83-392°F x 10<br>-64-200°C x 10      | NA      | The current reading of the variable compressor 1 refrigerant temperature sensor input.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Fixed Compressor Temperature Circuit 1           | 44                       | R          | -83-212°F x 10<br>-64-100°C x 10      | NA      | The fixed compressor refrigerant temperature sensor value.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|                                                  | 45                       |            |                                       |         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|                                                  | 46                       |            |                                       |         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| Discharge Line Refrigerant Temperature Circuit 1 | 47                       | R          | -83-392°F x 10<br>-64-200°C x 10      | NA      | The inverter compressor circuit 1 discharge line refrigerant temperature sensor value. Applies only to units configured for variable compressors or units with an optional refrigerant system monitoring package.                                                                                                                                                                                                                                                                                                                                                                                          |
|                                                  | 48                       |            |                                       |         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|                                                  | 49                       |            |                                       |         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |

| Description                                        | Holding Register (4xxxx) | Read/Write | Range                                    | Default | Notes                                                                                                                                                                                                                               |
|----------------------------------------------------|--------------------------|------------|------------------------------------------|---------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Defrost Temperature Circuit 1                      | 50                       | R          | -83-392°F x 10<br>-64-200°C x 10         | NA      | The current reading of the circuit 1 defrost sensor. Applies to heat pump units.                                                                                                                                                    |
| Suction Refrigerant Temperature Circuit 2          | 51                       | R          | -83-392°F x 10<br>-64-200°C x 10         | NA      | The current reading of the circuit 2 suction refrigerant temperature sensor input.                                                                                                                                                  |
| Suction Refrigerant Pressure Circuit 2             | 52                       | R          | 0-725 psi x 10<br>0-5000 kPa x 10        | NA      | The current reading of the circuit 2 suction line refrigerant pressure sensor input.                                                                                                                                                |
| Discharge Refrigerant Pressure Circuit 2           | 53                       | R          | 0-725 psi x 10<br>0-5000 kPa x 10        | NA      | The current reading of the circuit 2 discharge refrigerant pressure sensor input.                                                                                                                                                   |
| Liquid Line Refrigerant Temperature Circuit 2      | 54                       | R          | -83-212°F x 10<br>-64-100°C x 10         | NA      | The current reading of the circuit 2 liquid line refrigerant temperature sensor input.                                                                                                                                              |
| Variable Compressor 2 Temperature                  | 55                       | R          | -83-392°F x 10<br>-64-200°C x 10         | NA      | The current reading of the variable compressor 2 refrigerant temperature sensor input.                                                                                                                                              |
| Fixed Compressor Temperature Circuit 2             | 56                       | R          | -83-212°F x 10<br>-64-100°C x 10         | NA      | The circuit 2 fixed compressor refrigerant temperature sensor value.                                                                                                                                                                |
|                                                    | 57                       |            |                                          |         |                                                                                                                                                                                                                                     |
|                                                    | 58                       |            |                                          |         |                                                                                                                                                                                                                                     |
| Discharge Line Refrigerant Temperature Circuit 2   | 59                       | R          | -83-392°F x 10<br>-64-200°C x 10         | NA      | The inverter compressor circuit 2 discharge line refrigerant temperature sensor value. Applies only to units configured for variable compressors or units with an optional refrigerant system monitoring package.                   |
|                                                    | 60                       |            |                                          |         |                                                                                                                                                                                                                                     |
|                                                    | 61                       |            |                                          |         |                                                                                                                                                                                                                                     |
| Defrost Temperature Circuit 2                      | 62                       | R          | -83-392°F x 10<br>-64-200°C x 10         | NA      | The current reading of the circuit 2 defrost sensor. Applies to heat pump units.                                                                                                                                                    |
| Suction Refrigerant Temperature Circuit 3          | 63                       | R          | -83.2-212.0°F x 10<br>-64.0-100.0°C x 10 | NA      | The current reading of the circuit 3 suction refrigerant temperature sensor.                                                                                                                                                        |
| Suction Refrigerant Pressure Circuit 3             | 64                       | R          | 0-725.19 psi x 10<br>0-5000.0 kPa x 10   | NA      | The current reading of the circuit 3 suction line refrigerant pressure sensor.                                                                                                                                                      |
| Discharge Refrigerant Pressure Circuit 3           | 65                       | R          | 0-725.19 psi x 10<br>0-5000.0 kPa x 10   | NA      | The current reading of the circuit 3 discharge line refrigerant pressure sensor.                                                                                                                                                    |
| Liquid Line Refrigerant Temperature Circuit 3      | 66                       | R          | -83.2-212.0°F x 10<br>-64.0-100.0°C x 10 | NA      | The current reading of the circuit 3 liquid line refrigerant temperature sensor.                                                                                                                                                    |
| Variable Compressor 3 Temperature Circuit 3        | 67                       | R          | -83.2-212.0°F x 10<br>-64.0-100.0°C x 10 | NA      | The current reading of the circuit 3 refrigerant temperature sensor variable compressor 3.                                                                                                                                          |
| Fixed Compressor 1 Temperature Circuit 3           | 68                       | R          | -83.2-212.0°F x 10<br>-64.0-100.0°C x 10 | NA      | Circuit 3 refrigerant temperature sensor value for fixed compressors 1, 3 or 5. See <a href="#">Alarms and Events</a> section for alarm enumerations.                                                                               |
| Fixed Compressor 3 Temperature Circuit 3           | 69                       | R          | -83.2-212.0°F x 10<br>-64.0-100.0°C x 10 | NA      |                                                                                                                                                                                                                                     |
| Fixed Compressor 5 Temperature Circuit 3           | 70                       | R          | -83.2-212.0°F x 10<br>-64.0-100.0°C x 10 | NA      |                                                                                                                                                                                                                                     |
| Discharge Line Refrigerant Temperature 1 Circuit 3 | 71                       | R          | -83.2-212.0°F x 10<br>-64.0-100.0°C x 10 | NA      | The current reading of the circuit 3 discharge line refrigerant temperature sensor 1, 3, or 5.                                                                                                                                      |
| Discharge Line Refrigerant Temperature 3 Circuit 3 | 72                       | R          | -83.2-212.0°F x 10<br>-64.0-100.0°C x 10 | NA      |                                                                                                                                                                                                                                     |
| Discharge Line Refrigerant Temperature 5 Circuit 3 | 73                       | R          | -83.2-212.0°F x 10<br>-64.0-100.0°C x 10 | NA      |                                                                                                                                                                                                                                     |
| Total Unit Energy Usage                            | 80-81                    | R          | 0-9999999 kW x 10                        | NA      | Total amount of unit energy usage, in kilowatt hours.                                                                                                                                                                               |
| Voltage - Lines 1 and 2                            | 88                       | R          | 0-700V x 10                              | NA      | The voltage of 3-phase power measured between Lines 1 and 2.                                                                                                                                                                        |
| Voltage - Lines 2 and 3                            | 89                       | R          | 0-700V x 10                              | NA      | The voltage of 3-phase power measured between Lines 2 and 3.                                                                                                                                                                        |
| Voltage - Lines 1 and 3                            | 90                       | R          | 0-700V x 10                              | NA      | The voltage of 3-phase power measured between Lines 1 and 3.                                                                                                                                                                        |
| Current - Line 1                                   | 97                       | R          | 0-200 A x 10                             | NA      | Line 1 current, in amps.                                                                                                                                                                                                            |
| Current - Line 2                                   | 98                       | R          | 0-200 A x 10                             | NA      | Line 2 current, in amps.                                                                                                                                                                                                            |
| Current - Line 3                                   | 99                       | R          | 0-200 A x 10                             | NA      | Line 3 current, in amps.                                                                                                                                                                                                            |
| Suction Superheat Circuit 1                        | 116                      | R          | -83-147°F x 10<br>-64-64°C x 10          | NA      | The calculated suction superheat for circuit 1. The suction superheat function is used to control the indoor expansion valve in the variable capacity compressor circuit.                                                           |
| Discharge Superheat Circuit 1                      | 117                      | R          | -83-147°F x 10<br>-64-64°C x 10          | NA      | The calculated discharge superheat for circuit 1.                                                                                                                                                                                   |
| Subcooling Circuit 1                               | 118                      | R          | -83-147°F x 10<br>-64-64°C x 10          | NA      | The calculated temperature which is used to control the modulation of the liquid subcooling reheat valve. Subcooling for circuit 1 is used for display purposes when the unit is configured with a refrigeration monitoring option. |

| Description                                        | Holding Register (4xxxx) | Read/Write | Range                                      | Default                        | Notes                                                                                                                                                                                                                                                                                                                                      |
|----------------------------------------------------|--------------------------|------------|--------------------------------------------|--------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Suction Superheat Circuit 2                        | 119                      | R          | -83-147°F x 10<br>-64-64°C x 10            | NA                             | The calculated suction superheat for circuit 2. The suction superheat function is used to control the indoor expansion valve in the variable capacity compressor circuit.                                                                                                                                                                  |
| Discharge Superheat Circuit 2                      | 120                      | R          | -83-147°F x 10<br>-64-64°C x 10            | NA                             | The calculated discharge superheat for circuit 2.                                                                                                                                                                                                                                                                                          |
| Subcooling Circuit 2                               | 121                      | R          | -83-147°F x 10<br>-64-64°C x 10            | NA                             | The calculated temperature which is used to control the modulation of the liquid subcooling reheat valve. Subcooling for circuit 2 is used for display purposes when the unit is configured with a refrigeration monitoring option.                                                                                                        |
| Unit Cooling Capacity                              | 125                      | R          | 0-100% x 10                                | NA                             | The current cooling capacity of compressors that are commanded on when the circuit state is normal.                                                                                                                                                                                                                                        |
| Primary Heating Capacity                           | 126                      | R          | 0-100% x 10                                | NA                             | The capacity using a standard heating source for non-heat pump units (and standard heating is not being used for reheat purposes). Otherwise, it The capacity from a compressorized heating source for heat pump units.                                                                                                                    |
| Supply Fan Operation Output                        | 127                      | R          | 0=Off<br>1=On                              | NA                             | Indicates if the supply fan operation output signal is on or off.                                                                                                                                                                                                                                                                          |
| Outdoor Air Temperature                            | 128                      | R          | NA                                         | NA                             | The current value of the outdoor air sensor. Displayed when the network is overriding the local sensor.                                                                                                                                                                                                                                    |
| Discharge Air Temperature Economizer Setpoint      | 129                      | W          | 40-100°F x 10<br>4.4-37.8°C x 10           | 55°F x 10<br>12.8°C x 10       | Controls the discharge air temperature to this setpoint when the unit is in economizer mode and UseDATClgSpt = No (from the Cooling Set-Up menu).                                                                                                                                                                                          |
| Supply Fan Duct Static Pressure Setpoint (DSP)     | 130                      | W          | 0.2-4" wc x 10                             | 1" wc x 10                     | Supply fan is modulated to maintain the DSP at this setpoint when SupFanCtrl is set to DSP=1. Only applies to units configured with a supply fan DSP sensor.                                                                                                                                                                               |
| Supply Fan Building Static Pressure (BSP) Setpoint | 131                      | W          | -0.25-0.25" x 100<br>-62.2-62.2 Pa x 100   | 0.05" x 100<br>12.4 Pa x 100   | Supply fan is modulated to maintain the BSP at this setpoint when SupFanCtrl is set to BSP=4. Only applies to units configured with a supply fan BSP sensor.                                                                                                                                                                               |
| Supply Fan Outdoor Air Flow Setpoint               | 132                      | W          | 0-6000 cfm x 10                            | 2000 cfm x 10                  | Setpoint used to control the supply fan when the Supply Air Fan Capacity Control is set to Flow and the unit is configured for a Damper Type of 100OA(2) or 100wRec(5).                                                                                                                                                                    |
|                                                    | 133                      | W          | 0-6000 cfm x 10                            | 2000 cfm x 10                  |                                                                                                                                                                                                                                                                                                                                            |
| Return Air Fan DSP Setpoint                        | 134                      | W          | -5.0-0 in<br>0-1245 Pa                     | -1.0 in<br>249 Pa              | The return air fan duct static pressure setpoint. When the RAF/EAF control is set to DSP, the return/exhaust fans are modulated to maintain DSP at this setpoint.                                                                                                                                                                          |
| Effective Exhaust Plenum Static Pressure Setpoint  | 135                      | R          | 0-1 in<br>0-249 Pa                         | NA                             | Effective plenum static pressure setpoint. When the unit is equipped with a set of modulating relief dampers, the dampers are modulated to maintain the measured exhaust air plenum static pressure at this setpoint.                                                                                                                      |
| Building Static Pressure Setpoint                  | 137                      | W          | -0.25-0.25" x 1000<br>-62.2-62.2 Pa x 1000 | 0.05" x 1000<br>12.4 Pa x 1000 | The return air or exhaust fan is modulated to maintain the building static pressure sensor input at this setpoint when the ExhRetFanCtrl is set to BSP=2. Applies only if the unit is configured for a modulating return/exhaust fan.                                                                                                      |
| Occupied Cooling Setpoint                          | 138                      | W          | 0-100°F x 10<br>-17.8-37.8°C x 10          | 72°F x 10<br>22.2°C x 10       | Sets the Occupied Cooling Setpoint value when it is not controlled by another function. It uses maximum and minimum limits, so if the Present Value is set beyond the acceptable range from the network, the value is ignored and the unit controller continues to control to the last valid value.                                        |
| Unoccupied Cooling Setpoint                        | 139                      | W          | 40-100°F x 10<br>4.4-37.8°C x 10           | 85°F x 10<br>29.4°C x 10       | Sets the temperature above which the unit starts and provides cooling during unoccupied periods. An optional space temperature sensor is required for unoccupied cooling operation. If the network setpoint is outside the valid min/max range, the value is ignored and the unit controller continues to control to the last valid value. |
| Occupied Heating Setpoint                          | 140                      | W          | 0-100°F x 10<br>-17.8-37.8°C x 10          | 68°F x 10<br>20°C x 10         | Sets the Occupied Heating Setpoint value when it is not controlled by other function. If the network setpoint is outside the valid min/max range, the value is ignored and the unit controller continues to control to the last valid value.                                                                                               |
| Unoccupied Heating Setpoint                        | 141                      | W          | 40-100°F x 10<br>4.4-37.8°C x 10           | 55°F x 10<br>12.8°C x 10       | Sets the temperature below which the unit starts and provides heating during unoccupied periods. An optional space temperature sensor is required for unoccupied heating operation. If the network setpoint is outside the valid min/max range, the value is ignored and the unit controller continues to control to the last valid value. |
| Discharge Air Cooling Setpoint                     | 142                      | W          | 40-100°F x 10<br>4.4-37.8°C x 10           | 55°F x 10<br>12.8°C x 10       | Sets the network cooling discharge setpoint only when ClgDATReset = Network. The controller limits the value written between the DefaultDATClgSetpt (143) and the maximum cooling setpoint. Refer to the HMI Commission Unit/Cooling Set-Up menu.                                                                                          |

| Description                                       | Holding Register (4xxxx) | Read/Write | Range                                  | Default                      | Notes                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|---------------------------------------------------|--------------------------|------------|----------------------------------------|------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Minimum Discharge Air Cooling Setpoint            | 143                      | W          | 40-100°F x 10<br>4.4-37.8°C x 10       | 55°F x 10<br>12.8°C x 10     | Sets the minimum allowable discharge air cooling setpoint determined by the discharge air temperature reset function as well as the default network discharge air cooling setpoint. The unit controller uses the last valid value it received from either the network or unit controller HMI.                                                                                                                                            |
| Outdoor Air Damper Position                       | 144                      | R          | 0-100% x 10                            | NA                           | The current percentage of economizer capacity or outdoor air damper position.                                                                                                                                                                                                                                                                                                                                                            |
| Outdoor Air Damper Minimum Position Input         | 145                      | W          | 0-100% x 10                            | 0% x 10                      | Sets the outdoor air damper minimum position setpoint. The minimum outdoor air damper position input setpoint uses this value when 1) it is not controlled by another function and 2) when Min OAPosNetIn = Network via the unit controller HMI.<br><br>The controller limits the network value written between the DCV Limit and the Vent Limit in the Min OA Damper menu. Applies only to units configured with an airside economizer. |
| Discharge Air Heating Setpoint (Electric Heat)    | 146                      | W          | 40-105°F x 10<br>4.4-40.6°C x 10       | 85°F x 10<br>29.4°C x 10     | The effective discharge air heating setpoint that the unit is attempting to maintain. Applies to units configured for electric heating.                                                                                                                                                                                                                                                                                                  |
| Discharge Air Heating Setpoint (No Electric Heat) | 147                      | W          | 40-140°F x 10<br>4.4-60°C x 10         | 85°F x 10<br>29.4°C x 10     | The effective discharge air heating setpoint that the unit is attempting to maintain.                                                                                                                                                                                                                                                                                                                                                    |
| Maximum Discharge Air Heating Setpoint            | 148                      | W          | 40-130°F x 10<br>4.4-54°C x 10         | 120°F x 10<br>48.9°C x 10    | Sets the maximum allowable discharge air heating setpoint determined by the discharge air temperature reset function as well as the default network discharge air heating setpoint. It is also changeable via the unit controller HMI. The controller uses the last valid value it last received from either the network or the controller HMI.                                                                                          |
| Relative Humidity Input 1                         | 149                      | W          | 0-164% x 10                            | 164% x 10                    | Sets the space relative humidity from the network. If the network value becomes unreliable, the humidity reverts to the value provided by the attached relative humidity sensor.                                                                                                                                                                                                                                                         |
| Relative Humidity Input 2                         | 150                      | W          | 0-164% x 10                            | 164% x 10                    | Sets the space relative humidity from the network. If the network value becomes unreliable, the humidity reverts to the value provided by the attached relative humidity sensor.                                                                                                                                                                                                                                                         |
| Secondary Heating Capacity                        | 151                      | R          | 0-100% x 10                            | NA                           | The capacity from a standard heat source for heat pump units. Otherwise, secondary heating capacity is not applicable.                                                                                                                                                                                                                                                                                                                   |
| Supply Fan Capacity Input                         | 152                      | W          | 0-164% x 10                            | 164% x 10                    | Sets the supply fan VFD speed when the SupFanCtrl is set to Spd/Net=4. If the network value written is outside of the min/max setpoint range, the value is ignored and the unit controller continues to control to the last valid value.                                                                                                                                                                                                 |
| Return Fan Capacity Input                         | 153                      | W          | 0-164% x 10                            | 164% x 10                    | Sets the return/exhaust fan VFD speed when ExhRetFanCtrl is set to Speed=5. If the network value written is outside of the min/max setpoint range, the value is ignored and the unit controller continues to control to the last valid value.                                                                                                                                                                                            |
| Effective Discharge Air Temperature Setpoint      | 154                      | R          | -83-147°F x 10<br>-64-64°C x 10        | NA                           | The Effective Heating Discharge Temperature Setpoint if the unit is in the heating state. If not, it The Discharge Air Cooling Setpoint when the unit is in any other operating state.                                                                                                                                                                                                                                                   |
| Warning Alarm                                     | 155                      | R          | 0-255                                  | NA                           | The highest priority active warning alarm. This object is set to zero if no warning alarms are active.                                                                                                                                                                                                                                                                                                                                   |
| Problem Alarm                                     | 156                      | R          | 0-255                                  | NA                           | The highest priority active problem alarm. This object is set to zero if no problem alarms are active.                                                                                                                                                                                                                                                                                                                                   |
| Fault Alarm                                       | 157                      | R          | 0-255                                  | NA                           | The highest priority active warning alarm. This object is set to zero if no warning alarms are active.                                                                                                                                                                                                                                                                                                                                   |
| Alarm Value                                       | 158                      | R          | 0-255                                  | NA                           | The alarm value allows individual notification of the highest priority active alarm. This object is set to zero if no alarms are active.                                                                                                                                                                                                                                                                                                 |
| Space Temperature Input                           | 159                      | W          | -83.2-621.8°F x 10<br>-64-327.7°C x 10 | 621.8°F x 10<br>327.7°C x 10 | The current space or zone temperature input supplied by the network. If this network value becomes unreliable, the temperature reverts to the local space temperature sensor value.                                                                                                                                                                                                                                                      |
| Outdoor Air Temperature Input                     | 160                      | W          | -83-622°F x 10<br>-64-327.7°C x 10     | 622°F x 10<br>327.7°C x 10   | The current outdoor air temperature input supplied by the network. If this network value becomes unreliable, the temperature reverts to the local outdoor temperature sensor value.                                                                                                                                                                                                                                                      |
| Space IAQ (CO <sub>2</sub> ) Input                | 161                      | W          | 0-32767 ppm                            | 32767                        | Indicates the current space CO <sub>2</sub> level from the network. This value takes priority over a locally wired sensor. It is used for minimum OA damper control and only applies if ExtOAInput = CO2VDC, CO2mA or CO2QMX1.                                                                                                                                                                                                           |

| Description                                              | Holding Register (4xxxx) | Read/Write | Range                                    | Default                       | Notes                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|----------------------------------------------------------|--------------------------|------------|------------------------------------------|-------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Economizer Enable                                        | 162                      | W          | -1=Null<br>0=Off (Disabled)<br>1= Enable | -1 (Null)                     | Allows economizer cooling to be enabled or disabled by the network when Economizer Status is set to Enabled. Applies if the unit is configured for modulating economizer and when Ctrl Mode = Auto.                                                                                                                                                                                                                                                                                                                                                                                                                      |
|                                                          | 163                      | W          | 0-100% x 10                              | 100% x 10                     | If EconEnable = 0, then the economizer is disabled by the network and EconoStatus is set to OffNet.<br>If EconEnable = -1 (null), it is not being limited by the network.<br>If EconEnable = 1 and EconEnablePct is greater than 0, the economizer is enabled to a maximum EconEnablePct by the network and takes precedent over local enable/disable configuration.<br>If EconoEnable = 1 and EconoEnablePct = 0, economizing is disabled and EconoStatus is set to OffNet.<br><br>Economizer operation is disabled locally when the unit is in dehumidification, regardless of the network Economizer Enable settings. |
| Primary Cool Enable                                      | 164                      | W          | -1=Null<br>0=Off (Disabled)<br>1= Enable | -1 (Null)                     | Allows primary cooling to be enabled or disabled by the network when Cooling Status is set to Enabled. Applies only when Ctrl Mode = Auto. CoolEnablePct The percentage of cooling capacity in an enabled state.                                                                                                                                                                                                                                                                                                                                                                                                         |
|                                                          | 165                      | W          | 0-100% x 10                              | 100% x 10                     | If CoolEnable = 0, then the primary cooling is disabled by the network and ClgStatus is set to OffNet.<br>If CoolEnable is -1 (null), it is not being controlled by the network.<br>If CoolEnable = 1 and CoolEnablePct is greater than 0, the primary cooling is enabled by the network and takes precedent over local enable/disable configuration.<br>If CoolEnable = 1 and CoolEnablePct = 0, primary cooling is disabled and ClgStatus is set to OffNet.                                                                                                                                                            |
| Primary Heat Enable                                      | 166                      | W          | -1=Null<br>0=Off (Disabled)<br>1= Enable | -1 (Null)                     | Allows primary heating to be enabled or disabled by the network when Heating Status is set to Enabled. Applies only if 1) the unit is configured for heating and 2) when Ctrl Mode = Auto.                                                                                                                                                                                                                                                                                                                                                                                                                               |
|                                                          | 167                      | W          | 0-100% x 10                              | 100% x 10                     | If HeatEnable = 0, then the primary heating is disabled by the network and heating status is set to OffNet.<br>If HeatEnable = -1 (null), it is not being controlled by the network.<br>If HeatEnable = 1 and HeatEnablePct is greater than 0, the primary heating is enabled to a maximum of HeatEnablePct by the network and takes precedent over local enable/disable configuration.<br>If HeatEnable = 1 and HeatEnablePct = 0, primary heating is disabled and HeatingStatus is set to OffNet.                                                                                                                      |
| Humidity Sensor 1 Setpoint Input                         | 168                      | W          | 0-100% x 10                              | 50% x 10                      | Current humidity sensor setpoint from one of the two available sensors. Relative Humidity 1 uses Humidity1SP and Relative Humidity 2 uses Humidity2SP. The temperature reverts to the local space temperature sensor value if this network value becomes unreliable. It is valid only if Dehum Method is RelHum1, RelHum2, or RelHum12.                                                                                                                                                                                                                                                                                  |
| Humidity Sensor 2 Setpoint Input                         | 169                      |            |                                          |                               |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Dewpoint Setpoint 1                                      | 170                      | W          | 0-100°F x 10<br>-17.8-37.8°C x 10        | 50°F x 10<br>10°C x 10        | Current dewpoint setpoint. Used for dehumidification control, which also corresponds to one of the two relative humidity sensor inputs.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Dewpoint Setpoint 2                                      | 171                      |            |                                          |                               |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Supply Fan Outdoor Air Flow                              | 172                      | R          | 0-60000 cfm x 10<br>0-28320 l/s x 10     | NA                            | The amount of outdoor airflow entering the unit. Applies only to units configured with Outdoor Air Flow Signal set to VDC or mA.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|                                                          | 173                      |            |                                          |                               |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| HMI Supply Fan Outdoor Air Flow                          | 172                      |            |                                          |                               |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|                                                          | 173                      |            |                                          |                               |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Reheat Capacity                                          | 174                      | R          | 0-100% x 10                              | NA                            | Indicates the current percentage of the unit's reheat capacity. Applies only to units configured for reheat. With full control, the unit's cooling, heating and reheat capacity is controlled based on temperature inputs to the controller.                                                                                                                                                                                                                                                                                                                                                                             |
| Outdoor Airflow Setpoint                                 | 175-176                  | W          | 0-60000 cfm x 10<br>0-28320 l/s          | 2000 cfm x 10<br>944 l/s x 10 | Minimum outdoor air setpoint. Applies only to units configured with Outdoor Air Flow Signal set to VDC or mA.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| Minimum Leaving Coil Temperature Setpoint                | 177                      | W          | 42-70°F x 10<br>5.6-21.1°C x 10          | 45°F x 10<br>7.2°C x 10       | Determines the minimum value for the leaving coil temperature (LCT) setpoint. Is also used in calculating the LCT setpoint when the LCTSPtRst is not set to None or Network.                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| DX Coil Bypass Minimum Leaving Coil Temperature Setpoint | 178                      | W          | 45-65°F x 10<br>7.2-18.3°C x 10          | 45°F x 10<br>7.2°C x 10       | Determines the minimum value for the DX Coil Bypass (DXBP) leaving coil temperature (LCT) setpoint. Is also used in calculating the LCT setpoint when the DXBPLCTSPtRst is not set to None or Network.                                                                                                                                                                                                                                                                                                                                                                                                                   |

| Description                                              | Holding Register (4xxxx) | Read/Write | Range                           | Default                  | Notes                                                                                                                                                                                                                                                                                                                                                                 |
|----------------------------------------------------------|--------------------------|------------|---------------------------------|--------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Maximum Leaving Coil Temperature Setpoint                | 179                      | W          | 42-70°F x 10<br>5.6-21.1°C x 10 | 52°F x 10<br>11.1°C x 10 | Determines the maximum value for the leaving coil temperature (LCT) setpoint. Is also used in calculating the LCT setpoint when the LCTSPtRst is not set to None or Network.                                                                                                                                                                                          |
| DX Coil Bypass Maximum Leaving Coil Temperature Setpoint | 180                      | W          | 45-65°F x 10<br>7.2-18.3°C x 10 | 52°F x 10<br>11.1°C x 10 | Determines the maximum value for the DX Coil Bypass (DXBP) leaving coil temperature (LCT) setpoint. Is also used in calculating the LCT setpoint when the DXBPLCTSPtRst is not set to None or Network.                                                                                                                                                                |
| Leaving Coil Temperature Setpoint                        | 181                      | W          | 45-70°F x 10<br>7.2-21.1°C x 10 | 52°F x 10<br>11.1°C x 10 | The current effective leaving coil setpoint when dehumidification is active (Dehum Status = Active). Applies when unit is equipped with modulating cooling (such as chilled water or variable speed compressor) and the reheat type is not None or DX Bypass Only. This value can only be written when LCTSPtRst is set to Network.                                   |
| Leaving Coil Temperature Setpoint - Electric Heat        | 182                      | W          | 32-70°F x 10<br>0-21.1°C x 10   | 52°F x 10<br>11.1°C x 10 | The current effective leaving coil setpoint when dehumidification is active (Dehum Status = Active). Applies when unit is configured for SCR electric heat. This value can only be written when LCTSPtRst is set to Network.                                                                                                                                          |
| Leaving Coil Temperature Setpoint                        | 183                      | W          | 45-65°F x 10<br>7.2-18.3°C x 10 | 52°F x 10<br>11.1°C x 10 | The current effective leaving coil setpoint when the DX coil bypass (DXBP) function is active. This setpoint applies only if the unit is equipped with modulating cooling (such variable speed compressor), the reheat type includes DX coil bypass (DXBP) and when the DXBP function is active. This value can only be written when DXBPLCTSPtRst is set to Network. |
| Maximum Purge Time                                       | 184                      | W          | 0-300 Min x 10                  | 0 Min x 10               | Enables purge operation prior to any scheduled start by the amount of time defined by the maximum purge time. Purge operation is disabled if maximum purge time is set to zero.                                                                                                                                                                                       |
| Outdoor Air Damper Maximum Position                      | 186                      | R          | 0-100% x 10                     | 100% x 10                | Effective Outdoor Air Damper maximum position.                                                                                                                                                                                                                                                                                                                        |
| Supply Fan Flow Setpoint                                 | 187-188                  | W          | 0-6000 cfm x 10                 | 2000 cfm x 10            | Sets the supply fan so it can modulate airflow to maintain this setpoint. Applies when the SAF Capacity Control (SupFanCtrl) is set to Flow, the Damper Type is either 300A or Econ or Econ_FDD, and Supply Fan Flow Input (SAFFlowInput) is not None.                                                                                                                |
| Return/Exhaust Fan Flow Setpoint                         | 189-190                  | R          | 0-6000 cfm                      | 2000 cfm x 10            | Sets the return or exhaust fan flow setpoint. The return/exhaust fan is modulated to maintain this setpoint when the Return/Exhaust Fan Control Method is set to Flow. Applies when the unit is configured for an RFEF Flow Input.                                                                                                                                    |
| Supply Fan Hours                                         | 191-192                  | R          | 0-999999 Hrs                    | NA                       | The accumulated supply fan operating hours. This can be reset from the network.                                                                                                                                                                                                                                                                                       |
| Return Fan Hours                                         | 193-194                  | R          | 0-999999 Hrs                    | NA                       | The accumulated return or exhaust fan operating hours. This can be reset from the network.                                                                                                                                                                                                                                                                            |
| Reheat Hours                                             | 195-196                  | R          | 0-999999 Hrs                    | NA                       | The accumulated hours of unit reheat operation. This can be reset from the network.                                                                                                                                                                                                                                                                                   |
| Cooling Hours                                            | 197-198                  | R          | 0-999999 Hrs                    | NA                       | The accumulated mechanical cooling operating hours. This can be reset from the network.                                                                                                                                                                                                                                                                               |
| Variable Compressor 1 Hours                              | 199-200                  | R          | 0-999999 Hrs                    | NA                       | The accumulated operating hours for each variable compressor. This can be reset from the network.                                                                                                                                                                                                                                                                     |
| Variable Compressor 2 Hours                              | 201-202                  |            |                                 |                          |                                                                                                                                                                                                                                                                                                                                                                       |
| Variable Compressor 3 Hours                              | 203-204                  |            |                                 |                          |                                                                                                                                                                                                                                                                                                                                                                       |
| Fixed Compressor 1 Hours                                 | 205-206                  |            |                                 |                          |                                                                                                                                                                                                                                                                                                                                                                       |
| Fixed Compressor 2 Hours                                 | 207-208                  |            |                                 |                          |                                                                                                                                                                                                                                                                                                                                                                       |
| Fixed Compressor 3 Hours                                 | 209-210                  |            |                                 |                          |                                                                                                                                                                                                                                                                                                                                                                       |
| Fixed Compressor 4 Hours                                 | 211-212                  | R          | 0-999999 Hrs                    | NA                       | Circuit 1 and 2 accumulated operating hours by compressor. This can be reset from the network.                                                                                                                                                                                                                                                                        |
| Fixed Compressor 5 Hours                                 | 213-214                  |            |                                 |                          |                                                                                                                                                                                                                                                                                                                                                                       |
| Fixed Compressor 6 Hours                                 | 215-216                  |            |                                 |                          |                                                                                                                                                                                                                                                                                                                                                                       |
| Fixed Compressor 1 Hours                                 | 217-218                  |            |                                 |                          |                                                                                                                                                                                                                                                                                                                                                                       |
| Fixed Compressor 3 Hours                                 | 219-220                  |            |                                 |                          |                                                                                                                                                                                                                                                                                                                                                                       |
| Heating Hours                                            | 223-224                  | R          | 0-999999 Hrs                    | NA                       | The accumulated heating operating hours. This can be reset from the network.                                                                                                                                                                                                                                                                                          |
| Economizer Hours                                         | 225-226                  | R          | 0-999999 Hrs                    | NA                       | The accumulated economizer operating hours. This can be reset from the network.                                                                                                                                                                                                                                                                                       |
| Tenant Override Hours                                    | 227-228                  | R          | 0-999999 Hrs                    | NA                       | The accumulated tenant override operating hours. This can be reset from the network.                                                                                                                                                                                                                                                                                  |
| Dehumidification Hours                                   | 229-230                  | R          | 0-999999 Hrs                    | NA                       | The accumulated dehumidification operating hours. This can be reset from the network.                                                                                                                                                                                                                                                                                 |
| Energy Recovery Hours                                    | 231-232                  | R          | 0-999999 Hrs                    | NA                       | The accumulated energy recovery wheel operating hours. This can be reset from the network.                                                                                                                                                                                                                                                                            |
| SCR Preheat Hours                                        | 233-234                  | R          | 0-999999 Hrs                    | NA                       | The accumulated preheat operating hours for SCR heating type. This can be reset from the network.                                                                                                                                                                                                                                                                     |

| Description              | Holding Register (4xxxx) | Read/Write | Range                                                                                                                   | Default | Notes                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|--------------------------|--------------------------|------------|-------------------------------------------------------------------------------------------------------------------------|---------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| UV Light Hours           | 235-236                  | R          | 0-999999 Hrs                                                                                                            | NA      | The accumulated operating hours for the UV light. Applies when an IAQ sensor is present and unit is configured for one of the Monitoring Packages (IAQ, IAQRef, IAQPwr or IAQRP.) This can be reset from the network.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Unit Status              | 245                      | R          | 0=Enable<br>1=OffMan<br>2=OffManCtrl<br>3=OffNet<br>4=OffAlm<br>5=OffRetry<br>6=OffPassVnt<br>7=OffSnsrCfg<br>8=OffEvac | NA      | Indicates whether or not the unit is enabled to operate. Unit commands may be ignored when the unit is Off due to alarm or operating condition. Does not apply when Control Type = RefOnly.<br>0 = Enable (Unit is in operation. Conditions #1-8 are not active)<br>1 = OffMan (Control Mode = Off)<br>2 = OffManCtrl (Manual Control = On)<br>3 = OffNet (Control Mode = Auto and NetApplicMode = Off)<br>4 = OffAlm (Fault alarm is active)<br>5 = OffRetry (Fan Retry is active)<br>6 = OffPassVnt (Optional passive ventilation functionality is active, forcing the unit to an Off state)<br>7 = OffSnsrCfg (Forces the unit to an Off state during space temperature sensor configuration or power-up. This allows the sensor enough time to configure so that it can provide reliable data to the Unit controller. Applies when space temperature is used for the control temperature source)<br>8 = OffEvac (Evac mode is active) |
| Cooling Status           | 246                      | R          | 0=Enabled<br>1=None<br>2=OffAmb<br>3=OffAlm<br>4=OffNet<br>5=OffMan<br>6=NA<br>7=CfgErr*                                | NA      | Indicates if cooling is currently enabled. If not, the reason is displayed.<br>*CgErr = cooling is disabled due to an incorrect unit configuration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Economizer Status        | 247                      | R          | 0=Enabled<br>1=None<br>2=OffAmb<br>3=OffAlm<br>4=OffNet<br>5=OffMan<br>6=OffDehum                                       | NA      | Indicates if the economizer is currently enabled. If the economizer is disabled, the reason is indicated.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| Primary Heating Status   | 248                      | R          | 0=Enabled<br>1=None<br>2=OffAmb<br>3=OffAlm<br>4=OffNet<br>5=OffMan<br>6=OffDehum<br>7=CfgErr                           | NA      | Indicates if the primary (standard) heating source is enabled. If not, the reason is indicated.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| Application Mode         | 249                      | RW         | 0=Off<br>1=HeatOnly<br>2=CoolOnly<br>3=FanOnly<br>4=Auto<br>5=NA                                                        | 5=NA    | Sets the unit in an application mode. While it does not "force" the unit into any state, it does disable certain unit operations and may restrict network commands. For example, an Application Mode of "Cool Only" disables heating, "Heat Only" disables cooling, and "Fan Only" disables heating and cooling.<br>Application Mode has no affect unless Control Mode is set to Auto (Ctrl Mode = Auto). Control Mode is only set at the unit controller HMI.                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| Occupancy Status         | 250                      | R          | 0=Occ<br>1=Unocc<br>2=TntOvrd                                                                                           | NA      | Indicates if the unit is currently in an occupied, unoccupied, or tenant override mode of operation.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Occupancy Mode (Network) | 251                      | RW         | 0=Occ<br>1=Unocc<br>2=TntOvrd<br>3=Standby<br>4=Auto                                                                    | 4=Auto  | Sets the unit into a different occupancy mode. The request is typically sent by a wall-mounted occupant-interface module or a supervisory device used to manually control occupancy modes or to override the scheduled occupancy.<br>Note that OccManCmd is used only as an override.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Current State            | 252                      | RW         | 0=Occ<br>1=Unocc<br>2=TntOvrd<br>3=Standby<br>4=NA                                                                      | 4=NA    | Commands the occupancy function of the unit controller when Occupancy Mode is set to Auto. A scheduler or a supervisory node typically sends the request.<br>Note that Current State is generally used for daily Occupancy (Occ/Unocc) commands. It is active only when OccManCmd (251) = Auto.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| Next State               | 253                      | RW         | 0=Occ<br>1=Unocc<br>2=TntOvrd<br>3=Standby<br>4=NA                                                                      | 4=NA    | Commands the occupancy function of the unit controller when Occupancy Mode is set to Auto. A scheduler or a supervisory node typically sends the request.<br>Next State and TimeToNextState (254) are used only when implementing "Optimal Start" functionality.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |

| Description                 | Holding Register (4xxxx) | Read/Write | Range                                                                                         | Default  | Notes                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|-----------------------------|--------------------------|------------|-----------------------------------------------------------------------------------------------|----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Time to Next State          | 254                      | RW         | 0-65535                                                                                       | 65535    | Network input that determines the occupancy scheduler time from one state to the next (occupied, unoccupied, standby, auto).<br>TimeToNextState and NextState (253) are used only when implementing "Optimal Start" functionality.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Emergency Override          | 255                      | RW         | 0=Normal<br>1=Off                                                                             | 0=Normal | Shuts off the Unit controller. If it is set to Off, the Unit controller cannot start based on a time clock or any other means. Doing so also shuts off a network signal and puts Unit Status = OffNet. The only way to start the Unit controller is to change the value to Normal.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Supply Fan Control          | 256                      | RW         | 0=DSP<br>1=Speed<br>2=1ZnVAV<br>3=BSP<br>4=CO2<br>5=Flow<br>6=CAV                             | 6=CAV    | Supply fan control options are described as follows:<br><br>0=DSP (Duct Static Pressure. The supply fan modulates to maintain the duct static pressure at the duct static pressure setpoint, SAFDSPSpt. Does not apply when the Ctrl Type is configured for 1ZnVAV).<br><br>1=Speed (The supply fan modulates to maintain a speed command provided by the unit controller HMI or network command).<br><br>2=1ZnVAV (Single Zone VAV. The supply fan modulates to maintain the control temperature at the Occupied Cooling Setpoint (OccClgSpt) or the Occupied Heating Setpoint (OccHtgSpt) when the unit is running. Only applies when Ctrl Type is configured for 1ZnVAV).<br><br>3=BSP (Building Static Pressure. The supply fan modulates to maintain the BSP setpoint (BSPSpt). Available when the unit is running and configured for damper type 100OA. Does not apply when Ctrl Type is configured for 1ZnVAV).<br><br>4=CO <sub>2</sub> (The supply fan modulates based on the CO <sub>2</sub> level between allowable range. Available when the unit is running and configured for damper type 100OA (100% x 10 outdoor air). Does not apply when the Ctrl Type is configured for 1ZnVAV).<br><br>5=Flow (The supply fan modulates to maintain the supply airflow setpoint (SAFlowSpt). Available when the unit is running and configured for damper type 100OA. Does not apply when Ctrl Type is configured for 1ZnVAV).<br><br>6=CAV (Constant Air Volume. Unit controls to a constant effective maximum supply fan (SAF) capacity, EffMaxSAFCap. Does not apply when the Ctrl Type is configured for single zone VAV (1ZnVAV)). |
| Return Fan Capacity Control | 257                      | W          | 0=CAV<br>1=BSP<br>2=Tracking<br>3=DSP<br>4=Speed<br>5=Flow<br>6=OAD<br>7=FlowDiff             | 1=BSP    | Selects the method used to control the return or exhaust fan airflow.<br><br>0=CAV (Return/Exhaust fan is held at the MaxRFEFCap value when in operation)<br><br>1=BSP (Return/exhaust fan airflow is controlled independently of the supply fan to maintain building static pressure setpoint)<br><br>2=Tracking (If unit is equipped with VFD, airflow is controlled based on an adjustable tracking relationship between the supply fan and return fan)<br><br>3=DSP (Return fan is modulated to maintain the Duct Static Pressure at the RAFDSPSpt when in operation)<br><br>4=Speed (Return/exhaust fan airflow is controlled to a VFD speed setpoint adjusted via the Return Fan Capacity Input)<br><br>5=Flow (unit modulates to maintain the RFEFFlow Setpoint when in operation)<br><br>6=OAD (Exhaust fan airflow is controlled independently of the supply fan airflow based on the outdoor air damper position)<br><br>7=FlowDiff (Return/exhaust fan tracks to the SAFFlow)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Primary Heating Status      | 258                      | R          | 0=Enabled<br>1=None<br>2=OffAmb<br>3=OffAlm<br>4=OffNet<br>5=OffMan<br>6=OffDehum<br>7=CtgErr | NA       | Indicates if the primary (standard) heating source is enabled. If not, the reason is indicated.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |

| Description                  | Holding Register (4xxxx) | Read/Write | Range                                                                              | Default   | Notes                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|------------------------------|--------------------------|------------|------------------------------------------------------------------------------------|-----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| VAV Box Output Status        | 259                      | R          | 0=Heat<br>1=Cool                                                                   | 0=Heat    | The VAV box output is provided for interlocking field VAV operation with the unit heating or cooling. In most cases:<br>Heat = Unit is in any heating state, Start, or Recirc.<br>Cool = Unit is in any other state.<br>Applies only to units configured with supply fan VFDs.                                                                                                                                                                                                                                                                                                                                                                                    |
| Unit State                   | 260                      | R          | 0=Off<br>1=Start<br>2=Recirc<br>3=FanOnly<br>4=MinDAT<br>5=Htg<br>6=Econo<br>7=Clg | NA        | The current operating mode of the unit.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| Units of Measurement         | 261                      | R          | 0=Metric<br>1=English                                                              | 1=English | Sets the type of units (English or Metric) that are passed from the Unit controller to the Modbus network. Cycle power for change to take effect.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| Passive Ventilation          | 262                      | W          | 0=Off<br>1=On                                                                      | 0=Off     | Passive ventilation is activated by a locally-supplied contact closure or from a network command. When Passive ventilation is active, the following occurs:<br>1. Fan output is overridden to On<br>2. The Unit State is forced to Off*<br>3. The return/exhaust fan is commanded on and set to the return/exhaust fan air fan ventilation capacity value<br>4. Outdoor air dampers are held at 0% x 10<br>5. A passive ventilation Event message is generated<br>*Note that the Unit Status is forced to Off when the optional passive ventilation function is active.                                                                                           |
| Energy Recovery Wheel Status | 263                      | R          | 0=Off<br>1=On                                                                      | 0=Off     | The command status (On or Off) of the energy recovery wheel.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| AHU Local/Network            | 264                      | R          | 0=Network<br>1=Local                                                               | 0=Network | Indicates if the unit controller is set for local or network control. AHU Loc/Net can only be changed from the unit controller HMI. It must be set to Network (0) for most of the writeable network properties to apply.                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Control Temp Source          | 265                      | W          | 0=RAT<br>1=Space<br>2=OAT<br>3=None                                                | 0=RAT     | Selects the temperature sensor input to be used for the unit heating/cooling changeover or zone cooling and heating capacity change decisions. For example, if CtrlTempSrc is set to "Return Air Temperature (RAT)," then the Control Temp parameter reads the same value as the Return Air parameter. When CtrlTempSrc is set to "None" during regular occupied operation, the unit uses the discharge air temperature (DAT) sensor to heat or cool to the cooling DAT setpoint.<br>0=RAT (Not available on 100% x 10 outdoor air temperature (OAT) units)<br>1=Space<br>2=OAT (Available on ControlType=DAT only)<br>3=None (Available on ControlType=DAT only) |
| Dehumidification Status      | 266                      | R          | 0=Inactive<br>1=Active                                                             | NA        | Indicates if the dehumidification operation is currently active.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Network Demand Shed Enable   | 267                      | W          | 0=Inactive<br>1=Auto<br>2=Manual                                                   | NA        | Enables the demand shed functionality. For this feature to be active, 1) the DemandShed object in the HtgClg ChgOvr Set-Up HMI menu must be set to Enable, and 2) Network Demand Shed Enable must be set to Auto or Manual.                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Morning Warmup Status        | 268                      | R          | 0=Inactive<br>1=Active                                                             | NA        | Indicates if morning warm-up is currently active.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| Free Cooling Status          | 269                      | R          | 0=Unavail<br>1=Avail                                                               | NA        | Indicates if free cooling is currently available.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| Remote Setpoint Source       | 270                      | W          | 0=None<br>1=AI                                                                     | 0=None    | Configures occupied setpoints from up to three optional remote mounted space sensor analog inputs. When RemSptSrc is set to None, the occupied cooling setpoint (OccClgSpt) and the occupied heating setpoint (OccHtgSpt) are configurable from both the Unit controller HMI and the network. Note that occupied heating/cooling setpoint values change with the last valid value set from either the network or unit controller.                                                                                                                                                                                                                                 |
| Remote Setpoint Source       | 271                      | W          | 0=None<br>1=QMX1<br>2=QMX2<br>3=QMX3                                               | 0=None    | Configures occupied setpoints from up to three optional remote mounted QMX space sensor inputs. When RemSptSrc is set to None, the occupied cooling setpoint (OccClgSpt) and the occupied heating setpoint (OccHtgSpt) are configurable from both the Unit controller HMI and the network. Note that occupied heating/cooling setpoint values change with the last valid value set from either the network or unit controller.                                                                                                                                                                                                                                    |

| Description               | Holding Register (4xxxx)               | Read/Write | Range                                                                                                                                                                                   | Default | Notes                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|---------------------------|----------------------------------------|------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Secondary Heating Status  | 273                                    | R          | 0=Enabled<br>1=None<br>2=OffAmb<br>3=OffAlm<br>4=OffNet<br>5=OffMan<br>6=NA<br>7=NA                                                                                                     | NA      | Indicates if the standard heating source is currently enabled for heat pump units. If heating is disabled, the reason is indicated.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| Supply Air Fan 1-6 Status | 274<br>275<br>276<br>277<br>278<br>279 | R          | 0=OK<br>1=HLL<br>2=TFEI<br>3=TFM<br>4=TFE<br>5=LK<br>6=SKF<br>7=PHA<br>8=UzLo<br>9=UzHi<br>10=UeLo<br>11=UeHi<br>12=NoCm13=OC<br>14=OT<br>15=RRP<br>16=EE<br>17=POC<br>18=AOV<br>19=AUV | NA      | Indicates the status of the 1-6 ECM supply air fans.<br><br>0=OK (No Error) - fan operating normally<br>1=HLL (Hall Sensor Error) - possible external voltage spikes or hardware problem with the fan<br>2=TFEI (Electronics Interior Overheated) - operating temperature for EC fan control components has been exceeded, or a hardware problem with the fan<br>3=TFM (Motor Overheated) operating conditions for fan motor is outside of the expected temperature range, fan load has been exceeded, or a hardware problem with the fan<br>4=TFE (Power Mod Overheated) - operating conditions for module have exceeded the design temperature, input power supply is over/under voltage or fan overload<br>5=LK (Locked Motor) - fan motor may be blocked due to counter flow, dirt, ice, or other impurity<br>6=SKF (Communication Error) - possible voltage spikes or a hardware problem of the fan<br>7=PHA (Phase failure)<br>8=UzLow (DC bus under-voltage)<br>9=UzHigh (DC bus over-voltage)<br>10=UeLow (Main under-voltage)<br>11=UeHigh (Main over-voltage)<br>12=NoCm (No Communication)<br>13=OC (DC bus over-current)<br>14=OT (DC bus over-voltage)<br>15= RRP (backward rotating fan)<br>16=EE (EEPROM read/write fail)<br>17=POC (DC bus peak over-current)<br>18=AOV (AC bus average over-voltage)<br>19= AU (DC bus average under-voltage)<br><br>Note the options above may indicate DC or main voltage parameter values not within the specified range, insufficient fan power supply/experiencing signal disturbances, or a hardware problem with the fan. |
| Return Fan VFD Status     | 284                                    | R          | 1=OK<br>2=Fault<br>3=NoComm                                                                                                                                                             | NA      | Indicates the status of the return/exhaust fan drive.<br><br>1=OK (communication as expected)<br>2=Fault (controller has shut down the VFD due to a fault condition)<br>3=NoComm (controller is not receiving digital input data from the VFD)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |

| Description               | Holding Register (4xxxx) | Read/Write | Range                                                                                                                                                                                   | Default | Notes                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|---------------------------|--------------------------|------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Return Fan 1-4 Status     | 283<br>285<br>286<br>287 | R          | 0=OK<br>1=HLL<br>2=TFEI<br>3=TFM<br>4=TFE<br>5=LK<br>6=SKF<br>7=PHA<br>8=UzLo<br>9=UzHi<br>10=UeLo<br>11=UeHi<br>12=NoCm13=OC<br>14=OT<br>15=RRP<br>16=EE<br>17=POC<br>18=AOV<br>19=AUV | NA      | <p>Indicates the status of the 1-4 ECM return/exhaust air fan. Used for generating a fan failure notification as described below.</p> <p>0=OK (No Error) - fan operating normally<br/>           1=HLL (Hall Sensor Error) - possible external voltage spikes or hardware problem with the fan<br/>           2=TFEI (Electronics Interior Overheated) - operating temperature for EC fan control components has been exceeded, or a hardware problem with the fan<br/>           3=TFM (Motor Overheated) operating conditions for fan motor is outside of the expected temperature range, fan load has been exceeded, or a hardware problem with the fan<br/>           4=TFE (Power Mod Overheated) - operating conditions for module have exceeded the design temperature, input power supply is over/under voltage or fan overload<br/>           5=LK (Locked Motor) - fan motor may be blocked due to counter flow, dirt, ice, or other impurity<br/>           6=SKF (Communication Error) - possible voltage spikes or a hardware problem of the fan<br/>           7=PHA (Phase failure)<br/>           8=UzLow (DC bus under-voltage)<br/>           9=UzHigh (DC bus over-voltage)<br/>           10=UeLow (Main under-voltage)<br/>           11=UeHigh (Main over-voltage)<br/>           12=NoCm (No Communication)<br/>           13=OC (DC bus over-current)<br/>           14=OT (DC bus over-voltage)<br/>           15= RRP (backward rotating fan)<br/>           16=EE (EEPROM read/write fail)<br/>           17=POC (DC bus peak over-current)<br/>           18=AOV (AC bus average over-voltage)<br/>           19= AU (DC bus average under-voltage)</p> <p>Note the options above may indicate DC or main voltage parameter values not within the specified range, insufficient fan power supply/experiencing signal disturbances, or a hardware problem with the fan.</p> |
| Minimum Outdoor Air Reset | 288                      | W          | 0=No<br>1=Yes                                                                                                                                                                           | 0=No    | <p>Enables the network to control the outdoor air minimum position (NetOAMinPos) value. It also allows the network to assume control of the effective minimum ventilation position (MinVentPos), if needed. Applies when the unit is configured with an outdoor airflow measuring station.<sup>1</sup></p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| Supply Fan VFD Status     | 292                      | R          | 0=Fault<br>1=OK<br>2=NoComm                                                                                                                                                             | NA      | <p>Indicates the status of the supply fan VFD drive.</p> <p>0=OK (communication as expected)<br/>           1=Fault (controller has shut down the VFD due to a fault condition)<br/>           2=NoComm (controller is not receiving digital input data from the AZWZVFD)</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Occupancy Source          | 293                      | R          | 0=None<br>1=NetSchd<br>2=IntSchd<br>3=OneEvt<br>4=RemoteSw<br>5=NetManCmd<br>6=OccMode<br>7=TstatTO<br>8=ManTO<br>9=UnitDsbl                                                            | NA      | <p>Indicates the reason the Occupancy Status holding register (250) is Occupied or in Tenant Override.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| Unoccupancy Source        | 294                      | R          | 0=UnoccDehum<br>1=UnoccClg<br>2=UnoccHtg<br>3=IntOptStrt<br>4=NetOptStrt<br>5=IntPurge<br>6=NetPurge<br>7=None<br>8=A2LSnsrPrb<br>9=A2LLLeakPrb                                         | NA      | <p>Indicates the reason the Occupancy Status holding register (250) is Unoccupied.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

| Description                               | Holding Register (4xxxx) | Read/ Write | Range                                                                                                                                  | Default  | Notes                                                                                                                                                                                                                                                                                                                 |
|-------------------------------------------|--------------------------|-------------|----------------------------------------------------------------------------------------------------------------------------------------|----------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Minimum Outdoor Air Source                | 295                      | R           | 0=VentLmt<br>1=OAFlw<br>2=ExtAI<br>3=CO2<br>4=PM25<br>5=TVOC<br>6=Network<br>7=BSP<br>8=RstTLmt<br>9=MaxPos<br>10=FanDiff<br>11=ZeroOA | NA       | Indicates the function controlling the Effective Outdoor Air Minimum Position, EffOAMinPos.                                                                                                                                                                                                                           |
| Defrost Status                            | 296                      | R           | 0=Inactive<br>1=Active                                                                                                                 | NA       | Indicates if either of the circuits is in defrost.                                                                                                                                                                                                                                                                    |
| Generic Analog Inputs (0-10 VDC) 1-8      | 300                      | R           | 0-10 VDC x 10                                                                                                                          | NA       | If an EMB expansion module B is attached to the unit controller and one or more of the eight universal I/O objects is configured for an analog input, a corresponding Modbus register (300-323) is available to read the status via 0-10 VDC, 0-20 mA or 10K NTC sensor input types.                                  |
|                                           | 301                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 302                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 303                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 304                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 305                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 306                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
| Generic Analog Inputs (0-20mA) 1-8        | 307                      | R           | 0-20mA x 10                                                                                                                            | NA       |                                                                                                                                                                                                                                                                                                                       |
|                                           | 308                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 309                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 310                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 311                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 312                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 313                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
| Generic Analog Inputs (10kThermistor) 1-8 | 314                      | R           | -50-250°F x 10                                                                                                                         | NA       |                                                                                                                                                                                                                                                                                                                       |
|                                           | 315                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 316                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 317                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 318                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 319                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 320                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
| Generic Analog Inputs (10kThermistor) 1-8 | 321                      | R           | -50-250°F x 10                                                                                                                         | NA       |                                                                                                                                                                                                                                                                                                                       |
|                                           | 322                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 323                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 324                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 325                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 326                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 327                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
| Generic Analog Outputs 1-8                | 328                      | W           | 0-10V x 10                                                                                                                             | NA       | If an EMB expansion module B is attached to the controller, analog outputs AO1-AO8 are available to the Modbus network as commandable objects 324-335.<br><br>AO1-AO4 can be configured for <i>either</i> a 0-20 mA <i>or</i> a 0-10 VDC direct voltage output signal. AO1-AO4 can be one or the other, but not both. |
|                                           | 329                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 330                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 331                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 332                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 333                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 334                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
| Generic Analog Outputs 1-8                | 335                      | W           | 0-20V x 10                                                                                                                             | X10      |                                                                                                                                                                                                                                                                                                                       |
|                                           | 336                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 337                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 338                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 339                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 340                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 341                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
| Generic Digital Inputs 1-8                | 342                      | R           | 0=Open<br>1=Closed                                                                                                                     | 1=Closed | If an EMB expansion module B is attached to the controller and one or more of the eight universal I/O objects is configured as a digital input, corresponding Modbus registers (336-343) are available to read the status of the sensor inputs.                                                                       |
|                                           | 343                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 344                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 345                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 346                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 347                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |
|                                           | 348                      |             |                                                                                                                                        |          |                                                                                                                                                                                                                                                                                                                       |

| Description                 | Holding Register (4xxxx) | Read/Write | Range                                                                                                                                                                                                                                                                              | Default | Notes                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|-----------------------------|--------------------------|------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Generic Digital Outputs 1-6 | 344                      | R          | 0=Off<br>1=On                                                                                                                                                                                                                                                                      | 0=Off   | If an EMB expansion module B is attached to the controller, the status of up to six digital outputs can be read from the network via Modbus registers 344-349.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|                             | 345                      |            |                                                                                                                                                                                                                                                                                    |         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|                             | 346                      |            |                                                                                                                                                                                                                                                                                    |         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|                             | 347                      |            |                                                                                                                                                                                                                                                                                    |         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|                             | 348                      |            |                                                                                                                                                                                                                                                                                    |         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|                             | 349                      |            |                                                                                                                                                                                                                                                                                    |         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| Control Type                | 350                      | R          | 0=Zone<br>1=DAT<br>2=1ZnVAV<br>3=RO_FC<br>4=RO_FCGE<br>5=RO_DCSA                                                                                                                                                                                                                   | 1=DAT   | Indicates the control strategy configured for the unit controller.<br>0=Zone (Zone temperature control)<br>1=DAT (Discharge temperature control)<br>2=1ZnVAV (Single zone VAV control)<br>3=RO_FC (Refrigeration-only control for fans/compressors)<br>4=RO_FCGE (Refrigeration-only control for fans/compressors gas heat/electric heat)<br>5=RO_DCSA (Refrigeration-only control for DCSA)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Fixed Compressors           | 351                      | R          | 0-8                                                                                                                                                                                                                                                                                | 0       | Indicates the number of fixed compressors on the unit.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| Variable Compressors        | 352                      | R          | 0-4                                                                                                                                                                                                                                                                                | 0       | Indicates the number of variable compressors on the unit.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| Compressor Circuits         | 353                      | R          | 0-4                                                                                                                                                                                                                                                                                | 0       | Indicates the number of compressor cooling circuits available on the unit.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| Outdoor Air Fan Control     | 354                      | R          | 0=None<br>1=OnOffT<br>2=OnOffP<br>3=VarVFD<br>4=VarECM1<br>5=VarECM2<br>6=VarDK1<br>7=VarDK2                                                                                                                                                                                       | 0=None  | Indicates the outdoor air fan control strategy for the unit.<br>0=None (No outdoor fan control selected)<br>1=OnOffT (Staged on/off control using outdoor air temperature)<br>2=OnOffP (Outdoor fan control using discharge refrigerant pressure)<br>3=VarVFD (Variable outdoor fan control using single VFD)<br>4=VarECM1 (Variable outdoor fan control using ECM motor, circuit 1)<br>5=VarECM2 (Variable outdoor fan control using ECM motor, circuit 2)<br>6=VarDK1 (Variable frequency fan with ECM motor, circuit 1)<br>7=VarDK2 (Variable frequency fan with ECM motor, circuit 2)                                                                                                                                                                                                                                                                                                                                                                                                                         |
| Damper Type                 | 355                      | R          | 0=None<br>1=30OA<br>2=100OA<br>3=Econ<br>4=EconoFDD<br>5=100wRec                                                                                                                                                                                                                   | 3=Econ  | Indicates the type of damper installed in the unit based on the options as follows:<br>0=None (No damper)<br>1=30OA (Single position 0-30% x 10 OA fixed damper)<br>2=100OA (Single position 100% x 10 OA fixed damper)<br>3=Econ (Modulating airside economizer)<br>4=EconoFDD (Modulating airside economizer with fault detection)<br>5=100wRec (Single position 100% x 10 with recirculating air)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Heating Type                | 356                      | R          | 0=None<br>1=F&BP<br>2=HW_Stm<br>3=M1G5-1<br>4=M1G5-1<br>5=M1G5-1<br>6=M1G10-1<br>7=M1G10-1<br>8=M2G10-1<br>9=M3G10-1<br>10=M2G20-1<br>11=M3G20-1<br>12=2StgE<br>13=2StgG<br>14=4StgE<br>15=4StgG<br>16=SCR<br>17=SCR SRht<br>18=Not Used<br>19=M4G10-1<br>20=M4G20-1<br>21=M1G12-1 | 0=None  | Defines the type of heating in the unit. Not all options are available in all applications.<br>0=None (No heating type selected)<br>1=F&BP (Face and bypass)<br>2=HW_Stm (Steam or hot water)<br>3=M1G5-1 (Modulating gas, 5-1)<br>4=M1G5-1 (Modulating gas, 5-1)<br>5=M1G5-1 (Modulating gas, 5-1)<br>6=M1G10-1 (Modulating gas, 10-1)<br>7=M1G10-1 (Modulating gas, 10-1)<br>8=M2G10-1 (Modulating gas, 10-1)<br>9=M3G10-1 (Modulating gas, 10-1)<br>10=M2G20-1 (Modulating gas, 20-1)<br>11=M3G20-1 (Modulating gas, 20-1)<br>12=2StgE (Two-stage electric)<br>13=2StgG (Two-stage gas)<br>14=4StgE (Four-stage electric)<br>15=4StgG (Four-stage gas)<br>16=SCR* (SCR electric)<br>17=SCR SRht* (SCR electric/supplemental reheat)<br>18=Not used<br>19=M4G4StgL (Modulating gas, 10-1)<br>20=M4G4StgH (Modulating gas, 20-1)<br>21=MG4StgH (Modulating gas, 12-1)<br><br>*SCR (silicon controlled rectifier) modulates the time the electric heater is powered on in order to satisfy the zone requirements. |
| Maximum Heat Rise           | 357                      | R          | 0-100                                                                                                                                                                                                                                                                              | 100     | When the unit is equipped with any type of gas or electric heat, MaximumHeatRise prevents the discharge air temperature heating setpoint (DATHtgSpt) from exceeding the entering fan temperature by more than this value.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |

| Description                | Holding Register (4xxx) | Read/Write | Range                                                                                                                                                        | Default | Notes                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|----------------------------|-------------------------|------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Supply Air Fan Type        | 358                     | R          | 0=Anlg1<br>1=1M<br>2=2M<br>3=3M<br>4=4M<br>5=6M<br>6=VFDMB                                                                                                   | 1=1M    | Indicates the supply air fan type for the unit, which may be configured with one or more Modbus-controlled supply fan ECM motors or up to three VFDs.<br><br>0=Anlg1 (Locally-supplied analog input)<br>1=1M (1 ECM supply fan)<br>2=2M (2 ECM supply fans)<br>3=3M (3 ECM supply fans)<br>4=4M (4 ECM supply fans)<br>5=6M (6 ECM supply fans)<br>6=VFDMB (Supply fan VFD Modbus control)                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| Return Air Fan Type        | 359                     | R          | 0=None<br>1=RFAng1<br>2=EFAnlg1<br>3=1ECMRF<br>4=2ECMRF<br>5=3ECMRF<br>6=6ECMRF<br>7=1ECMEF<br>8=2ECMEF<br>9=3ECMEF<br>10=6ECMEF<br>11=RFVFDMB<br>12=EFVFDMB | 0=None  | Indicates the type of return or exhaust fan installed in the unit. Return/exhaust fans may be configured with one or more Modbus-controlled ECM motors or VFD.<br><br>0=None (No return/exhaust fan control)<br>1=RFAng1 (Return fan control via analog output from the unit controller)<br>2=EFAnlg1 (Exhaust fan control via analog output from the unit controller)<br>3=1ECMRF (1 ECM return fan)<br>4=2ECMRF (2 ECM Modbus-controlled return fans)<br>5=3ECMRF (3 ECM Modbus-controlled return fans)<br>6=6ECMRF (6 ECM Modbus-controlled return fans)<br>7=1ECMEF (1 ECM Modbus-controlled exhaust fan)<br>8=2ECMEF (2 ECM Modbus-controlled exhaust fans)<br>9=3ECMEF (3 ECM Modbus-controlled exhaust fans)<br>10=6ECMEF (6 ECM Modbus-controlled exhaust fans)<br>11=RFVFDMB (Return fan VFD Modbus control)<br>12=EFVFDMB (Exhaust fan VFD Modbus control) |
| Energy Recovery            | 360                     | R          | 0=None<br>1=CS<br>2=CSRH<br>3=NA<br>4=NA<br>5=VFD<br>6=Anlg                                                                                                  | 0=None  | Indicates if there is an energy recovery wheel installed, and if so, what type.<br><br>0=None (No energy wheel control)<br>1=CS (Constant speed energy wheel)<br>2=CSRH (Constant speed energy wheel with reheat)<br>3=NA<br>4=NA<br>5=VFD (Energy wheel with VFD control)<br>6=Anlg (Generic analog input to the unit controller)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| Reheat Type                | 361                     | R          | 0=None<br>1=PriHtg<br>2= PriHtBP<br>3= MHG<br>4= MHGBBP<br>5= HG_LSC<br>6= HGLSCBP<br>7= DXBP<br>8= MLSC                                                     | 0=None  | Indicates the reheat control type<br><br>Note that reheat options are based on unit configuration. Not all options are available to the network<br><br>0=None (No reheat)<br>1=PriHtg (Primary heating reheat)<br>2=PriHtBP (Primary heating reheat with DX bypass)<br>3=MHG (Modulating hot gas)<br>4=MHGBBP (Modulating hot gas with DX bypass)<br>5=HG_LSC (Modulating hot gas and liquid subcooling reheat)<br>6=HGLSCBP (Modulating hot gas and liquid subcooling reheat with DX bypass)<br>7=DXBP (DX bypass only)<br>8=MLSC (Modulating liquid subcooling reheat)                                                                                                                                                                                                                                                                                             |
| External Outdoor Air Input | 362                     | R          | 0=None<br>1=ExtVDC<br>2=ExtmA<br>3=CO2VDC<br>4=CO2mA<br>5=CO2QMX+<br>6=IAQMB                                                                                 | 0=None  | Indicates the type of input signal available for outdoor air damper reset from a local CO <sub>2</sub> sensor, QMX sensor* or other device.<br><br>0=None<br>1= ExtVDC (Generic external VDC input)<br>2=ExtmA (Generic external mA analog input)<br>3=CO2VDC (VDC input for local CO <sub>2</sub> sensor)<br>4=CO2mA (mA input for local CO <sub>2</sub> sensor)<br>5=CO2QMX+ (Input from QMX CO <sub>2</sub> sensor)<br>6=IAQMB (CO <sub>2</sub> input from Modbus IAQ sensor)<br><br>*A QMX room sensor(s) is installed on the network and wired directly to the unit controller.                                                                                                                                                                                                                                                                                 |
| Outdoor Air Flow Input     | 363                     | R          | 0=None<br>1=VDC<br>2=mA                                                                                                                                      | 0=None  | Indicates if voltage or current is used to measure outdoor airflow.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Supply Air Fan Flow Input  | 364                     | R          | 0=None<br>1=1Fan<br>2=2 Fan<br>3=3 Fan<br>4=4 Fan<br>5=6 Fan                                                                                                 | 0=None  | Indicates the supply fan configured for outdoor air flow measurement. Available only when the unit is configured with an outdoor airflow measuring device.<br><br>0=None (No supply fan)<br>1=1Fan (One supply fan)<br>2=2Fan (Two supply fans)<br>3=3Fan (Three supply fans)<br>4=4Fan (Four supply fans)<br>5=6Fan (Six supply fans)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |

| Description                     | Holding Register (4xxx) | Read/Write | Range                                                                                               | Default    | Notes                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|---------------------------------|-------------------------|------------|-----------------------------------------------------------------------------------------------------|------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Return Fan Flow Input           | 365                     | R          | 0=None<br>1=1Fan<br>2=2Fan<br>3=3Fan                                                                | 0=None     | Indicates the return or exhaust fan available for outdoor air flow measurement. Available only when the unit is configured with an outdoor airflow measuring device.<br><br>0=None (No return/exhaust fan)<br>1=1Fan (One return/exhaust fan)<br>2=2Fan (Two return/exhaust fans)<br>3=3Fan (Three return/exhaust fans)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Duct Static Pressure Sensor     | 366                     | R          | 0=NA:NA<br>1=DSP:NA<br>2=DSP:DSP<br>3=DSP:BSP<br>4=BSP:NA<br>5=NA:DSP<br>6=NA:BSP                   | 0=NA:NA    | Indicates if a static pressure sensor is installed. Sensor configuration types are described below:<br><br>0=NA:NA (Not available on supply or return/exhaust fan static pressure sensor input)<br>1=DSP:NA (Duct static pressure (DSP) sensor on the supply fan input, no sensor on the return/exhaust fan input)<br>2=DSP:DSP (DSP sensor is present on the supply and return/exhaust fan inputs)<br>3=DSP:BSP (DSP sensor on the supply fan input, Building Static Pressure (BSP) sensor is present on the return fan input)<br>4=BSP:NA (BSP sensor on the supply fan input, no sensor on the return/exhaust fan input)<br>5=NA:DSP (No sensor on the supply fan input, DSP sensor on the return/exhaust fan input)<br>6=NA:BSP (No sensor on the supply fan input, BSP sensor on the return/exhaust fan input)                                                                          |
| Space Temperature Sensor        | 367                     | R          | 0=None<br>1=1AI<br>2=2AI<br>3=3AI<br>4=1QMXS<br>5=2QMXS<br>6=3QMXS<br>7=1QMX+<br>8=2QMX+<br>9=3QMX+ | 0=None     | Configures the type of space temperature sensor input to the unit controller. <sup>2</sup> If this parameter is set to None, the network can still provide a space temperature value. The network can override a local sensor.<br><br>0=None (No local sensors installed)<br>1=1AI (10k analog input available for local sensor)<br>2=2AI (Two 10k analog inputs available for local sensors)<br>3=3AI (Three 10k analog inputs available for local sensors)<br>4=1QMXS (Input from 1 QMX space temp sensor)<br>5=2QMXS (Input from 2 QMX space temp sensors)<br>6=3QMXS (Input from 3 QMX space temp sensors)<br>7=1QMX+ (Input from 1 QMX space/hum/CO2 sensor)<br>8=2QMX+ (Input from 2 QMX space/hum/CO2 sensors)<br>9=3QMX+ (Input from 3 QMX space/hum/CO2 sensors)<br><br>Note: All sensors must be one type. A mix of local analog sensors and Modbus/QMX2 sensors is not supported. |
| Unit Size                       | 368                     | R          | 0-999                                                                                               | 0          | Three-digit configuration parameter that indicates the unit model size.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Monitoring Packages             | 369                     | R          | 0=None<br>1=RefSys                                                                                  | 0=None     | Indicates the type of monitoring package installed on the unit.<br><br>0= None (No refrigerant or monitoring package)<br>1=RefSys (Refrigerant monitoring only)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Electronic Hot Gas Bypass Input | 370                     | R          | 0=None<br>1=Circ12<br>2=Circ1<br>3=Circ2                                                            | 0=None     | Indicates which circuit (1, 2, or both circuits) is configured for electronic hot gas bypass.<br><br>Note that EHGPS is used to regulate circuit suction pressure during light load conditions when only one fixed capacity compressor is operating in the unit.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| Refrigerant Type                | 371                     | R          | 0=None<br>1=R410A<br>2=R32<br>3=R32HP<br>4=R32HP75<br>5=R32HP50<br>6=R32HP25<br>7=R32HP0            | 1=R410A    | Indicates the type of refrigerant in the unit.<br><br>0=None<br>1=R410A (No heat pump)<br>2=R32 (No heat pump)<br>3=R32HP (Heat pump with no auxilliary heat limit)<br>4=R32HP75 (Heat pump with 75% auxilliary heat limit)<br>5=R32HP50 (Heat pump 50% auxilliary heat limit)<br>6=R32HP25 (Heat pump 25% auxilliary heat limit)<br>7=R32HP0 (Heat pump 0% auxilliary heat limit)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| Unit Voltage                    | 372                     | R          | 0=208_60Hz<br>1=230_60Hz<br>2=460_60Hz<br>3=575_60Hz                                                | 2=460_60Hz | Defines the voltage applied to the unit controller.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Preheat Type                    | 373                     | R          | 0=None<br>1=HW_Stm<br>2=F&BP<br>3=SCR                                                               | 0=None     | Indicates the preheat control method. A dedicated hot water/steam coil or heating face and bypass is located upstream of the cooling coil to maintain the leaving cooling coil temperature above an adjustable preheat leaving coil temperature setpoint.<br><br>0=None (No preheat selected)<br>1=HW_Stm (Hot water/steam)<br>2=F&BP (Face and bypass)<br>3=SCR (Electric heat)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |

| Description                 | Holding Register (4xxxx) | Read/Write | Range                                                                                                                                                                                                  | Default  | Notes                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|-----------------------------|--------------------------|------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Expansion Valve Type        | 374                      | R          | 0=None<br>1=DFETS<br>2=DFCol<br>3=FJPAM2<br>4=FJPAM3<br>5=SpIn<br>6=Fj3/Fj2<br>7=Fj2/Fj3<br>8=DFC/Fj2<br>9=DFC/Fj3<br>10=Spr/Fj2<br>11=Spr/Fj3<br>12=Spr/DFC<br>13=Fj2/Spr<br>14=Fj3/Spr<br>15=DFC/Spr | 0=None   | Indicates the expansion valve model type configured for the unit.<br><br>0=None (no expansion valve selected)<br>1=Danfoss ETS DFETS (DFETS)<br>2=Danfoss Colibri (DFCol)<br>3=Fujikoki_PAM 2000 (FJPAM2)<br>4= Fujikoki_PAM 3000 (FJPAM3)<br>5= Sporlan (SpIn)<br>6=Fujikoki_PAM 3000/Fujikoki_PAM 2000 (Fj3/Fj2)<br>7=Fujikoki_PAM 3000/Fujikoki_PAM 2000 (Fj2/Fj3)<br>8=Danfoss Colibri/Fujikoki_PAM 2000 (DFC/Fj2)<br>9=Danfoss Colibri/Fujikoki_PAM 3000 (DFC/Fj3)<br>10=Sporlan/Fujikoki_PAM 2000 (Spr/Fj2)<br>11=Sporlan/Fujikoki_PAM 3000 (Spr/Fj3)<br>12=Sporlan/Danfoss Colibri (Spr/DFC)<br>13=Fujikoki_PAM 2000/Sporlan (Fj2/Spr)<br>14=Fujikoki_PAM 3000/Sporlan (Fj3/Spr)<br>15=Danfoss Colibri/Sporlan (DFC/Spr) |
| I/O Configuration Parameter | 375                      | R          | 0=RebApp<br>1=Rebel<br>2-DCSA                                                                                                                                                                          | 0=RebApp | The I/O configuration parameter which determines the type of unit controller.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| Sensor Configuration        | 376                      | R          | 0-8                                                                                                                                                                                                    | 0        | Defines the number of A2L sensors equipped with the unit.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Clear Alarms                | 400                      | W          | 0=No<br>1=ClrFlts<br>2=ClrPrblms<br>3=ClrWrngs<br>4=ClrAllAlms                                                                                                                                         | 0=No     | Clears all active alarms within an alarm class or clears all active alarms.<br><br>All active alarms are cleared automatically when power is cycled to the controller. If conditions that triggered the alarm are still present after a power cycle, the active alarm is re-initiated with a new date/time stamp.<br><br>Also see <a href="#">Alarms and Events</a> .                                                                                                                                                                                                                                                                                                                                                           |

## Alarms and Events

This section describes alarm, problem, warning, and event information available from the MicroTech unit controller via Modbus. Alarms are generated by internal control logic to protect equipment and maintain safe operation. Depending on severity, alarms may restrict unit operation, limit specific functions, or force the unit to an Off state. Active alarms may prevent externally commanded Modbus values from taking effect. Alarms can be monitored and cleared using more than one method.

Alarm priority and classification determine how the unit responds as described below.

### Alarm Classes

Alarms in the unit controller are divided into three classes: Faults, Problems, and Warnings. Fault alarms have the highest priority. Problem alarms have the next priority. Warning alarms have the lowest priority. The alarms within each class are also prioritized.

#### Fault Alarms

Faults are conditions that are serious enough to completely shut down the unit. The alarm condition must be corrected and the alarm cleared before unit operation can resume. Fault alarms have the highest priority.

#### Problem Alarms

Problem alarms do not cause unit shutdown but do limit operation of the unit in some way. Some of these alarms must be cleared manually, others clear automatically when conditions return to normal. Problem alarms have the next highest priority.

#### Warning Alarms

Warnings are conditions that should be addressed, but do not limit operation in any way. Some of these alarms must be cleared manually, others will clear automatically when conditions return to normal. Warning alarms have the lowest priority.

### Events And Standby Events

Indicate operating conditions or protective states that may temporarily alter unit behavior. These conditions are informational and reflect internal sequencing or protection logic.

## Alarm Notification

Each alarm is assigned a priority number from 1-255. Faults (200-255) have a higher priority than Problems (61-199) which have a higher priority than Warnings (1-60).

The alarm priority number is set to 0 to indicate no alarm or to the enumeration of the highest priority active alarm. [Table 7 - Table 9](#) describe the Warning, Problem, and Fault alarm registers and index ranges.

### Active Alarm (Alarm Value)

Alarm values reported via Modbus represent the highest-priority active condition at the time of the request. Use holding register 158 (Alarm Value) to read, display, or view the highest priority alarm regardless of class.

## Alarm Clearing

Alarm clearing restores normal operation only if the condition that generated the alarm has been resolved.

Alarms can be cleared via Modbus by setting Clear Alarms register (400) to a value other than one (1). After the alarms are cleared, the state returns to Normal (0).

All active alarms are cleared automatically when power is cycled to the unit controller. If conditions that triggered the alarm are still present after a power cycle, the active alarm is re-initiated with a new date/time stamp.

## Alarm Data Points

The following section describes alarm values that can be mapped via Modbus. [Table 5](#) describes the holding registers used for alarm class notification and clearing. Use holding register 158 (Alarm Value) to enable notification of the highest priority alarm regardless of class ([Table 6](#)). [Table 7](#) - [Table 9](#) describe the

alarms in each class based on Alarm Value priority. [Table 10](#) describes events and standby events. Alarms and Events are read-only.

Refer to unit controller OM for more alarm generation descriptions ([Reference Documents](#)).

**Table 5: Modbus Alarm Class Notification**

| Alarm          | Holding Register (4xxxx) | Range                                                          | Description                                                                                                                                                                                                                                                                                                          |
|----------------|--------------------------|----------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Clear Alarms   | 400                      | 0=No<br>1=ClrFlts<br>2=ClrPrblms<br>3=ClrWrngs<br>4=ClrAllAlms | Clears all active alarms or group of alarm types. Applies to ZTC, DTC or 1ZnVAV controller configurations.<br><b>Value</b><br>0=No<br>1=ClrFlts<br>2=ClrPrblms<br>3=ClrWrngs<br>4=ClrAllAlms<br><b>Action</b><br>No Action Taken<br>Clear All Faults<br>Clear All Problems<br>Clear All Warnings<br>Clear All Alarms |
| Active Warning | 155                      | 0-255                                                          | Highest priority active problem alarm.                                                                                                                                                                                                                                                                               |
| Active Problem | 156                      | 0-255                                                          | Highest priority active warning alarm.                                                                                                                                                                                                                                                                               |
| Active Fault   | 157                      | 0-255                                                          | Highest priority active fault alarm.                                                                                                                                                                                                                                                                                 |
| Alarm Value    | 158                      | 0-255                                                          | Highest priority active alarm. Alarm object = 0 if no alarms are active or to the enumeration of the highest priority active alarm.                                                                                                                                                                                  |

**Table 6: Active Alarms Supported by Alarm Status (Holding Register 40158)**

| Holding Register (4xxxx) | Alarm Name                       | Range               | Default  | Clear     | Description                                                                                                                                                                                                                                          |
|--------------------------|----------------------------------|---------------------|----------|-----------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 401                      | Air Flow Status                  | 0=NoFlow<br>1=Flow  | 0=NoFlow | Manual    | Indicates the airflow status.                                                                                                                                                                                                                        |
| 402                      | Filter Switch Input              | 0=Open<br>1=Closed  | 1=Closed | NA        | Indicates the status of the main filter switch. <sup>2</sup> The 0=Open position generates the warning alarm (404).                                                                                                                                  |
| 403                      | Final Filter Switch Input        | 0=Open<br>1=Closed  | 1=Closed | NA        | Indicates the status of the final filter switch. <sup>2</sup> The 0=Open position generates the warning alarm (405).                                                                                                                                 |
| 404                      | Filter Warning                   | 0=Normal<br>1=Alarm | 0=Normal | NA        | Indicates whether filter 1 (main filter) is in alarm condition. Alarm indicates the main filter switch input (FilterSw1) is in the alarm (open) position or when the filter pressure inputs 1 or 2 exceed the high filter pressure 1 or 2 setpoints. |
| 405                      | Final Filter Warning             | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates whether filter 2 (final filter) is in alarm condition. Alarm indicates the final filter switch input (FilterSw2) is in the alarm (open) position or when the filter pressure 3 input exceeds the high filter pressure 3 setpoint.          |
| 406                      | Energy Wheel Warning             | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates that the energy recovery wheel is not functioning as expected and the Energy Wheel Warning alarm is active. <sup>1</sup>                                                                                                                   |
| 407                      | Over Economizing Warning         | 0=Normal<br>1=Alarm | 0=Normal | Automatic | An active alarm indicates that the unit is economizing when it should not be economizing.                                                                                                                                                            |
| 408                      | Under Economizing Warning        | 0=Normal<br>1=Alarm | 0=Normal | Automatic | An active alarm indicates that the unit is not economizing when it should be economizing.                                                                                                                                                            |
| 409                      | Excess Outdoor Air Warning       | 0=Normal<br>1=Alarm | 0=Normal | Automatic | An active alarm indicates that the unit is delivering excess outdoor air.                                                                                                                                                                            |
| 410                      | Outdoor Air Damper Stuck Warning | 0=Normal<br>1=Alarm | 0=Normal | Automatic | Indicates that the freezestat is in the open position and an alarm has been generated. <sup>2</sup>                                                                                                                                                  |
| 411                      | Return / Exhaust Fan Warning     | 0=Normal<br>1=Alarm | 0=Normal | Automatic | An active alarm indicates that there is a problem with the return or exhaust fan operation. The OffNormal state of this object indicates a Return / Exhaust Fan Warning. Applies to units with a VFD or ECM return/exhaust fan. <sup>1</sup>         |
| 412                      | Freeze Fault                     | 0=Open<br>1=Closed  | 1=Closed | Manual    | Indicates that the freezestat is in the open position and an alarm has been generated. <sup>2</sup>                                                                                                                                                  |
| 413                      | Freeze Problem                   | 0=Alarm<br>1=Normal | 1=Normal | Automatic | Activates the Freeze Problem alarm when input is in the Open position. <sup>1</sup>                                                                                                                                                                  |
| 414                      | Heat Fail Problem                | 0=Normal<br>1=Alarm | 0=Normal | Automatic | Indicates the status of the Heat Fail Problem alarm. <sup>1</sup>                                                                                                                                                                                    |

**Table 5: Active Alarms Supported by Alarm Status (Holding Register 40158)**

| Holding Register (4xxxx) | Alarm Name <sup>5</sup>                                      | Range               | Default  | Clear     | Description                                                                                                                                                                                                                                                                                                                                                         |
|--------------------------|--------------------------------------------------------------|---------------------|----------|-----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 415                      | A2L Refrigerant Sensor Problem                               | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates that the A2L mitigation board is in fault or that communication to the A2L board has been lost.                                                                                                                                                                                                                                                           |
| 416                      | A2L Refrigerant Leak Problem                                 | 0=Normal<br>1=Alarm | 0=Normal | Automatic | An alarm indicates that the A2L mitigation board has detected a refrigerant concentration level above the allowable threshold.                                                                                                                                                                                                                                      |
| 417                      | High Pressure Problem Circuit 1                              | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates the status of the high pressure switch input. When it is in the alarm (Open) position, the High Pressure Problem alarm is active and the inverter compressor refrigerant circuit 1 limit has been exceeded. <sup>1</sup>                                                                                                                                  |
| 418                      | Low Pressure Problem Circuit 1                               | 0=Alarm<br>1=Normal | 1=Normal | Automatic | Indicates the status of the low pressure switch input. When it is in the alarm (Open) position, the Low Pressure Problem alarm is active. This means that the low pressure switch input has been in the alarm (Open) position for longer than the default of two seconds or that the compressor on circuit 1 has been on for longer than five seconds. <sup>1</sup> |
| 419                      | Low Discharge Pressure Problem Circuit 1                     | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates the status of the Low Discharge Pressure Problem alarm for VFD circuit 1 compressor. <sup>1</sup>                                                                                                                                                                                                                                                         |
| 420                      | Outdoor Air Fan 1 Problem                                    | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates if an Outdoor Air Fan Problem alarm is active. <sup>1</sup>                                                                                                                                                                                                                                                                                               |
| 421                      | Inverter Compressor Board (IFB) 1 Problem                    | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates if an interruption has occurred between the unit controller and an inverter compressor interface communication board (IFB) board, if installed. <sup>1</sup>                                                                                                                                                                                              |
| 422                      | Charge Loss Problem Circuit 1                                | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates if the refrigerant system charge on circuit 1 has been lost. <sup>1</sup>                                                                                                                                                                                                                                                                                 |
| 423                      | High Variable Speed Compressor Temperature Problem Circuit 1 | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates if the variable speed compressor for circuit 1 has exceeded the high temperature setpoint.                                                                                                                                                                                                                                                                |
| 424                      | Variable Speed Compressor Problem Circuit 1                  | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates the status of the Variable Speed Compressor Problem alarm on circuit 1. Applies to units with VFD compressors. <sup>1</sup>                                                                                                                                                                                                                               |
| 425                      | Low Discharge Superheat Problem Circuit 1                    | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates if the circuit 1 Discharge Superheat Problem alarm is active because of a low superheat reading. Applies to units with VFD compressors. <sup>1</sup>                                                                                                                                                                                                      |
| 426                      | High Discharge Superheat Problem Circuit 1                   | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates if the circuit 1 Discharge Superheat Problem alarm is active because of a high superheat reading. Applies to units with VFD compressors. <sup>1</sup>                                                                                                                                                                                                     |
| 427                      | High Discharge Line Temperature Problem Circuit 1            | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates if the circuit 1 High Discharge Line Temperature has exceeded the high temperature limit. Applies to units with VFD compressors. <sup>1</sup>                                                                                                                                                                                                             |
| 428                      | Expansion Valve Problem Circuit 2                            | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates the status of the circuit 2 Expansion Valve Problem alarm. <sup>1</sup>                                                                                                                                                                                                                                                                                   |
| 429                      | Modulating Hot Gas Reheat Problem Circuit 1                  | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates that the modulating hot gas reheat valve motor and driver are not synchronizing as expected. <sup>1</sup>                                                                                                                                                                                                                                                 |
| 430                      | High Pressure Problem Circuit 2                              | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates the status of the high pressure switch input. When it is in the alarm (Open) position, the High Pressure Problem alarm is active and the inverter compressor refrigerant circuit 2 limit has been exceeded. <sup>1</sup>                                                                                                                                  |
| 431                      | Low Pressure Problem Circuit 2                               | 0=Normal<br>1=Alarm | 0=Normal | Automatic | Indicates the status of the low pressure switch input. When it is in the alarm (Open) position, the Low Pressure Problem alarm is active. This means that the low pressure switch input has been in the alarm (Open) position for longer than the default of two seconds or that the compressor on circuit 2 has been on for longer than five seconds. <sup>1</sup> |
| 432                      | Low Discharge Pressure Problem Circuit 2                     | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates the status of the Low Discharge Pressure Problem alarm for VFD circuit 2 compressor. <sup>1</sup>                                                                                                                                                                                                                                                         |
| 433                      | Outdoor Air Fan Problem Circuit 2                            | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates if an Outdoor Air Fan Problem alarm is active on circuit 2. <sup>1</sup>                                                                                                                                                                                                                                                                                  |
| 434                      | Inverter Compressor Board (IFB) Problem Circuit 2            | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates if an interruption has occurred between the unit controller and an inverter compressor interface communication board (IFB) board. <sup>1</sup>                                                                                                                                                                                                            |
| 435                      | Charge Loss Problem Circuit 2                                | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates if the refrigerant system charge on circuit 2 has been lost. <sup>1</sup>                                                                                                                                                                                                                                                                                 |
| 436                      | High Variable Speed Compressor Temperature Problem Circuit 2 | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates if the variable speed compressor for circuit 2 has exceeded the high temperature setpoint.                                                                                                                                                                                                                                                                |
| 437                      | Variable Speed Compressor Problem Circuit 2                  | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates the status of the Variable Speed Compressor Problem alarm on circuit 2. Applies to units with VFD compressors. <sup>1</sup>                                                                                                                                                                                                                               |
| 425                      | Low Discharge Superheat Problem Circuit 2                    | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates if the circuit 2 Discharge Superheat Problem alarm is active because of a low superheat reading. Applies to units with VFD compressors. <sup>1</sup>                                                                                                                                                                                                      |

**Table 5: Active Alarms Supported by Alarm Status (Holding Register 40158)**

| Holding Register (4xxxx) | Alarm Name <sup>5</sup>                                      | Range               | Default  | Clear     | Description                                                                                                                                                                                                                                                                                                                                                             |
|--------------------------|--------------------------------------------------------------|---------------------|----------|-----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 439                      | High Discharge Superheat Problem Circuit 2                   | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates if the circuit 2 Discharge Superheat Problem alarm is active because of a high superheat reading. Applies to units with VFD compressors. <sup>1</sup>                                                                                                                                                                                                         |
| 440                      | High Discharge Line Temperature Problem Circuit 2            | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates if the circuit 2 High Discharge Line Temperature Problem alarm on has exceeded the high temperature limit. Applies to units with VFD compressors. <sup>1</sup>                                                                                                                                                                                                |
| 441                      | Expansion Valve Problem Circuit 2                            | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates the status of the circuit 1 Expansion Valve Problem alarm. <sup>1</sup>                                                                                                                                                                                                                                                                                       |
| 442                      | High Dewpoint Cooling Disable Problem                        | 0=Normal<br>1=Alarm | 0=Normal | Automatic | Indicates the outdoor air dewpoint is greater than the OA dewpoint maximum value (HiOADwptValue) setpoint. Applies to 100% OA damper units.                                                                                                                                                                                                                             |
| 443                      | High Dewpoint Cooling Disable Fault                          | 0=Normal<br>1=Alarm | 0=Normal | Automatic | Indicates the outdoor air dewpoint is greater than the OA dewpoint maximum value (HiOADwptValue) setpoint. Applies to 100% OA damper units.                                                                                                                                                                                                                             |
| 444                      | Condensate Overflow Problem                                  | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates that the condensate input is open continuously for 10 seconds. Alarm is generated on units with R32 refrigerant.                                                                                                                                                                                                                                              |
| 446                      | 4-Way Valve 1 Problem                                        | 0=Normal<br>1=Alarm | 0=Normal | Manual    | The 4-way reversing valve indicates a problem with compressor cooling and heating operation. Applies to heat pump units.                                                                                                                                                                                                                                                |
| 447                      | 4-Way Valve 2 Problem                                        |                     |          |           |                                                                                                                                                                                                                                                                                                                                                                         |
| 448                      | 4-Way Valve 3 Problem                                        |                     |          |           |                                                                                                                                                                                                                                                                                                                                                                         |
| 459                      | Low Charge Problem Circuit 1                                 | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates status of the low refrigerant charge problem alarm on circuit 1, 2, or 3. <sup>1</sup>                                                                                                                                                                                                                                                                        |
| 460                      | Low Charge Problem Circuit 1                                 |                     |          |           |                                                                                                                                                                                                                                                                                                                                                                         |
| 461                      | Low Charge Problem Circuit 1                                 |                     |          |           |                                                                                                                                                                                                                                                                                                                                                                         |
| 453                      | Duct High Limit Fault                                        | 0=Open<br>1=Closed  | 1=Closed | Manual    | Indicates the status of the local duct high limit switch with input from the local sensor. This is the object that generates a Fault alarm when in the Open position. <sup>2</sup>                                                                                                                                                                                      |
| 454                      | Emergency Off Fault                                          | 0=Open<br>1=Closed  | 1=Closed | Manual    | Indicates the status of the emergency off switch. Input is from either a local sensor or the network. This is the object that generates a Fault alarm when in the Open position. <sup>2</sup>                                                                                                                                                                           |
| 455                      | Airflow Fault                                                | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates the condition of the airflow switch <sup>1</sup> . It is the object that generates the alarm. Determines whether or not sufficient supply air flow is present for unit operation. Does not apply to refrigeration-only units.                                                                                                                                 |
| 456                      | High Return Air Temperature Fault                            | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates that the return air temperature is greater than the high return temperature limit of 120°F for longer than the high/low temperature alarm delay of 35 seconds and that the return air temperature sensor is not reliable (shorted or open circuited). <sup>1</sup>                                                                                            |
| 474                      | High Pressure Problem Circuit 3                              | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates the status of the circuit 3 high pressure switch input. When it is in the alarm (Open) position, the High Pressure Problem alarm is active and the inverter compressor refrigerant circuit high limit has been exceeded. <sup>1</sup>                                                                                                                         |
| 475                      | Low Pressure Problem Circuit 3                               | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates the status of the circuit 3 low pressure switch input. When it is in the alarm (Open) position, the Low Pressure Problem alarm is active. This means that the low pressure switch input has been in the alarm (Open) position for longer than the default of two seconds or that the compressor has been on for longer than five seconds. <sup>1</sup>        |
| 476                      | Low Discharge Pressure Problem Circuit 3                     | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates the status of the circuit 3 Low Discharge Pressure Problem alarm on VFD compressor units. <sup>1</sup>                                                                                                                                                                                                                                                        |
| 477                      | Outdoor Air Fan 3 Problem Circuit 3                          | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates the status of the circuit 3 Outdoor Air Fan Problem alarm. <sup>1</sup>                                                                                                                                                                                                                                                                                       |
| 478                      | IFB3 Comm Fail Problem                                       | 0=Normal<br>1=Alarm | 0=Normal | Manual    | An interruption has occurred between the unit controller and an inverter compressor interface communication board (IFB) board. This indicates that the HP3 switch input is in the normal (Close) position.<br>Note: The high pressure switch disables a 16VDC power input from the variable compressor controller. This may cause an erroneous IFB3 Comm problem alarm. |
| 479                      | Charge Loss Problem Circuit 3                                | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates a circuit 3 Charge Loss Problem alarm.                                                                                                                                                                                                                                                                                                                        |
| 461                      | Low Refrigerant Charge Problem Circuit 3                     | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates the status of the circuit 3 Low Refrigerant Charge Problem alarm. <sup>1</sup>                                                                                                                                                                                                                                                                                |
| 480                      | Variable Speed Compressor High Temperature Problem Circuit 3 | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates the status of the circuit 3 Variable Speed Compressor Problem alarm. Occurs when the temperature input exceeds the high temperature setpoint. Alarm can be cleared manually after the temperature is below the setpoint continuously for one minute. <sup>1</sup>                                                                                             |
| 481                      | Variable Speed Compressor Problem Circuit 3                  | 0=Normal<br>1=Alarm | 0=Normal | Manual    | Indicates the status of the circuit 3 Variable Speed Compressor Problem alarm. Applies to units with VFD compressors. <sup>1</sup>                                                                                                                                                                                                                                      |

**Table 5: Active Alarms Supported by Alarm Status (Holding Register 40158)**

| Holding Register (4xxx) | Alarm Name <sup>5</sup>                           | Range               | Default  | Clear  | Description                                                                                                                                                                                                                                       |
|-------------------------|---------------------------------------------------|---------------------|----------|--------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 482                     | Low Discharge Superheat Problem Circuit 3         | 0=Normal<br>1=Alarm | 0=Normal | Manual | Indicates if the circuit 3 Discharge Superheat Problem alarm is active. Alarm occurs when the superheat input is below the allowable setpoint. Applies to units with VFD compressors. <sup>1</sup>                                                |
| 483                     | High Discharge Superheat Problem Circuit 3        | 0=Normal<br>1=Alarm | 0=Normal | Manual | Indicates if the circuit 3 Discharge Superheat Problem alarm is active. Alarm occurs when the superheat input exceeds the setpoint limit. Applies to units with VFD compressors. <sup>1</sup>                                                     |
| 484                     | High Discharge Line Temperature Problem Circuit 3 | 0=Normal<br>1=Alarm | 0=Normal | Manual | Indicates if the circuit 3 High Discharge Line Temperature Problem alarm is active. Alarm occurs when the temperature exceeds the setpoint limit. Applies to units with VFD compressors. <sup>1</sup>                                             |
| 485                     | Expansion Valve Problem Circuit 3                 | 0=Normal<br>1=Alarm | 0=Normal | Manual | Indicates the status of the circuit 3 Expansion Valve Problem alarm. <sup>1</sup>                                                                                                                                                                 |
| 487                     | Remote Condenser Reheat Disable                   | 0=Normal<br>1=Alarm | 0=Normal | Manual | Indicates that the remote condenser reheat status input is disabled (Off) and dehumidification is required. Applies to air handling (DAHA) units when configured to be integrated with a remote condensing unit controller (DCSA).                |
| 488                     | Remote Condenser Disable                          | 0=Normal<br>1=Alarm | 0=Normal | Manual | Indicates that the remote condenser compressor status input is disabled (Off) and cooling or dehumidification is required. Applies to air handling (DAHA) units when configured to be integrated with a remote condensing unit controller (DCSA). |

<sup>1</sup> Normal = 0, In Alarm = 1<sup>2</sup> Open or short-circuited = 0, Closed = 1<sup>3</sup> Alarm is manual when the Emergency Off Reset parameter is set to ManClr. Otherwise, it is automatic when Emergency Off Reset is set to AutoClr from the HMI**Table 7: Warning Alarms**

| Alarm Number | Alarm Name                       | Clear     | Description                                                                                                                                                                                                             |
|--------------|----------------------------------|-----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 0            | No Active Warnings               |           | No active alarms.                                                                                                                                                                                                       |
| 2            | Hi PM10 Warning                  | Automatic | The sensor has detected particulate matter larger than 10 micrometers in diameter. This indicates air quality is poor or possibly hazardous if high PM10 level persists beyond the timer limit of 1440 minutes.         |
| 3            | Hi TVOC Warning                  | Automatic | The sensor has detected a high level of total volatile organic compounds. This indicates air quality is poor or possibly hazardous if total VOC level persists beyond the timer limit of 1440 minutes.                  |
| 4            | Hi Space RH1 Warning             | Manual    | Indicates that a space or return air humidity sensor has exceeded the setpoint high limit for longer than the Hi Humid time. Applies when units are configured for IAQ monitoring and have the proper sensor installed. |
| 5            | Lo Space Rh1 Warning             | Manual    | Indicates that a space or return air humidity sensor is below the setpoint low limit for longer than the Lo Humid time. Applies when units are configured for IAQ monitoring and have the proper sensor installed.      |
| 6            | Lo Bldg Press Warning            | Automatic | Indicates the building static pressure (BSP) is below the low BSP setpoint. Applies when units are configured for IAQ monitoring and have the proper sensor installed.                                                  |
| 7            | Hi CO2 Warning                   | Manual    | Indicates the amount of CO2 in the space is at poor or hazard conditions for longer than the Hi CO2 time. Applies when units are configured for IAQ monitoring and have the proper sensor installed.                    |
| 24           | Main Filter Warning              | Manual    | Indicates the status of the main filter switch. <sup>1</sup>                                                                                                                                                            |
| 25           | Final Filter Warning             | Manual    | Indicates the status of the final filter switch. <sup>1</sup>                                                                                                                                                           |
| 34           | Return / Exhaust Fan Warning     | Automatic | An active alarm indicates that there is a problem with the return or exhaust fan operation. Applies to units with a VFD or ECM return/exhaust fan. <sup>2</sup>                                                         |
| 50           | Over Economizing Warning         | Automatic | An active alarm indicates that the unit is economizing when it should not be economizing. <sup>2</sup>                                                                                                                  |
| 52           | Under Economizing Warning        | Automatic | An active alarm indicates that the unit is not economizing when it should be economizing. <sup>2</sup>                                                                                                                  |
| 54           | Excess Outdoor Air Warning       | Automatic | An active alarm indicates that the unit is delivering excess outdoor air. <sup>2</sup>                                                                                                                                  |
| 56           | Outdoor Air Damper Stuck Warning | Automatic | An active alarm indicates that the outdoor air dampers may be stuck. <sup>2</sup>                                                                                                                                       |

<sup>1</sup> Normal = 0, In Alarm = 1<sup>2</sup> Open or short-circuited = 0, Closed = 1

**Table 8: Problem Alarms**

| Alarm Number | Alarm Name <sup>5</sup> | Clear                  | Description                                                                                                                                                                                                                                     |
|--------------|-------------------------|------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 0            | No Active Problems      |                        | No active alarms.                                                                                                                                                                                                                               |
| 61           | HiDPCIDsbldPrb Problem  | Automatic              | Indicates that the outdoor air dewpoint is above the setpoint and dewpoint cooling is disabled.                                                                                                                                                 |
| 62           | CondOverflow Problem    | Manual                 | Indicates that the condensate input is open continuously for 10 seconds. Alarm is generated on units with R32 refrigerant.                                                                                                                      |
| 63           | RemCmpsDsblD Problem    | Manual                 | Indicates that the remote condenser compressor status input is disabled (Off) and cooling or dehumidification is required.                                                                                                                      |
| 64           | C1HiC1FCmpTmp1 Problem  | Automatic <sup>3</sup> | Indicates that the fixed compressor high temperature 1 is above 120°F continuously for 5 seconds.                                                                                                                                               |
| 65           | C1HiC1FCmpTmp3 Problem  | Automatic <sup>3</sup> | Indicates that the fixed compressor high temperature 3 is above 120°F continuously for 5 seconds.                                                                                                                                               |
| 66           | C1HiC1FCmpTmp5 Problem  | Automatic <sup>3</sup> | Indicates that the fixed compressor high temperature 5 is above 120°F continuously for 5 seconds.                                                                                                                                               |
| 67           | C1FCmpTmp1 Problem      | Manual                 | Indicates that the fixed compressor temperature sensor 1 is present and either shorted or open circuited for longer than temperature alarm delay default of 30 seconds, or the sensor value has exceeded the allowable range.                   |
| 68           | C1FCmpTmp3 Problem      | Manual                 | Indicates that the fixed compressor temperature sensor 3 is present and either shorted or open circuited for longer than temperature alarm delay default of 30 seconds, or the sensor value has exceeded the allowable range.                   |
| 69           | C1FCmpTmp5 Problem      | Manual                 | Indicates that the fixed compressor temperature sensor 5 is present and either shorted or open circuited for longer than temperature alarm delay default of 30 seconds, or the sensor value has exceeded the allowable range.                   |
| 70           | C1DRT3Sensor Problem    | Manual                 | Indicates that the DRT sensor 3 is present and either shorted or open circuited for longer than temperature alarm delay default of 30 seconds, or the sensor value has exceeded the allowable range.                                            |
| 71           | C1DRT5Sensor Problem    | Manual                 | Indicates that the DRT sensor 5 is present and either shorted or open circuited for longer than temperature alarm delay default of 30 seconds, or the sensor value has exceeded the allowable range.                                            |
| 73           | RemRhtDsblD Problem     | Manual                 | Indicates that the remote condenser reheat status input is disabled (Off) and dehumidification is required.                                                                                                                                     |
| 74           | C2Hi FCmpTmp2 Problem   | Automatic <sup>3</sup> | Indicates that the fixed compressor high temperature 2 is above 120°F for five seconds.                                                                                                                                                         |
| 75           | C2Hi FCmpTmp4 Problem   | Automatic <sup>3</sup> | Indicates that the fixed compressor high temperature 4 is above 120°F for five seconds                                                                                                                                                          |
| 76           | C2Hi FCmpTmp6 Problem   | Automatic <sup>3</sup> | Indicates that the fixed compressor high temperature 6 is above 120°F for five seconds                                                                                                                                                          |
| 77           | C2FCmpTmp2 Problem      | Manual                 | Indicates that the fixed compressor temperature sensor 2 is present and either shorted or open circuited for longer than temperature alarm delay default of 30 seconds, or the sensor value has exceeded the allowable range.                   |
| 78           | C2FCmpTmp4 Problem      | Manual                 | Indicates that the fixed compressor temperature sensor 4 is present and either shorted or open circuited for longer than temperature alarm delay default of 30 seconds, or the sensor value has exceeded the allowable range.                   |
| 79           | C2FCmpTmp6 Problem      | Manual                 | Indicates that the fixed compressor temperature sensor 6 is present and either shorted or open circuited for longer than temperature alarm delay default of 30 seconds, or the sensor value has exceeded the allowable range.                   |
| 80           | C2DRT4Sensor Problem    | Manual                 | Indicates that the DRT sensor 4 is present and either shorted or open circuited for longer than temperature alarm delay default of 30 seconds, or the sensor value has exceeded the allowable range.                                            |
| 81           | C2DRT6 Sensor Problem   | Manual                 | Indicates that the DRT sensor 6 is present and either shorted or open circuited for longer than temperature alarm delay default of 30 seconds, or the sensor value has exceeded the allowable range.                                            |
| 82           | DFT1Sensor Problem      | Manual                 | Indicates the defrost sensor 1 is present and either shorted or opened for longer than the temperature alarm delay default of 30 seconds, or the sensor value has exceeded the allowable range. Applies to heat pump units.                     |
| 83           | DFT2Sensor Problem      | Manual                 | Indicates the defrost sensor 2 is present and either shorted or opened for longer than the temperature alarm delay default of 30 seconds, or the sensor value has exceeded the allowable range. Applies to heat pump units.                     |
| 84           | DFT3Sensor Problem      | Manual                 | Indicates the defrost sensor 3 is present and either shorted or opened for longer than the temperature alarm delay default of 30 seconds, or the sensor value has exceeded the allowable range. Applies to heat pump units.                     |
| 85           | HiC3FCmpTmp1 Problem    | Automatic              | Indicates that the circuit 3 fixed compressor 1 has remained above the maximum allowable temperature of 120°C (248°F) continuously for 5 seconds.                                                                                               |
| 86           | HiC3FCmpTmp3 Problem    | Automatic              | Indicates that the circuit 3 fixed compressor 3 has remained above the maximum allowable temperature of 120°C (248°F) continuously for 5 seconds.                                                                                               |
| 87           | HiC3FCmpTmp5 Problem    | Automatic              | Indicates that the circuit 3 fixed compressor 5 has remained above the maximum allowable temperature of 120°C (248°F) continuously for 5 seconds.                                                                                               |
| 88           | C3FCmpTmp1 Problem      | Manual                 | Indicates that the circuit 3 fixed compressor temperature sensor 1 is shorted and either open circuited for longer than temperature alarm delay default of 30 seconds or is not detected, or the sensor value has exceeded the allowable range. |
| 89           | C3FCmpTmp3 Problem      | Manual                 | Indicates that the circuit 3 fixed compressor temperature sensor 3 is shorted and either open circuited for longer than temperature alarm delay default of 30 seconds or is not detected, or the sensor value has exceeded the allowable range. |

**Table 8: Problem Alarms, Continued**

| Alarm Number | Alarm Name <sup>5</sup>  | Clear     | Description                                                                                                                                                                                                                                                                                                                         |
|--------------|--------------------------|-----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 90           | C3FCmpTmp5 Problem       | Manual    | Indicates that the circuit 3 fixed compressor temperature sensor 5 is shorted and either open circuited for longer than temperature alarm delay default of 30 seconds or is not detected, or the sensor value has exceeded the allowable range.                                                                                     |
| 91           | C3DRT3Sensor Problem     | Manual    | Indicates that the circuit 3 DRT sensor 3 is present and either shorted or open circuited for longer than temperature alarm delay default of 30 seconds, or the sensor value has exceeded the allowable range.                                                                                                                      |
| 92           | C3DRT5Sensor Problem     | Manual    | Indicates that the circuit 3 DRT sensor 5 is present and either shorted or open circuited for longer than temperature alarm delay default of 30 seconds, or the sensor value has exceeded the allowable range.                                                                                                                      |
| 95           | 4WV3 Problem             | Manual    | The 4-way reversing valve 3 indicates a problem with compressor cooling and heating operation. Applies to heat pump units.                                                                                                                                                                                                          |
| 97           | C3DRT1 Sensor Problem    | Manual    | Indicates that the circuit 3 DRT sensor 1 is present and either shorted or open circuited for longer than temperature alarm delay default of 30 seconds, or the sensor value has exceeded the allowable range.                                                                                                                      |
| 101          | MHGRht Vlv1 Problem      | Manual    | Indicates that the modulating hot gas reheat valve motor and driver are not synchronizing as expected. <sup>1</sup>                                                                                                                                                                                                                 |
| 102          | MHGRhtVlv2 Problem       | Manual    | Indicates that the modulating hot gas reheat valve motor 2 and driver are not synchronizing. <sup>1</sup>                                                                                                                                                                                                                           |
| 105          | C1DRT1 Sensor Problem    | Manual    | Indicates that the DRT sensor 1 is present and either shorted or opened for longer than the temperature alarm delay default of 30 seconds, or the sensor value has exceeded the allowable range.                                                                                                                                    |
| 106          | C2DRT2 Sensor Problem    | Manual    | Indicates that the DRT sensor 2 is present and either shorted or opened for longer than the temperature alarm delay default of 30 seconds, or the sensor value has exceeded the allowable range.                                                                                                                                    |
| 107          | 4WV1 Problem             | Manual    | The 4-way reversing valve 1 indicates a problem with compressor cooling and heating operation. Applies to heat pump units.                                                                                                                                                                                                          |
| 108          | 4WV2 Problem             | Manual    | The 4-way reversing valve 2 indicates a problem with compressor cooling and heating operation. Applies to heat pump units.                                                                                                                                                                                                          |
| 109          | ProtIntrck Problem       | Manual    | The Protection Interlock Problem alarm is generated when the effective compressor capacity input is greater than 5% x 10 and the system safety protection interlock input is Open or the safety switch command is Off for 90 seconds. Compressor operation is disabled under these conditions. Applies to refrigeration-only units. |
| 110          | VCmp 1 Problem           | Manual    | Indicates the current status of the variable speed compressor problem alarm on circuit 1. Applies to units with VFD compressors. <sup>1</sup>                                                                                                                                                                                       |
| 111          | VCmp 2 Problem           | Manual    | Indicates the current status of the variable speed compressor problem alarm on circuit 2. Applies to units with VFD compressors. <sup>1</sup>                                                                                                                                                                                       |
| 112          | VCmp 3 Problem           | Manual    | Indicates the current status of the variable speed compressor problem alarm on circuit 3. Applies to units with VFD compressors. <sup>1</sup>                                                                                                                                                                                       |
| 115          | SRT Sensor 1 Problem     | Manual    | Indicates that suction refrigerant temperature sensor on circuit 1, 2, or 3 is present and either shorted or opened for longer than the temperature alarm delay default of 30 seconds, or the sensor value has exceeded the allowable range.                                                                                        |
| 116          | SRT Sensor 2 Problem     |           |                                                                                                                                                                                                                                                                                                                                     |
| 117          | SRT Sensor 3 Problem     |           |                                                                                                                                                                                                                                                                                                                                     |
| 120          | Hi DL Temp_1 Problem     | Manual    | Indicates if the high discharge line temperature problem alarm on variable compressor circuit 1, 2 or 3 has exceeded the high temperature limit. Applies to units with VFD compressors. <sup>1</sup>                                                                                                                                |
| 121          | Hi DL Temp_2 Problem     |           |                                                                                                                                                                                                                                                                                                                                     |
| 122          | Hi DL Temp_3 Problem     |           |                                                                                                                                                                                                                                                                                                                                     |
| 125          | Exp Valve 1 Problem      | Manual    | Indicates the status of the circuit 1, 2 or 3 expansion valve problem alarm. <sup>1</sup>                                                                                                                                                                                                                                           |
| 126          | Exp Valve 2 Problem      |           |                                                                                                                                                                                                                                                                                                                                     |
| 127          | Exp Valve 3 Problem      |           |                                                                                                                                                                                                                                                                                                                                     |
| 130          | OA Fan 1 Problem         | Manual    | Indicates if an outdoor air fan problem alarm on circuit 1, 2 or 3 is active. <sup>1</sup>                                                                                                                                                                                                                                          |
| 131          | OA Fan 2 Problem         |           |                                                                                                                                                                                                                                                                                                                                     |
| 132          | OA Fan 3 Problem         |           |                                                                                                                                                                                                                                                                                                                                     |
| 133          | Refrigerant Leak Problem | Manual    | Indicates the A2L leak detection board has detected a leak with one or more of the refrigerant sensors.                                                                                                                                                                                                                             |
| 134          | Refrig Sensor Problem    | Automatic | Indicates the A2L refrigerant sensor is in fault condition or is not communicating to the controller.                                                                                                                                                                                                                               |
| 135          | PTS1 Sensor Problem      | Manual    | The suction refrigerant pressure sensor 1 or 2 is present and the following are true for 30 seconds:<br>1. Charge Loss Problem is Inactive<br>2. The sensor value is less than -96.53 kPa (-14.0 psi)                                                                                                                               |
| 136          | PTS2 Sensor Problem      |           |                                                                                                                                                                                                                                                                                                                                     |
| 137          | PTS3 Sensor Problem      |           |                                                                                                                                                                                                                                                                                                                                     |
| 140          | PTD1 Sensor Problem      | Manual    | The discharge refrigerant pressure sensor 1, 2, or 3 is present and the sensor value is greater than 4619.5 kPa (670 psi) or less than -96.53 kPa (-14.0 psi).                                                                                                                                                                      |
| 141          | PTD2 Sensor Problem      |           |                                                                                                                                                                                                                                                                                                                                     |
| 142          | PTD3 Sensor Problem      |           |                                                                                                                                                                                                                                                                                                                                     |
| 145          | Low Charge 1 Problem     | Manual    | Indicates a low refrigerant charge problem alarm on circuit 1, 2, or 3. <sup>1</sup>                                                                                                                                                                                                                                                |
| 146          | Low Charge 2 Problem     |           |                                                                                                                                                                                                                                                                                                                                     |
| 147          | Low Charge 3 Problem     |           |                                                                                                                                                                                                                                                                                                                                     |

**Table 8: Problem Alarms, Continued**

| Alarm Number | Alarm Name <sup>5</sup> | Clear                  | Description                                                                                                                                                                                                                                                                                                                                                                                                               |
|--------------|-------------------------|------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 150          | Charge Loss 1 Problem   | Manual                 | Indicates if the refrigerant system charge on circuit 1, 2, or 3 has been lost and the following are true for 20 seconds: <sup>1</sup><br>1. The discharge refrigerant pressure sensor is less than or equal to 68.94 kPa (10 psi)<br>2. The suction refrigerant pressure sensor is less than or equal to 68.94 kPa (10 psi)                                                                                              |
| 151          | Charge Loss 2 Problem   |                        |                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 152          | Charge Loss 3 Problem   |                        |                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 155          | VCmp1LoDSH Problem      | Manual                 | Indicates if the discharge superheat problem alarm on circuit 1, 2, or 3 is active because of a low superheat reading. Applies to units with VFD compressors <sup>1</sup>                                                                                                                                                                                                                                                 |
| 156          | VCmp2LoDSH Problem      |                        |                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 157          | VCmp3LoDSH Problem      |                        |                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 160          | Lo Press 1 Problem      | Manual                 | Indicates the status of the low pressure switch input. When it is in the alarm (Open) position, the low pressure problem alarm is active. This means that the low pressure switch input has been in the alarm (Open) position for longer than the default of two seconds or that the compressor on circuit 1, 2, or 3 has been on for longer than 5 seconds <sup>1</sup>                                                  |
| 161          | Lo Press 2 Problem      |                        |                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 162          | Lo Press 3 Problem      |                        |                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 165          | Hi Press 1 Problem      | Manual                 | Indicates the status of the high pressure switch input. When it is in the alarm (Open) position, the high pressure problem alarm is active and the inverter compressor refrigerant circuit 1, 2, or 3 high limits have been exceeded. Applies to units with VFD compressors. <sup>1</sup>                                                                                                                                 |
| 166          | Hi Press 2 Problem      |                        |                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 167          | Hi Press 3 Problem      |                        |                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 170          | Lo Press Diff 1 Problem | Manual                 | Current status of the low discharge pressure problem alarm on circuit 1, 2, or 3. Applies to units with VFD compressors. <sup>1</sup>                                                                                                                                                                                                                                                                                     |
| 171          | Lo Press Diff 2 Problem |                        |                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 172          | Lo Press Diff 3 Problem |                        |                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 175          | HiVCmp1Temp Problem     | Manual                 | Indicates the status of the variable compressor high temperature problem alarm on circuit 1, 2, or 3. Applies to variable speed compressors. Alarm requires a manual clear after VCmp1Temp is below 212°F (100°C) continuously for one minute. <sup>1</sup>                                                                                                                                                               |
| 176          | HiVCmp2Temp Problem     |                        |                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 177          | HiVCmp3Temp Problem     |                        |                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 180          | VCmpTSnsr1 Problem      | Manual                 | Indicates that the variable compressor temperature sensor 1, 2, or 3 is present but has been shorted. It can also indicate that the sensor is in the alarm (Open) position, or that no sensor is detected.                                                                                                                                                                                                                |
| 181          | VCmpTSnsr2 Problem      |                        |                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 182          | VCmpTSnsr 3 Problem     |                        |                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 185          | VCmp1HiDSH Problem      | Manual                 | Indicates the high discharge superheat problem alarm on cooling circuit 1, 2, or 3. Applies to units with VFD compressors. <sup>1</sup>                                                                                                                                                                                                                                                                                   |
| 186          | VCmp2HiDSH Problem      |                        |                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 187          | VCmp3HiDSH Problem      |                        |                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 190          | IFB1 Comm Problem       | Automatic <sup>4</sup> | An interruption has occurred between the unit controller and an inverter compressor interface communication board (IFB) board, if installed. This indicates that both the high pressure switch HP1 or HP2 switch input is in the normal (Close) position.<br><br>Note: The high pressure switch disables a 16VDC input from the variable compressor controller. This may cause an erroneous IFB1/IFB2 Comm problem alarm. |
| 191          | IFB2 Comm Problem       |                        |                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 192          | EFT/LCT Snsr Problem    | Automatic              | Indicates that the entering fan/leaving coil temperature sensor is present and either shorted or open circuited for longer than temperature alarm delay default of 30 seconds. Applies when unit control type is ZTC, DTC, or 1ZnVAV.                                                                                                                                                                                     |
| 193          | RAT Sensor Problem      | Automatic              | The return air temperature sensor is present and either shorted or opened for longer than the temperature alarm delay default of 30 seconds. Applies when unit control type is ZTC, DTC, or 1ZnVAV. Alarm clears automatically when the sensor becomes reliable.                                                                                                                                                          |
| 194          | Space Sensor 1 Problem  | Automatic              | Indicates that the local space sensor input is shorted or open circuited for longer than the temperature alarm delay of 30 seconds. Applies when unit control type is ZTC, DTC, or 1ZnVAV. Alarm clears automatically when the sensor becomes reliable.                                                                                                                                                                   |
| 195          | Space Sensor 2 Problem  |                        |                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 196          | Space Sensor 3 Problem  |                        |                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 197          | OAT Sensor Problem      | Manual                 | Indicates that a valid network outdoor air temperature input value is not present and that the local outdoor air temperature sensor is either shorted or open circuited. Applies when unit control type is ZTC, DTC, or 1ZnVAV.                                                                                                                                                                                           |
| 198          | Freeze Problem          | Automatic              | Indicates that the freezestat input is in the Open position. <sup>1</sup> Applies when unit control type is ZTC, DTC, or 1ZnVAV.                                                                                                                                                                                                                                                                                          |
| 199          | Heat Fail Problem       | Automatic              | Indicates the heat fail problem alarm is active. <sup>1</sup> Applies when unit control type is ZTC, DTC, 1ZnVAV or RO_FCGE.                                                                                                                                                                                                                                                                                              |

<sup>1</sup> Normal = 0, In Alarm = 1<sup>2</sup> Open or short-circuited = 0, Closed = 1<sup>3</sup> Requires a manual reset if the alarm occurs three times within 100 minutes<sup>4</sup> Requires a manual reset if the alarm occurs five times within 100 minutes<sup>5</sup> Circuit designations "C1, C2 or C3" are supported in unit controller software v2506036118 and newer

**Table 9: Fault Alarms**

| Alarm Number | Alarm Name           | Clear               | Description <sup>1</sup>                                                                                                                                                                                                                                                                                 |
|--------------|----------------------|---------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 0            | No Active Faults     |                     | No active alarms.                                                                                                                                                                                                                                                                                        |
| 205          | HiDPCIDsbldFlt Fault | Automatic           | High Dewpoint Cooling Disable Fault. Indicates the outdoor air dewpoint is greater than the OA dewpoint maximum value (HiOADwptValue) setpoint. Applies to 100% OA damper units.                                                                                                                         |
| 208          | Airflow Fault        | Manual              | Airflow Fault. Indicates the condition of the airflow switch used to determine whether or not sufficient supply air flow is present for unit operation. <sup>1</sup> Does not apply to refrigeration-only units.                                                                                         |
| 212          | Lo Disch Temp Fault  | Manual              | Low Discharge Air Temperature Fault. Indicates that the discharge air temperature is below the low discharge temperature setting and that the discharge air temperature sensor reading is reliable (not open or short-circuited).                                                                        |
| 216          | Hi Disch Temp Fault  | Manual              | High Discharge Air Temperature Fault. Indicates that the discharge air temperature is greater than the high discharge temperature limit and that the discharge air temperature sensor reading is reliable (not open or short-circuited). <sup>2</sup>                                                    |
| 220          | Hi Return Tmp Fault  | Manual              | High Return Air Temperature Fault. Indicates that the return air temperature is greater than the high return temperature limit of 120°F for longer than the high/low temperature alarm delay of 35 seconds and that the return air temperature sensor reading is reliable (not open or short-circuited). |
| 224          | Duct Hi Limit Fault  | Manual              | Duct High Limit Fault. Applies only to Variable Air Volume (VAV) units configured for a VFD or ECM supply fan.                                                                                                                                                                                           |
| 228          | Disch Tmp Fault      | Manual              | Discharge Air Temperature Sensor Fault. Indicates that the sensor is not reliable for longer than the temperature sensor alarm delay default of 30 seconds <sup>2</sup> .                                                                                                                                |
| 244          | Control Temp Fault   | Manual              | Control Temperature Fault. Indicates that the sensor, configured for control temperature, is not present, is not reliable <sup>2</sup> or is out of range. Also, no other sensor (the return air temperature, outdoor air temperature, or space temperature sensor) is available.                        |
| 250          | Emerg Stop Fault     | Manual <sup>3</sup> | Emergency Stop Fault. Indicates that the emergency off switch input is in the alarm (Open) position.                                                                                                                                                                                                     |
| 252          | Freeze Fault         | Manual              | Freeze Fault. Indicates that the freezestat input is in the alarm (Open) position and the supply air fan is on for at least 30 seconds. <sup>2</sup> Applies when the unit heating is face and bypass or hot water steam, or the unit cooling is chilled water.                                          |

<sup>1</sup> Normal = 0, In Alarm = 1<sup>2</sup> Open or short-circuited = 0, Closed = 1<sup>3</sup> Alarm is manual when the Emergency Off Reset parameter is set to ManClr. Otherwise, it is automatic when Emergency Off Reset is set to AutoClr from the HMI**Table 10: Events and Standby Events**

| Holding Register (4xxxx) | Event Name                                              | Range                  | Default    | Clear     | Description                                                                                                                              |
|--------------------------|---------------------------------------------------------|------------------------|------------|-----------|------------------------------------------------------------------------------------------------------------------------------------------|
| 445                      | HtRiseLmtg Event                                        | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Heat Rise Limiting Event is active. Occurs when the DAT – Effective/LCT has exceeded the Max Heat Rise value.                        |
| 449                      | C1OilRet Event                                          | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 1 Oil Return Event is active.                                                                                                |
| 450                      | C2OilRet Event                                          | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 2 Oil Return Event is active.                                                                                                |
| 451                      | C1OAFReqSB Event                                        | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 1 compressor state is forced to standby due to a fan control board request.                                                  |
| 452                      | C2OAFReqSB Event                                        | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 2 compressor state is forced to standby due to a fan control board request.                                                  |
| 462                      | C1HiSSHRHOvrd Event                                     | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 1 High Suction Superheat Reheat Override Event is active.                                                                    |
| 463                      | C2HiSSHRHOvrd Event                                     | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 2 High Suction Superheat Reheat Override Event is active.                                                                    |
| 464                      | HPEmrHt Event                                           | 0=Inactive<br>1=Active | 0=Inactive | Automatic | Heat Pump Emergency Heat Event is active.                                                                                                |
| 467                      | BkUpRhtAct Event                                        | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Backup Reheat Event control is active.                                                                                               |
| 500                      | Fan Retry Event                                         | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Supply Fan Retry Event is active.                                                                                                    |
| 501                      | Tenant Override Event                                   | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Tenant Override Event operation is active.                                                                                           |
| 503                      | Reheat Limiting Control                                 | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Reheat Compressor Limiting Event is active.                                                                                          |
| 504                      | Expansion Valve Synchronization Standby Event Circuit 1 | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 1 EV Sync Event is active. Occurs when the expansion valve and stepper motor are not synchronized due to power interruption. |
| 505                      | Fin Temperature Unload Event Circuit 1                  | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 1 High Fin Temperature Unloading Event is active. Applies to units with inverter compressors.                                |

**Table 10: Events and Standby Events, Continued**

| Holding Register (4xxxx) | Event Name                                                 | Range                  | Default    | Clear     | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|--------------------------|------------------------------------------------------------|------------------------|------------|-----------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 506                      | High Compression Ratio Unloading Event Circuit 1           | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Circuit 1 High Compression Ratio Unloading Event is active.                                                                                                                                                                                                                                                                                                                                                                                                                |
| 507                      | High Discharge Line Temperature Standby Event Circuit 1    | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Circuit 1 High Compression Ratio Unloading Event is active.                                                                                                                                                                                                                                                                                                                                                                                                                |
| 508                      | High Discharge Line Temperature Unload Event Circuit 1     | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Circuit 1 High Discharge Line Temperature Unloading Event is active on the variable compressor.                                                                                                                                                                                                                                                                                                                                                                            |
| 509                      | High Current Unload Event Circuit 1                        | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Circuit 1 High Amp Unloading Event is active.                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 510                      | High Discharge Superheat Standby Event Circuit 1           | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit compressor state is forced into Standby because of high discharge superheat protection.                                                                                                                                                                                                                                                                                                                                                                            |
| 511                      | Compressor Body High Temperature Standby Event Circuit 1   | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit compressor state is forced into Standby because of compressor body high temperature protection.                                                                                                                                                                                                                                                                                                                                                                    |
| 512                      | High Pressure Standby Event Circuit 1                      | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit compressor state is forced into Standby because of compressor body high temperature protection.                                                                                                                                                                                                                                                                                                                                                                    |
| 513                      | High Pressure Unload Event Circuit 1                       | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Circuit 1 High Pressure Unloading Event is active.                                                                                                                                                                                                                                                                                                                                                                                                                         |
| 514                      | Low Pressure Differential Pressure Standby Event Circuit 1 | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit compressor state is forced into Standby because of low differential pressure protection unloading control.                                                                                                                                                                                                                                                                                                                                                         |
| 515                      | Low Differential Pressure Unload Event Circuit 1           | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Circuit 1 Low Differential Pressure Unloading Event is active.                                                                                                                                                                                                                                                                                                                                                                                                             |
| 516                      | Low Discharge Superheat Event Circuit 1                    | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 1 Low Discharge Superheat Disable Event indicates the discharge superheat temperature is below the DSH setpoint. Applies to variable compressor units configured for optional refrigerant monitoring system.                                                                                                                                                                                                                                                       |
| 517                      | Low Pressure Standby Event Circuit 1                       | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit compressor state is forced into Standby because of low pressure unloading control.                                                                                                                                                                                                                                                                                                                                                                                 |
| 518                      | Low Pressure Unload Event Circuit 1                        | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Circuit 1 Low Differential Pressure Unloading Event is active.                                                                                                                                                                                                                                                                                                                                                                                                             |
| 519                      | Outdoor Air Fan Standby Event Circuit 1                    | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 1 outdoor air fan is forced into Standby because of a fault detected by the outdoor air fan VFD.                                                                                                                                                                                                                                                                                                                                                                   |
| 520                      | Unload Request Event Circuit 1                             | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Circuit 1 Unload Request Control control is active.                                                                                                                                                                                                                                                                                                                                                                                                                        |
| 521                      | Variable Compressor Problem Standby Event Circuit 1        | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit compressor state is forced into Standby because of a fault detected by the variable compressor controller.                                                                                                                                                                                                                                                                                                                                                         |
| 522                      | Variable Compressor Request Standby Event Circuit 1        | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The compressor circuit is forced to Standby due to a request from the variable compressor controller.                                                                                                                                                                                                                                                                                                                                                                          |
| 523                      | High Ambient Limiting Control Event Circuit 1              | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The fixed compressor circuit high ambient limiting control is active.                                                                                                                                                                                                                                                                                                                                                                                                          |
| 524                      | Low Suction Superheat Event Circuit 1                      | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Circuit 1 Low Suction Superheat Event is active when the SSH1 < 5°F for at least 60 minutes. Applies to units configured for optional refrigerant monitoring system.                                                                                                                                                                                                                                                                                                       |
| 525                      | High Suction Superheat Event Circuit 1                     | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Circuit 1 High Suction Superheat Event is active when SSH1 > 30°F for at least 60 minutes. Applies to units configured for optional refrigerant monitoring system.                                                                                                                                                                                                                                                                                                         |
| 526                      | Low Discharge Superheat Event Circuit 1                    | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Low Discharge Superheat Event is active when DSH1 < 20°F for at least 60 minutes. Applies to units configured for optional refrigerant monitoring system.                                                                                                                                                                                                                                                                                                                  |
| 527                      | High Discharge Superheat Event Circuit 1                   | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The High Discharge Superheat Event is active when DSH1 < 20°F for at least 60 minutes. Applies to units configured for optional refrigerant monitoring system.                                                                                                                                                                                                                                                                                                                 |
| 528                      | Low Subcooling Event Circuit 1                             | 0=Inactive<br>1=Active | 0=Inactive | Automatic | <p>The Low Subcooling Event is active when all of the following are true for at least 60 minutes:</p> <ul style="list-style-type: none"> <li>• Subcooling1 &lt; 1°F</li> <li>• All compressors in the circuit are running</li> <li>• OA Problem alarm inactive</li> <li>• Effective OAT &gt; 75°F</li> <li>• Unit State = Cooling</li> <li>• The Dehumidification Status is Inactive</li> </ul> <p>Applies to units configured for optional refrigerant monitoring system.</p> |

**Table 10: Events and Standby Events, Continued**

| Holding Register (4xxx) | Event Name                                                 | Range                  | Default    | Clear     | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-------------------------|------------------------------------------------------------|------------------------|------------|-----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 529                     | High Subcooling Event Circuit 1                            | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The High Subcooling Event is active when all of the following are true for at least 60 minutes: <ul style="list-style-type: none"> <li>Subcooling1 &gt; 25°F</li> <li>All compressors in the circuit are running</li> <li>The OA Problem alarm is inactive</li> <li>Effective OAT &gt; 75°F</li> <li>Unit State = Cooling</li> <li>The Dehumidification Status is Inactive</li> </ul> Applies to units configured for optional refrigerant monitoring system. |
| 530                     | Low Tc Event Circuit 1                                     | 0=Inactive<br>1=Active | 0=Inactive | Automatic | A Low Tc Event is active when the Tc1 value is below the acceptable range. Applies to units configured for optional refrigerant monitoring system.<br>Tc = Circuit discharge pressure saturated temperature input.                                                                                                                                                                                                                                            |
| 531                     | High Tc Event Circuit 1                                    | 0=Inactive<br>1=Active | 0=Inactive | Automatic | A High Tc Event is active when the Tc1 value is above the acceptable range. Applies to units configured for optional refrigerant monitoring system.<br>Tc = Circuit discharge pressure input (PTD_1).                                                                                                                                                                                                                                                         |
| 532                     | Low Te Event Circuit 1                                     | 0=Inactive<br>1=Active | 0=Inactive | Automatic | A Low Te Event is active when the Te1 value is below the acceptable range. Applies to units configured for optional refrigerant monitoring system.<br>Te = Circuit suction pressure input.                                                                                                                                                                                                                                                                    |
| 533                     | High Te Event Circuit 1                                    | 0=Inactive<br>1=Active | 0=Inactive | Automatic | A High Te Event is active when the Te1 value is below the acceptable range. Applies to units configured for optional refrigerant monitoring system.<br>Te = Circuit suction pressure input.                                                                                                                                                                                                                                                                   |
| 534                     | High Discharge Refrigerant Temperature Event Circuit 1     | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Discharge Refrigerant Temperature Event is active when the DRT1 sensor input is > 275°F for at least 30 minutes. Applies to units configured for optional refrigerant monitoring system.                                                                                                                                                                                                                                                                  |
| 535                     | High Suction Return Temperature Event Circuit 1            | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The High Suction Return Temperature Event is active when the SRT1 sensor input is > 95°F for at least 45 minutes. Applies to units configured for optional refrigerant monitoring system.                                                                                                                                                                                                                                                                     |
| 536                     | Low Oil Prevention Event Circuit 1                         | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Low Oil Prevention Event is active when compressors are operating under extreme conditions and low oil protection is required. Applies to variable compressor units.                                                                                                                                                                                                                                                                                      |
| 537                     | High Discharge Line Temperature Unload Event Circuit 1     | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Circuit 1 High Discharge Line Temperature Unloading Event is active on fixed compressor 3 or 5.                                                                                                                                                                                                                                                                                                                                                           |
| 538                     |                                                            |                        | 0=Inactive | Automatic |                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| 539                     | Expansion Valve Synchronization Standby Event Circuit 2    | 0=Inactive<br>1=Active | 0=Inactive | Automatic | Event is active when the expansion valve and stepper motor are not synchronized due to power interruption.                                                                                                                                                                                                                                                                                                                                                    |
| 540                     | Fin Temperature Unload Event Circuit 2                     | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Circuit 2 High Fin Temperature Unloading Event is active. Applies to units with inverter compressors.                                                                                                                                                                                                                                                                                                                                                     |
| 541                     | High Compression Ratio Unloading Event Circuit 1           | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Circuit 1 High Compression Ratio Unloading Event is active.                                                                                                                                                                                                                                                                                                                                                                                               |
| 542                     | High Compression Ratio Unloading Event Circuit 2           | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Circuit 2 High Discharge Line Temperature Unloading Event is active on fixed compressor 1.                                                                                                                                                                                                                                                                                                                                                                |
| 543                     | High Discharge Line Temperature Unload Event Circuit 2     | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 2 High Discharge Line Temperature Unloading Event is active on the variable or fixed compressor 2.                                                                                                                                                                                                                                                                                                                                                |
| 544                     | High Discharge Superheat Standby Event Circuit 2           | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit compressor state is forced into Standby because of high discharge superheat protection.                                                                                                                                                                                                                                                                                                                                                           |
| 545                     | High Discharge Superheat Standby Event Circuit 2           | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit compressor state is forced into Standby because of high discharge superheat protection.                                                                                                                                                                                                                                                                                                                                                           |
| 546                     | Compressor Body High Temperature Standby Event Circuit 2   | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit compressor state is forced into Standby because of compressor body high temperature protection.                                                                                                                                                                                                                                                                                                                                                   |
| 547                     | Compressor Body High Temperature Standby Event Circuit 2   | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit compressor state is forced into Standby because of compressor body high temperature protection.                                                                                                                                                                                                                                                                                                                                                   |
| 548                     | High Pressure Unload Event Circuit 2                       | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Circuit 2 High Pressure Unloading Event is active.                                                                                                                                                                                                                                                                                                                                                                                                        |
| 549                     | Low Pressure Differential Pressure Standby Event Circuit 2 | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit compressor state is forced into Standby because of low differential pressure protection unloading control.                                                                                                                                                                                                                                                                                                                                        |
| 550                     | Low Differential Pressure Unload Event Circuit 2           | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Circuit 2 Low Differential Pressure Unloading Event is active.                                                                                                                                                                                                                                                                                                                                                                                            |

**Table 10: Events and Standby Events, Continued**

| Holding Register (4xxxx) | Event Name                                          | Range                  | Default    | Clear     | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|--------------------------|-----------------------------------------------------|------------------------|------------|-----------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 551                      | Low Discharge Superheat Event Circuit 2             | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Low Discharge Superheat Event is active when DSH2 < 20°F for at least 60 minutes. Applies to units configured for optional refrigerant monitoring system.                                                                                                                                                                                                                                                                                                              |
| 552                      | Low Pressure Standby Event Circuit 2                | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit compressor state is forced into Standby because of low pressure unloading control.                                                                                                                                                                                                                                                                                                                                                                             |
| 553                      | Low Pressure Unload Event Circuit 2                 | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Circuit 2 Low Differential Pressure Unloading Event is active.                                                                                                                                                                                                                                                                                                                                                                                                         |
| 554                      | Outdoor Air Fan Standby Event Circuit 2             | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 2 outdoor air fan is forced into Standby because of a fault detected by the outdoor air fan VFD.                                                                                                                                                                                                                                                                                                                                                               |
| 555                      | Unload Request Event Circuit 2                      | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Circuit 2 Unload Request Control control is active.                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 556                      | Variable Compressor Problem Standby Event Circuit 2 | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit compressor state is forced into Standby because of a fault detected by the variable compressor controller.                                                                                                                                                                                                                                                                                                                                                     |
| 557                      | Variable Compressor Request Standby Event Circuit 2 | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The compressor circuit is forced to Standby due to a request from the variable compressor controller.                                                                                                                                                                                                                                                                                                                                                                      |
| 558                      | High Ambient Limiting Control Event Circuit 2       | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The fixed compressor circuit high ambient limiting control is active.                                                                                                                                                                                                                                                                                                                                                                                                      |
| 559                      | Low Suction Superheat Event Circuit 2               | 0=Inactive<br>1=Active | 0=Inactive | Automatic | Circuit 2 Low Suction Superheat Event is active when the SSH2 < 5°F for at least 60 minutes. Applies to units configured for optional refrigerant monitoring system.                                                                                                                                                                                                                                                                                                       |
| 560                      | High Suction Superheat Event Circuit 2              | 0=Inactive<br>1=Active | 0=Inactive | Automatic | Circuit 2 High Suction Superheat Event is active when SSH2 > 30°F for at least 60 minutes. Applies to units configured for optional refrigerant monitoring system.                                                                                                                                                                                                                                                                                                         |
| 561                      | Low Discharge Superheat Event Circuit 2             | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The Low Discharge Superheat Event is active when DSH2 < 20°F for at least 60 minutes. Applies to units configured for optional refrigerant monitoring system.                                                                                                                                                                                                                                                                                                              |
| 562                      | High Discharge Superheat Event Circuit 2            | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The High Discharge Superheat Event is active when DSH2 < 20°F for at least 60 minutes. Applies to units configured for optional refrigerant monitoring system.                                                                                                                                                                                                                                                                                                             |
| 563                      | Low Subcooling Event Circuit 2                      | 0=Inactive<br>1=Active | 0=Inactive | Automatic | <p>The Low Subcooling Event is active when all of the following are true for at least 60 minutes:</p> <ul style="list-style-type: none"> <li>Subcooling1 &lt; 1°F</li> <li>All compressors in the circuit are running</li> <li>OA Problem alarm inactive</li> <li>Effective OAT &gt; 75°F</li> <li>Unit State = Cooling</li> <li>The Dehumidification Status is Inactive</li> </ul> <p>Applies to units configured for optional refrigerant monitoring system.</p>         |
| 564                      | High Subcooling Event Circuit 2                     | 0=Inactive<br>1=Active | 0=Inactive | Automatic | <p>The High Subcooling Event is active when all of the following are true for at least 60 minutes:</p> <ul style="list-style-type: none"> <li>Subcooling1 &gt; 25°F</li> <li>All compressors in the circuit are running</li> <li>The OA Problem alarm is inactive</li> <li>Effective OAT &gt; 75°F</li> <li>Unit State = Cooling</li> <li>The Dehumidification Status is Inactive</li> </ul> <p>Applies to units configured for optional refrigerant monitoring system</p> |
| 565                      | Low Tc Event Circuit 2                              | 0=Inactive<br>1=Active | 0=Inactive | Automatic | <p>A Low Tc Event is active when the Tc2 value is below the acceptable range. Applies to units configured for optional refrigerant monitoring system.</p> <p>Tc = Discharge pressure saturated temperature input</p>                                                                                                                                                                                                                                                       |
| 566                      | High Tc Event Circuit 2                             | 0=Inactive<br>1=Active | 0=Inactive | Automatic | <p>A High Tc Event is active when the Tc2 value is above the acceptable range. Applies to units configured for optional refrigerant monitoring system.</p> <p>Tc = Discharge pressure input (PTD_1).</p>                                                                                                                                                                                                                                                                   |
| 567                      | Low Te Event Circuit 2                              | 0=Inactive<br>1=Active | 0=Inactive | Automatic | <p>A Low Te Event is active when the Te2 value is below the acceptable range. Applies to units configured for optional refrigerant monitoring system.</p> <p>Te = Circuit suction pressure input.</p>                                                                                                                                                                                                                                                                      |
| 568                      | High Te Event Circuit 2                             | 0=Inactive<br>1=Active | 0=Inactive | Automatic | <p>The circuit 2 High Te Event is active when the Te2 value is above the acceptable range. Applies to units configured for optional refrigerant monitoring system.</p> <p>Te = Circuit suction pressure input.</p>                                                                                                                                                                                                                                                         |

**Table 10: Events and Standby Events, Continued**

| Holding Register (4xxxx) | Event Name                                             | Range                  | Default    | Clear     | Description                                                                                                                                                                                                 |
|--------------------------|--------------------------------------------------------|------------------------|------------|-----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 569                      | High Discharge Refrigerant Temperature Event Circuit 2 | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 2 Discharge Refrigerant Temperature Event is active when the DRT2 sensor input is > 275°F for at least 30 minutes. Applies to units configured for optional refrigerant monitoring system.      |
| 570                      | C2HiSRT Event                                          | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 2 High Suction Return Temperature Event is active. Occurs when the SRT2 sensor input is > 95°F for at least 45 minutes. Applies to units configured for optional refrigerant monitoring system. |
| 571                      | C2LowOilPrvnt Event                                    | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 2 Low Oil Prevention Event is active when compressors are operating under extreme conditions and low oil protection is required. Applies to variable compressor units.                          |
| 572                      | C2HDLT4UL Event                                        | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 2 High Discharge Line Temperature Unloading Event is active on the fixed compressor 4 or 6.                                                                                                     |
| 573                      | C2HDLT6UL Event                                        | 0=Inactive<br>1=Active | 0=Inactive | Automatic |                                                                                                                                                                                                             |
| 600                      | C3EVSynSB Event                                        | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 compressor state is forced into Standby because of expansion valve re-synchronization.                                                                                                        |
| 601                      | C3FinTUL Event                                         | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 High Fin Temperature Unloading Event is active on the inverter compressor.                                                                                                                    |
| 602                      | C3HCRUL Event                                          | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 High Compression Ratio Unloading Event is active.                                                                                                                                             |
| 603                      | C3HDLTSB Event                                         | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 compressor state is forced into Standby because of high discharge line temperature unloading.                                                                                                 |
| 604                      | VCmp3HDLTUL Event                                      | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 High Discharge Line Temperature Unloading Event is active on the variable compressor.                                                                                                         |
| 604                      | C3HDLT1UL Event                                        | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 High Discharge Line Temperature Unloading Event is active on the fixed compressor.                                                                                                            |
| 605                      | C3HiAmpUL Event                                        | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 High Amp Unloading Event is active on the fixed compressor.                                                                                                                                   |
| 606                      | C3HiDSHSB Event                                        | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 compressor state is forced into Standby because of high discharge superheat protection.                                                                                                       |
| 607                      | C3HiTSB Event                                          | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 compressor state is forced into Standby because of compressor body high temperature protection.                                                                                               |
| 608                      | C3HPSB Event                                           | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 compressor state is forced into Standby because of high pressure unloading control.                                                                                                           |
| 609                      | C3HPUL Event                                           | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 High Pressure Unloading Event is active.                                                                                                                                                      |
| 610                      | C3LDPSB Event                                          | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 compressor state is forced into Standby because of low differential pressure protection unloading control.                                                                                    |
| 611                      | C3LDPUL Event                                          | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 Low Differential Pressure Unloading Event is active.                                                                                                                                          |
| 612                      | C3LoDSHDSbl Event                                      | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 Low Discharge Superheat Disable Event indicates the discharge superheat temperature is below the DSH setpoint.                                                                                |
| 613                      | C3LPSB Event                                           | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 compressor state is forced into Standby because of low pressure unloading control.                                                                                                            |
| 614                      | C3LPUL Event                                           | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 Low Differential Pressure Unloading Event is active.                                                                                                                                          |
| 615                      | C3OAFSB Event                                          | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 outdoor air fan is forced into Standby because of a fault detected by the outdoor air fan VFD.                                                                                                |
| 616                      | C3ReqUL Event                                          | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 Unload Request Control control is active.                                                                                                                                                     |
| 617                      | C3VCmpPrbSB Event                                      | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 compressor state is forced into Standby because of a fault detected by the variable compressor.                                                                                               |
| 618                      | C3VCmpReqSB Event                                      | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 compressor state is forced into Standby because of a request from the variable compressor.                                                                                                    |
| 619                      | C3HiAmbLmtg Event                                      | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 fixed compressor High Ambient Limiting control is active.                                                                                                                                     |
| 620                      | C3LoSSH Event                                          | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 Low Suction Superheat Event is active when the SSH3 < 5°F for at least 60 minutes. Applies to units configured for optional refrigerant monitoring system.                                    |
| 621                      | C3HiSSH Event                                          | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 High Suction Superheat Event is active when SSH3 > 30°F for at least 60 minutes. Applies to units configured for optional refrigerant monitoring system.                                      |

**Table 10: Events and Standby Events, Continued**

| Holding Register (4xxxx) | Event Name          | Range                  | Default    | Clear     | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|--------------------------|---------------------|------------------------|------------|-----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 622                      | C3LoDSH Event       | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 Low Discharge Superheat Event is active when DSH3 < 20°F for at least 60 minutes. Applies to units configured for optional refrigerant monitoring system.                                                                                                                                                                                                                                                                                                 |
| 623                      | C3HiDSH Event       | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 High Discharge Superheat Event is active when DSH3 < 20°F for at least 60 minutes. Applies to units configured for optional refrigerant monitoring system.                                                                                                                                                                                                                                                                                                |
| 624                      | C3LoSubClg Event    | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 Low Subcooling Event is active when all of the following are true for at least 60 minutes: <ul style="list-style-type: none"> <li>Subcooling1 &lt; 1°F</li> <li>All compressors in the circuit are running</li> <li>OA Problem alarm inactive</li> <li>Effective OAT &gt; 75°F</li> <li>Unit State = Cooling</li> <li>The Dehumidification Status is Inactive</li> </ul> Applies to units configured for optional refrigerant monitoring system.          |
| 625                      | C3HiSubClg Event    | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 High Subcooling Event is active when all of the following are true for at least 60 minutes: <ul style="list-style-type: none"> <li>Subcooling1 &gt; 25°F</li> <li>All compressors in the circuit are running</li> <li>The OA Problem alarm is inactive</li> <li>Effective OAT &gt; 75°F</li> <li>Unit State = Cooling</li> <li>The Dehumidification Status is Inactive</li> </ul> Applies to units configured for optional refrigerant monitoring system. |
| 626                      | C3LoTc Event        | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 Low Tc Event is active when the corresponding circuit Tc value is below the acceptable range. Applies to units configured for optional refrigerant monitoring system.                                                                                                                                                                                                                                                                                     |
| 627                      | C3HiTc Event        | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 High Tc Event is active when the corresponding circuit Tc value is above the acceptable range. It is determined from the circuit's average discharge pressure (PTD) analog input. Applies to units configured for optional refrigerant monitoring system.                                                                                                                                                                                                 |
| 628                      | C3LoTe Event        | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 Low Te Event is active when the corresponding circuit Tc value is below the acceptable range. It is determined from the circuit's average discharge pressure (PTD) analog input. Applies to units configured for optional refrigerant monitoring system.                                                                                                                                                                                                  |
| 629                      | C3HiTe Event        | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 High Te Event is active when the corresponding circuit Te value is above the acceptable range. It is determined from the circuit's average discharge pressure (PTD) analog input. Applies to units configured for optional refrigerant monitoring system.                                                                                                                                                                                                 |
| 630                      | C3HiDRT Event       | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 Discharge Refrigerant Temperature Event is active when the corresponding circuit DRT sensor input is > 275°F for at least 30 minutes. Applies to units configured for optional refrigerant monitoring system.                                                                                                                                                                                                                                             |
| 631                      | C3HiSRT Event       | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 High Suction Return Temperature Event is active when the corresponding circuit SRT sensor input is > 95°F for at least 45 minutes. Applies to units configured for optional refrigerant monitoring system.                                                                                                                                                                                                                                                |
| 632                      | C3LowOilPrvnt Event | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 Low Oil Prevention Event is active when compressors are operating under extreme conditions and low oil protection is required. Applies to variable compressor units.                                                                                                                                                                                                                                                                                      |
| 633                      | C3HDLT3UL Event     | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 High Discharge Line Temperature Unloading Event is active on fixed compressor 3.                                                                                                                                                                                                                                                                                                                                                                          |
| 634                      | C3HDLT5UL Event     | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 High Discharge Line Temperature Unloading Event is active on fixed compressor 5.                                                                                                                                                                                                                                                                                                                                                                          |
| 635                      | C3OAFReqSB Event    | 0=Inactive<br>1=Active | 0=Inactive | Automatic | The circuit 3 compressor state is forced to standby due to a fan control board request.                                                                                                                                                                                                                                                                                                                                                                                 |

# Service Information

## Troubleshooting and Support

This section provides guidance for diagnosing common Modbus integration issues. In most cases, unexpected behavior is related to configuration issues rather than communication failure.

Before contacting technical support, verify the following:

- Unit is in Network Control mode
- The correct Modbus communication module is installed (RTU or TCP)
- The target register is supported by the unit type and configuration
- MicroTech unit controller application is v3.06 (250636306) and newer (applies to Modbus TCP only)
- Register numbers and scaling are correct
- Unit Status indicates the unit is enabled
- Application Mode permits the requested operation
- No active alarms or safeties are preventing operation
- BAS polling rates are within recommended limits
- No active alarms are limiting unit operation
- Written values are within allowable ranges and scaling is correct
- BAS polling rates are appropriate and not excessive

## Network Communications

- Confirm that the DHCP parameter is set to "Off" when a static IP address is being used for non-DHCP networks.

## Multiple IP Subnets - DHCP

- Networks with DHCP use a server (typically a router or gateway) to automatically request network configuration parameters, such as IP addresses, to all devices. DHCP-enabled networks eliminate the need for a user to configure these settings manually since IP Addresses and other parameters are determined dynamically by the server.
- TCP Only: Ping the unit controller using these steps if the communication module is not working:

| Step | Action                                                                    |
|------|---------------------------------------------------------------------------|
| 1    | Select Start > Run on the Windows start bar<br>The "Run" dialog box opens |
| 2    | Enter C:\>ping XX XX XX and press Enter<br>The ping result is displayed   |

- A response from that IP address indicates connection to the communication module. If the ping fails and there is no response, verify the IP communication module and the PC network settings.

## Network Wiring and Performance

If network traffic is slow, communication is intermittent, or the trunk is experiencing noise:

- Confirm that the shield is landed at only one point in the trunk.
- Be aware that the recommended network topology is daisy-chain (no T-Taps or ring layout).
- Verify that network wiring does not exceed 4000 ft total distance limit (without repeaters) at 38400 bps baud.
- Verify that polarity is maintained.
- Check that there are end-of-line termination resistors (120  $\Omega$ ) at the first and last device on the trunk. This is required by the EIA-485 specification.
- Verify that the network trunk avoids strong sources of electromagnetic interference (EMI).
- Note that the two-wire bus is *not* interchangeable and must be connected correctly.
- Verify that the network trunk is not located near a DC load switch (relay).

## Parts

**Table 11: Modbus TCP and Modbus RTU Communication Module Kit Part Numbers**

| Description                                                                                                                    | Part Number |
|--------------------------------------------------------------------------------------------------------------------------------|-------------|
| BACnet IP/Modbus TCP communication module kit (includes communication module, board-to-board connector and network connector). | 090016709   |
| Modbus RTU communication module (kit includes communication module, board-to-board connector and network connector).           | 350147413   |
| Network connector (3-pin)                                                                                                      | 193410303   |
| Board-to-board connector (10-pin)                                                                                              | 300047027   |

## Technical Assistance

For additional assistance, contact Daikin Applied Controls Customer Support at (800) 432-1342 or CTLTechSupport@daikinapplied.com.

## Appendix: ASCII Conversion

Table 12 lists the ASCII characters and their decimal and hexadecimal numbers. Non-printing characters, with the

exception of the (Space) character, are not listed in this table and are not supported. Characters not supported are translated to a space.

**Table 12: ASCII Conversion Table**

| Char (Space) | Decimal | Hexadecimal | Char | Decimal | Hexadecimal | Char | Decimal | Hexadecimal |
|--------------|---------|-------------|------|---------|-------------|------|---------|-------------|
|              | 32      | 0x20        | @    | 64      | 0x40        | `    | 96      | 0x60        |
| !            | 33      | 0x21        | A    | 65      | 0x41        | a    | 97      | 0x61        |
| "            | 34      | 0x22        | B    | 66      | 0x42        | b    | 98      | 0x62        |
| #            | 35      | 0x23        | C    | 67      | 0x43        | c    | 99      | 0x63        |
| \$           | 36      | 0x24        | D    | 68      | 0x44        | d    | 100     | 0x64        |
| % x 10       | 37      | 0x25        | E    | 69      | 0x45        | e    | 101     | 0x65        |
| &            | 38      | 0x26        | F    | 70      | 0x46        | f    | 102     | 0x66        |
| '            | 39      | 0x27        | G    | 71      | 0x47        | g    | 103     | 0x67        |
| (            | 40      | 0x28        | H    | 72      | 0x48        | h    | 104     | 0x68        |
| )            | 41      | 0x29        | I    | 73      | 0x49        | i    | 105     | 0x69        |
| *            | 42      | 0x2a        | J    | 74      | 0x4a        | j    | 106     | 0x6a        |
| +            | 43      | 0x2b        | K    | 75      | 0x4b        | k    | 107     | 0x6b        |
| ,            | 44      | 0x2c        | L    | 76      | 0x4c        | l    | 108     | 0x6c        |
| -            | 45      | 0x2d        | M    | 77      | 0x4d        | m    | 109     | 0x6d        |
| .            | 46      | 0x2e        | N    | 78      | 0x4e        | n    | 110     | 0x6e        |
| /            | 47      | 0x2f        | O    | 79      | 0x4f        | o    | 111     | 0x6f        |
| 0            | 48      | 0x30        | P    | 80      | 0x50        | p    | 112     | 0x70        |
| 1            | 49      | 0x31        | Q    | 81      | 0x51        | q    | 113     | 0x71        |
| 2            | 50      | 0x32        | R    | 82      | 0x52        | r    | 114     | 0x72        |
| 3            | 51      | 0x33        | S    | 83      | 0x53        | s    | 115     | 0x73        |
| 4            | 52      | 0x34        | T    | 84      | 0x54        | t    | 116     | 0x74        |
| 5            | 53      | 0x35        | U    | 85      | 0x55        | u    | 117     | 0x75        |
| 6            | 54      | 0x36        | V    | 86      | 0x56        | v    | 118     | 0x76        |
| 7            | 55      | 0x37        | W    | 87      | 0x57        | w    | 119     | 0x77        |
| 8            | 56      | 0x38        | X    | 88      | 0x58        | x    | 120     | 0x78        |
| 9            | 57      | 0x39        | Y    | 89      | 0x59        | y    | 121     | 0x79        |
| :            | 58      | 0x3a        | Z    | 90      | 0x5a        | z    | 122     | 0x7a        |
| ;            | 59      | 0x3b        | [    | 91      | 0x5b        | {    | 123     | 0x7b        |
| <            | 60      | 0x3c        | \    | 92      | 0x5c        |      | 124     | 0x7c        |
| =            | 61      | 0x3d        | ]    | 93      | 0x5d        | }    | 125     | 0x7d        |
| >            | 62      | 0x3e        | ^    | 94      | 0x5e        | ~    | 126     | 0x7e        |
| ?            | 63      | 0x3f        | _    | 95      | 0x5f        |      |         |             |

# Revision History

| Revision   | Date           | Description of Changes                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|------------|----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ED 19133   | April 2024     | Initial release                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| ED 19133-1 | September 2024 | Added Rebel DPS to cover page. Application software supports both Rebel Applied DPSA and Rebel DPS unit types. Added the following configuration options: 1. RO_DCSA to holding register 350 (Control Type) 2. SCR to holding register 373 (Preheat Type) and 3. Fujikoki_PAM 3000/Fujikoki_PAM 2000 (Fj2/Fj3) to holding register 374 (Expansion Valve Type), 4. DCSA to holding register 375 (IO Config), 5. OffEvac to holding register 245 (Unit Status) and removed AnlgMB1-AnlgMB3 to holding register 358 (SAF Type), holding register 364 (SAFlowInput) has been updated to remove unsupported options and holding register 365 (RFEFFlowInput) added option 3.                                                                                                                                                                                         |
| ED 19133-2 | October 2025   | Added holding registers:<br>RAFDSPSpt to 40134<br>HMISAFOAFlow to 40172-40173<br>VCmp3Hrs to 40203-40204<br>C3FCmp1.RunHrs to 40217-40218<br>C3FCmp3.RunHrs to 40219-40220<br>HiDPCIDsbldPrb to 40442<br>HiDPCIDsbldFlt to 40443<br>CondOvrflwPrb to 40444<br>HtRiseLmtgEvnt to 40445<br>4WV1Prob to 40446<br>4WV2Prob to 40447<br>4WV3Prob to 40448<br>C1OilRet_Event to 40449<br>C2OilRet_Event to 40450<br>C1OAFReqSB_Event to 40451<br>C2 OAFReqSB_Event to 40452<br>C3 events and problems to 40600-40635<br>C1HDLTULA_Event to 40508<br>C2HDLTULA_Event to 40543<br>C3HDLTULA_Event to 40635<br>LoCharge1Prob to 40459<br>LoCharge2Prob to 40460<br>C3LoCharge3Prob to 40461<br>BkUpRhtActEvnt to 40467<br>HPEmrgHtEvnt to 40464<br>C1HiSSHRHOvrd Evnt to 40462<br>C2HiSSHRHOvrd Evnt to 40463<br>Discharge Air Heating Setpoint (Electric Heat) to 40146 |
| ED 19133-3 | February 2026  | Changes to support controller application 2506036304. Added support for Models DPSA and DPS Carb/R-32 Refrigeration Only Controls (ROC) and DCSA Air-Cooled Split Condensing Systems. Added 2=NoComm to register 292 & 284. Added register 296, Defrost Status.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| ED 19133-4 | June 2026      | Changes to support Modbus TCP/IP (Ethernet) protocol. Updated configuration and added integration checklist. Removed Energy Wheel Recovery Warning Alarm (58). Added Problem alarms 63 and 73.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |

# COMPLETE HVAC SYSTEM SOLUTIONS

SELF-CONTAINED | ROOFTOPS | COILS | CONDENSING UNITS  
AIR HANDLERS | WATER-COOLED CHILLERS | AIR-COOLED CHILLERS  
MODULAR CENTRAL PLANTS | CONNECTED BUILDING CONTROLS  
UNIT HEATERS | FAN COILS | AIR PURIFIERS | WATER SOURCE HEAT PUMPS  
VARIABLE AIR VOLUME UNITS | UNIT VENTILATORS



13600 INDUSTRIAL PARK BLVD. | MINNEAPOLIS, MN 55441  
1-800-432-1342 | 763-553-5330

LEARN MORE AT  
**DAIKINAPPLIED.COM**