

Key-Lock Access Door for ThinLine Vertical Fan Coils

Group: Applied Air Systems


Part Number: 668115705

Date: August 2009

The key-lock access door kit can be installed on ThinLine 3G cabinet units to prevent access to unit controls. It is installed as follows.

- 1 Locate all components and remove from carton. Kit includes:
 - Tamperproof control door
 - 2 hinge pins
 - Locking mechanism
 - Locking mechanism keys
- 2 Open the control door on the fan coil. Then unscrew the two attaching screws and remove the door from the unit. See [Figure 1](#). Save screws for reattachment!

Figure 1: Remove Control Door From Unit




- 3 Remove the hinge pins from the old control door by either re-rounding the flattened pin ends with a needle-nose pliers or drilling out the pins with a 5/32" drill bit. Then separate the door from the hinge bracket.

Figure 2: Remove Old Door from Bracket



- 4 Attach the locking mechanism to the tamper-proof control door. See [Figure 3](#).
- 5 Attach the new tamperproof control door to the hinge bracket using new hinge pins. See [Figure 3](#). Secure the hinge pins to the bracket by pinching protruding ends with a needle-nose pliers.

Figure 3: Attach Bracket and Lock to New Door



- 6 Install the new door and locking mechanism on the unit using the screws removed in Step 2.